



FLEX 5000 Shield Bar

5094-STB, 5094-STB-QTY5

This publication describes the FLEX 5000™ shield bar for use with FLEX 5000 terminal base assemblies.

The FLEX 5000 shield bar is recommended with terminal base assemblies for all analog input, analog output and high speed counter modules.

The FLEX 5000 shield bars come in packs of five units.

The 5094-STB-QTY5 pack contains five screw-type shield bars and this publication.

5094-STB Technical Specifications

Attribute	Value
Voltage, max	300V AC
Current, max	10 A
Input/output ratings (IN/OUT), max	2A @ 32V DC
Wire size	0.34...2.5 mm ² (22...14 AWG) solid or stranded copper wire rated at 105 °C (221 °F), or greater, 1.2 mm (3/64 in.) insulation max
Wire strip length, max	12 mm ± 1 mm (0.47 in ± 0.04 in)
Torque specifications	0.4 N-m (3.5 lb-in)
Dimensions (HxWxD), approx	33.2 x 93.6 x 23.7 mm (1.30 x 3.68 x 0.93 in.)
Weight, approx	56 g (1.97 oz.)

For information on how to install the shield bar on FLEX 5000 terminal base assemblies, see the FLEX 5000 Terminal Base Assembly Modules Installation Instructions, publication [5094-IN010](#).



Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview.page , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, FLEX 5000, Rockwell Automation, Rockwell Software, and TechConnect are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 5094-PC002A-EN-P - May 2018

PN-482994

Copyright © 2018 Rockwell Automation, Inc. All rights reserved. Printed in Germany.