

# FLEX 5000 Analog I/O Modules

Catalog Numbers 5094-IF8, 5094-IF8XT, 5094-IY8, 5094-IY8XT, 5094-OF8, 5094-OF8XT



# Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

---

**IMPORTANT** Identifies information that is critical for successful application and understanding of the product.

---

Labels may also be on or inside the equipment to provide specific precautions.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



**ARC FLASH HAZARD:** Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

---

	<b>Preface .....</b>	<b>7</b>
	Summary of Changes .....	7
	Additional Resources .....	7
	<b>Chapter 1</b>	
<b>Analog I/O Module Operation in a Logix 5000 Control System</b>	Remote I/O Modules.....	10
	Before You Begin.....	11
	Types of Analog I/O Modules.....	11
	Module Overview .....	12
	Power FLEX 5000 I/O Modules.....	13
	SA Power Requirements .....	13
	Ownership .....	14
	Configure FLEX 5000	
	Analog I/O Modules .....	14
	Connections .....	14
	Requested Packet Interval .....	16
	Connection Over an EtherNet/IP Network .....	17
	Input Module Operation .....	17
	Output Module Operation.....	18
	Listen Only Mode.....	20
	Protected Operations.....	21
	<b>Chapter 2</b>	
<b>Common Analog I/O Module Features</b>	Rolling Timestamp of Data .....	24
	Rolling Timestamp with the 5094-IF8 and 5094-IY8 Modules	24
	Rolling Timestamp with the 5094-OF8 Module .....	24
	Floating Point Data Format .....	24
	Calibration .....	25
	Module Data Quality Reporting.....	25
	Calibration Causes Uncertain Data Quality Indication on Input	
	Module Groups .....	26
	Software Configurable.....	26
	Fault and Status Reporting.....	27
	Module Inhibiting.....	27
	Electronic Keying .....	28
	More Information .....	29
	Producer/Consumer Communication .....	29
	Status Indicators .....	29
	Use CIP Sync Time with	
	I/O Modules.....	30
	Alarm Latching .....	30
	Enable Latching.....	30
	Unlatch Alarms .....	31
	Scaling .....	31
	Data Offset .....	32

	Module Accuracy .....	33
	Absolute Accuracy at 25 °C (77 °F).....	33
	Module Accuracy Drift with Temperature.....	33
	Module Firmware .....	34
<b>Current/Voltage Analog Input Module Features (5094-IF8)</b>	<b>Chapter 3</b>	
	Module Features .....	36
	Multiple Input Ranges .....	36
	Notch Filter.....	37
	Digital Filter .....	40
	Underrange/Overrange Detection .....	41
	Process Alarms .....	42
	Rate Alarm.....	44
	Sensor Offset.....	45
	Open Wire Detection.....	45
	Over Temperature Detection.....	46
	Field Power Loss Detection.....	46
	Fault and Status Reporting.....	47
<b>Current/Voltage/Temperature- sensing Analog Input Module Features (5094-IY8)</b>	<b>Chapter 4</b>	
	Module Features .....	50
	Multiple Input Ranges .....	51
	Notch Filter.....	52
	Digital Filter .....	55
	Underrange/Overrange Detection .....	56
	Process Alarms .....	59
	Rate Alarm.....	61
	Sensor Types .....	62
	Sensor Offset.....	66
	10 Ohm Copper Offset .....	66
	Input SSV Switch Enable.....	66
	Open Wire Detection.....	67
	Temperature Units .....	68
	Over Temperature Detection.....	68
	Field Power Loss Detection.....	68
	Cold Junction Compensation .....	69
	Fault and Status Reporting.....	69

<b>Current/Voltage Analog Output Module Features (5094-OF8)</b>	<b>Chapter 5</b>	
	Module Features . . . . .	72
	Multiple Output Ranges . . . . .	72
	Channel Offset . . . . .	73
	Hold for Initialization . . . . .	73
	Connection Fault Handling . . . . .	74
	Output Clamping . . . . .	75
	Clamp Alarming . . . . .	76
	Output Ramping/Rate Limiting . . . . .	77
	Data Echo . . . . .	77
	No Load Detection . . . . .	78
	Short Circuit Protection . . . . .	78
	Over Temperature Detection . . . . .	79
Field Power Loss Detection . . . . .	79	
	Fault and Status Reporting . . . . .	80
<b>Configure the Module</b>	<b>Chapter 6</b>	
	Before You Begin . . . . .	82
	Create a New Module . . . . .	82
	Discover Modules . . . . .	83
	New Module . . . . .	85
	Edit the Module Configuration Common Categories . . . . .	87
	General Category . . . . .	87
	Connection Category . . . . .	89
	Module Info Category . . . . .	90
	Edit 5094-IF8 Module Configuration Categories . . . . .	91
	Channels Category . . . . .	91
	Calibration Category . . . . .	93
	Edit 5094-IY8 Module Configuration Categories . . . . .	94
	Channels Category . . . . .	94
	CJ Channels Category . . . . .	96
	Calibration Category . . . . .	96
	Edit 5094-OF8 Module Configuration Categories . . . . .	97
	Channels Category . . . . .	97
	Calibration Category . . . . .	99
	View the Module Tags . . . . .	100

	<b>Chapter 7</b>	
<b>Calibrate the Module</b>	Before You Begin.....	101
	Controller State During Calibration .....	102
	Calibration Impacts Data Quality on Entire Input Module Group	
	102	
	Difference Between Calibrating an Input Module and an Output	
	Module.....	103
	Calibrate the Input Modules .....	104
	Calibrate the 5094-IF8 Module.....	104
	Calibrate the 5094-IY8 Module .....	107
	Calibrate the Output Modules .....	110
	Calibrate a 5094-OF8 Module.....	110
	<b>Appendix A</b>	
<b>Troubleshoot Your Module</b>	SA Power Indicator .....	115
	Module Status Indicator .....	116
	FLEX 5000 Analog Input Modules Status Indicators.....	117
	FLEX 5000 Analog Output Modules Status Indicators.....	119
	Use the Logix Designer Application for Troubleshooting.....	121
	Warning Signal in the I/O Configuration Tree .....	121
	Status and Fault Information in Module Properties Categories	122
	Logix Designer Application Tag Editor.....	125
	<b>Appendix B</b>	
<b>Module Tag Definitions</b>	Tag Name Conventions .....	128
	Access the Tags .....	128
	5094-IF8 Module Tags .....	129
	Configuration Tags.....	129
	Input Tags.....	131
	Output Tags .....	134
	5094-IY8 Module Tags .....	136
	Configuration Tags.....	136
	Input Tags .....	141
	Output Tags .....	145
	5094-OF8 Module Tags .....	147
	Configuration Tags.....	147
	Input Tags.....	149
	Output Tags .....	152
	<b>Index.....</b>	<b>155</b>

This manual describes how to use FLEX 5000 analog I/O modules in Logix 5000™ control systems.

Make sure that you are familiar with the following:

- Use of a controller in a Logix 5000 control system
- Use of an EtherNet/IP network, if the analog I/O modules are installed in a remote location from the controller that is accessible via the EtherNet/IP network
- Studio 5000 Logix Designer® environment

- 
- IMPORTANT** Remember the following when you use FLEX 5000 analog I/O modules:
- You cannot use FLEX 5000 I/O modules with all Logix 5000 controllers. For example, you can use FLEX 5000 I/O modules with CompactLogix™ 5380 and ControlLogix® 5580 controllers but not with CompactLogix 5370 and ControlLogix 5570 controllers.  
For the most current information on the Logix 5000 controllers with which you can use FLEX 5000 I/O modules, see the product description at <http://www.ab.com>.
  - You must use the Logix Designer application, **version 31 or later**, to configure the FLEX 5000 analog I/O modules.
- 

## Summary of Changes

This manual contains new and updated information as indicated in the following table.

Topic	Page
Removed section Multiple Owners of FLEX 5000 Input Modules	14
Updated section Input SSV Switch Enable feature for 5094-IY8	66

## Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
FLEX 5000 EtherNet/IP Adapters with RJ45 Ports Installation Instructions, publication <a href="#">5094-IN001</a>	Describes how to install and wire the 5094-AENTR, 5094-AENTRXT, 5094-AEN2TR, and 5094-AEN2TRXT EtherNet/IP adapters.
FLEX 5000 EtherNet/IP Adapters with SFP Support Installation Instructions, publication <a href="#">5094-IN002</a>	Describes how to install and wire the 5094-AENSFPRXT and 5094-AEN2SFPRXT EtherNet/IP adapters.
FLEX 5000 Digital 16-point Sinking Input Modules Installation Instructions, publication <a href="#">5094-IN003</a>	Describes how to install and wire the 5094-IB16 and 5094-IB16XT digital input modules.
FLEX 5000 Digital 16-point Sourcing Output Modules Installation Instructions, publication <a href="#">5094-IN004</a>	Describes how to install and wire the 5094-OB16 and 5094-OB16XT digital output modules.

FLEX 5000 Digital 8-point Isolated Relay Output Modules Installation Instructions, publication <a href="#">5094-IN005</a>	Describes how to install and wire the 5094-OW8I and 5094-OW8IXT digital output modules.
FLEX 5000 Analog 8-channel Current/Voltage Input Modules Installation Instructions, publication <a href="#">5094-IN006</a>	Describes how to install and wire the 5094-IF8 and 5094-IF8XT analog input modules.
FLEX 5000 Analog 8-channel Current/Voltage Output Modules Installation Instructions, publication <a href="#">5094-IN007</a>	Describes how to install and wire the 5094-OF8 and 5094-OF8XT analog output modules.
FLEX 5000 Analog 8-channel Current/Voltage/RTD/ Thermocouple Input Modules Installation Instructions, publication <a href="#">5094-IN008</a>	Describes how to install and wire the 5094-IY8 and 5094-IY8XT analog input modules.
FLEX 5000 High-speed Counter I/O Modules Installation Instructions, publication <a href="#">5094-IN009</a>	Describes how to install and wire the 5094-HSC and 5094-HSCXT high-speed counter I/O modules.
FLEX 5000 Terminal Base Assembly Modules Installation Instructions, publication <a href="#">5094-IN010</a>	Describes how to install and wire the terminal base assemblies for the FLEX 5000 system.
FLEX 5000 Modules Specifications Technical Data, publication <a href="#">5094-TD001</a>	Provides specifications for FLEX 5000 EtherNet/IP adapters and FLEX 5000 modules.
CompactLogix 5380 Controllers User Manual, publication <a href="#">5069-UM001</a>	Describes how to configure, operate, and troubleshoot CompactLogix 5380 controllers.
FLEX 5000 Digital I/O Modules User Manual, publication <a href="#">5094-UM001</a>	Describes how to configure, operate, and troubleshoot FLEX 5000 digital I/O modules.
FLEX 5000 Analog I/O Modules User Manual, publication <a href="#">5094-UM002</a>	Describes how to configure, operate, and troubleshoot FLEX 5000 analog I/O modules.
FLEX 5000 High-speed Counter I/O Modules User Manual, publication <a href="#">5094-UM003</a>	Describes how to configure, operate, and troubleshoot FLEX 5000 high-speed counter modules.
EtherNet/IP Communication Modules in 5000 Series Control Systems User Manual, publication <a href="#">ENET-UM004</a>	Describes how to configure, operate, and troubleshoot the FLEX 5000 EtherNet/IP adapters.
Integrated Architecture and CIP Sync Configuration Application Technique, publication <a href="#">IA-AT003</a>	Provides information about CIP Sync technology and how to synchronize clocks within the Rockwell Automation® Integrated Architecture® system.
Electronic Keying in Logix5000 Control Systems Application Technique, publication <a href="#">LOGIX-AT001</a>	Describes how to use electronic keying in Logix5000 control system applications.
Logix5000 Controllers Tasks, Programs, and Routines Programming Manual, publication <a href="#">1756-PM005</a>	Provides more information on event tasks and event task configuration.
Position-based Output Control with the MAOC Instruction, publication <a href="#">1756-AT017</a>	Describes how to configure time-scheduled output control with the MAOC instruction.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <a href="http://www.rockwellautomation.com/rockwellautomation/certification/overview.page">http://www.rockwellautomation.com/rockwellautomation/certification/overview.page</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/global/literature-library/overview.page>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative



## Analog I/O Module Operation in a Logix 5000 Control System

Topic	Page
Remote I/O Modules	10
Before You Begin	11
Types of Analog I/O Modules	11
Module Overview	12
Power FLEX 5000 I/O Modules	13
Ownership	14
Configure FLEX 5000 Analog I/O Modules	14
Input Module Operation	17
Output Module Operation	18
Listen Only Mode	20
Protected Operations	21

---

**IMPORTANT** You cannot use FLEX 5000 I/O modules with all Logix 5000™ controllers. For example, you can use FLEX 5000 I/O modules with CompactLogix™ 5380 and ControlLogix® 5580 controllers but not with CompactLogix 5370 and ControlLogix 5570 controllers.

You can use FLEX 5000 I/O modules with Logix 5000 controllers as remote I/O modules only.

Throughout this publication, the term **Logix 5000 controller** refers to the controllers with which you can use FLEX 5000 I/O modules in a given capacity. The term does not refer to all Logix 5000 controllers.

For the most current information on the Logix 5000 controllers with which you can use FLEX 5000 I/O modules, see the product description at <http://www.ab.com>.

---

Logix 5000 controllers use FLEX 5000 analog I/O modules to control devices in a control system. The controllers access the modules over an EtherNet/IP network. FLEX 5000 analog I/O modules use terminal base (TB) assemblies to connect field-side wiring.

Analog I/O modules convert analog signals to digital values for inputs and convert digital values to analog signals for outputs. Controllers use these signals for control purposes.

FLEX 5000 analog I/O modules use the Producer/Consumer network communication model. This communication is an intelligent data exchange between modules and other system devices in which each module produces data without first being polled. You use the Studio 5000 Logix Designer® application, version 31 or later, to configure the modules.

## Remote I/O Modules

You use FLEX 5000 analog I/O modules as remote I/O modules that are accessible via an EtherNet/IP network. The modules are installed to the right of a FLEX 5000 EtherNet/IP adapter.

Logix 5000 controllers can exchange data with the modules over the network.


---

**IMPORTANT** You cannot use FLEX 5000 I/O modules as remote I/O modules with all Logix 5000 controllers. For example, you can use FLEX 5000 I/O modules with CompactLogix 5380 and ControlLogix 5580 controllers but not with CompactLogix 5370 and ControlLogix 5570 controllers.

For the most current information on the Logix 5000 controllers with which you can use FLEX 5000 I/O modules, see the product description at <http://www.ab.com>.

---

Figure 1 - FLEX 5000 I/O Modules in a Logix 5000 Control System



## Before You Begin

Before you use your analog I/O module, you must complete the following:

- a. Install a FLEX 5000 EtherNet/IP adapter.
- b. Install the FLEX 5000 I/O modules to the right of adapter.
- c. Install an EtherNet/IP network.
- d. Install the Logix 5000 controller that accesses the FLEX 5000 I/O modules via an EtherNet/IP network.

Make sure that you have enough FLEX 5000 terminal base (TB) assemblies to satisfy your application needs. For more information, see the FLEX 5000 Terminal Base Assembly Modules Installation Instructions, publication [5094-IN010](#).

---

**IMPORTANT** TBs are not included with your module and are not available for purchase. TBs consists of a mounting base (MB) and removable terminal block (RTB). You must purchase MBs and RTBs separately and assemble them together.

---

## Types of Analog I/O Modules

[Table 1](#) describes the types of FLEX 5000 analog I/O modules.

**Table 1 - FLEX 5000 Analog I/O Modules**

Cat. No.	Description
5094-IF8, 5094-IF8XT	8-channel current/voltage input module
5094-IY8, 5094-IY8XT	8-channel current/voltage/RTD/thermocouple input module
5094-OF8, 5094-OF8XT	8-channel current/voltage output module

Module Overview

Figure 2 shows the parts of an example FLEX 5000 analog I/O module.

Figure 2 - Example FLEX 5000 Analog I/O Module




Table 2 - FLEX 5000 Analog I/O Module Parts

Item	Description
1	<b>Status indicators</b> - Displays the status of communication, module health, and input/output devices. Indicators help with troubleshooting anomalies.
2	<b>Release lever</b> - Disengages the latching hooks to allow removal of the module from the terminal base assembly.
3	<b>Module keying</b> - Indicates the keying position the terminal base assembly must be configured to before installing the module.
4	<b>Terminal base</b> - Indicates the type of terminal base assembly to use with the module.
5	<b>Latching hooks</b> - Securely installs FLEX 5000 modules on the terminal base assembly.

## Power FLEX 5000 I/O Modules

FLEX 5000 analog I/O modules receive the following power types:

- System-side power that powers the system and lets modules transfer data and execute logic. System-side power is also known as Backplane power.
- Field-side power that powers field-side devices that are connected to some FLEX 5000 I/O modules. Field-side power is also known as SA power.

System-side power begins at the FLEX 5000 EtherNet/IP adapter and passes across the FLEX 5000 module internal circuitry via terminal base power bus, that is, Backplane power.

Field-side power, that is, SA power begins at the first terminal base assembly and can be daisy-chained to the next terminal base assembly on the right. You can also install a separate field-side power source to each terminal base assembly.

For more information on how to power FLEX 5000 analog I/O modules, see the EtherNet/IP Communication Modules in 5000 Series Systems User Manual, publication [ENET-UM004](#).

### SA Power Requirements

Take note of the following when supplying SA power to your system:

- You must limit the SA field-side power source to 10 A, max, at 18...32V DC.
- Confirm that the external module power supply is adequately sized for the total module power bus current draw in the system.

For example, if the total module power current draw, including current inrush requirements, is 5 A, you can use a module power supply that is limited to 5 A.

- You must use SELV-listed power supplies for module power if there are Functional Safety modules that are connected to the FLEX 5000 I/O family.
- Not all power supplies are certified for use in all applications, for example, nonhazardous and hazardous environments.

---

**IMPORTANT** We recommend that you use separate external power supplies for the adapter and the adjacent terminal base. This practice can prevent unintended consequences that can result if you use one supply.

---

## Ownership

Every I/O module in a Logix 5000 control system must be owned by a controller, also known as the owner-controller. When the FLEX 5000 analog I/O modules are used in a Logix 5000 control system, the owner-controller performs the following:

- Stores configuration data for every module that it owns.
- Can reside in a location that differs from the FLEX 5000 I/O modules.
- Sends the I/O module configuration data to define module behavior and begin operation in the control system.

Each FLEX 5000 analog I/O module must continuously maintain communication with its owner-controller during normal operation.

Typically, each I/O module in a FLEX 5000 I/O system has only one owner-controller. Output modules are limited to one owner-controller.

## Configure FLEX 5000 Analog I/O Modules

You must create a Logix Designer application project for the Logix 5000 controller that owns the FLEX 5000 analog I/O modules. The project includes module configuration data for the FLEX 5000 analog I/O modules.

The Logix Designer application transfers the project to the owner-controller during the program download. Data is then transferred to the FLEX 5000 analog I/O modules over the EtherNet/IP network.

The FLEX 5000 analog I/O modules can operate immediately after receiving the configuration data.

## Connections

During module configuration, you must define the module. Among the Module Definition parameters, you must choose a connection type for the module. A connection is a real-time data transfer link between the owner-controller and the module that occupies the slot that the configuration references.

When you download module configuration to a controller, the controller attempts to establish a connection to each module in the configuration.

Because part of module configuration includes a slot in the FLEX 5000 I/O system, the owner-controller checks for the presence of a module there. If a module is detected, the owner-controller sends the configuration. One of the following occurs:

- If the configuration is appropriate to the module detected, a connection is made and operation begins.

- If the configuration is not appropriate to the module detected, the data is rejected and the Logix Designer application indicates that an error occurred.

The configuration can be inappropriate for many reasons. For example, a mismatch in electronic keying that helps prevents normal operation.

The owner-controller monitors its connection with a module. Any break in the connection, for example, the loss of power to the FLEX 5000 I/O system, causes a fault. The Logix Designer application monitors the fault status tags to indicate when a fault occurs on a module.

### *Connection Types Available with FLEX 5000 Analog I/O Modules*

When configuring a FLEX 5000 analog I/O module, you must define the module. Connection is a required parameter in the Module Definition. The choice determines what data is exchanged between the owner-controller and the module.

[Table 3](#) describes the connection types that you can use with FLEX 5000 analog I/O modules.

**Table 3 - Connections - FLEX 5000 Analog I/O Modules**

Connection Type	Description	
	FLEX 5000 Analog Input Modules	FLEX 5000 Analog Output Modules
Data	The module returns the following to the owner-controller: <ul style="list-style-type: none"> <li>• General fault data</li> <li>• Input data</li> </ul>	The module returns the following to the owner-controller: <ul style="list-style-type: none"> <li>• General fault data</li> <li>• Output data</li> </ul>
Data with Calibration	The module returns the following to the owner-controller: <ul style="list-style-type: none"> <li>• General fault data</li> <li>• Input data</li> <li>• Calibration data</li> </ul>	The module returns the following to the owner-controller: <ul style="list-style-type: none"> <li>• General fault data</li> <li>• Output data</li> <li>• Calibration data</li> </ul>
Listen Only	<p>When a Listen Only data connection is used, another controller owns the module. A controller that makes a Listen Only connection to the module does not write configuration for the module. It merely listens to the data exchanged with the owner-controller.</p> <p><b>IMPORTANT:</b> If a controller uses a Listen Only connection, the connection must use the Multicast option.</p> <p>For more information on Listen Only connections, see <a href="#">Listen Only Mode on page 20</a>. In this case, all other connections to the module, for example, the connection to the owner-controller must also use the Multicast option.</p>	

### *Data Types Available with FLEX 5000 Analog I/O Modules*

The Module Definition includes a Data parameter that matches the module type. Analog input modules use Input Data, and analog output modules use Output Data.

The available Data parameter choices are as follows:

- Analog input modules - The Input Data choice is always Analog Data.
- Analog output modules - The Output Data choices are Analog Data or None. The Output Data choice None is only available if you choose the Connection parameter Listen Only.

For more information on the Connection and Data parameter choices available with FLEX 5000 I/O modules, see the Logix Designer application.

## **Requested Packet Interval**

The Requested Packet Interval (RPI) is a configurable parameter that defines a specific rate at which data is exchanged between the owner-controller and the module.

You set the RPI value during initial module configuration and can adjust it as necessary after module operation has begun. Valid RPI values are 0.2...750 ms.

- 
- |                  |  |
|------------------|--|
| <b>IMPORTANT</b> | If you change the RPI while the project is online, the connection to the module is closed and reopened in one of the following ways: <ul style="list-style-type: none"><li>• You inhibit the connection to the module, change the RPI value, and uninhibit the connection.</li><li>• You change the RPI value. In this case, the connection is closed and reopened immediately after you apply the change to the module configuration.</li></ul> |
|------------------|--|
- 

For more information on guidelines for specifying RPI rates, see the Logix5000 Controllers Design Considerations Reference Manual, publication [1756-RM094](#).



## Connection Over an EtherNet/IP Network

During module configuration, you must configure the Connection over EtherNet/IP parameter. The configuration choice dictates how input data is broadcast over the network.

The FLEX 5000 analog I/O modules use one of the following methods to broadcast data:

- Multicast - Data is sent to all network devices
- Unicast - Data is sent to a specific controller depending on the module configuration

Unicast is the default setting. We recommend that you use Unicast because it reduces network bandwidth usage.

## Input Module Operation

Logix 5000 controllers do not poll the FLEX 5000 analog input modules for input data. Instead, the input modules send their input data, that is channel and status data, at the RPI.

At the RPI, not only does the module send input data to the controller, but also the controller sends data to the module inputs. For example, the controller sends data to command the module to unlatch alarms or enable alarms.

FLEX 5000 analog input modules reside in a FLEX 5000 I/O system that is accessible to a Logix 5000 controller over an EtherNet/IP network. A FLEX 5000 EtherNet/IP adapter is the first component in a FLEX 5000 I/O system and connects the system to the EtherNet/IP network.

FLEX 5000 analog input modules communicate input data to the FLEX 5000 EtherNet/IP adapter at the defined RPI. The input data consists of channel and status data.

At the RPI, the following events occur.

1. The remote analog input module scans its channels for input data.
2. The module sends the data to the FLEX 5000 EtherNet/IP adapter.
3. The FLEX 5000 EtherNet/IP adapter in the FLEX 5000 I/O system sends the data over the EtherNet/IP network.
4. One of the following:
  - If the controller is directly connected to the EtherNet/IP network, it receives the input data immediately.
  - If the controller is connected to the EtherNet/IP network through another communication module, the module sends the data to its backplane and the controller receives it.

## Output Module Operation

The controller sends data to an output module at the RPI or after an Immediate Output (IOT) instruction is executed.

The RPI defines when the controller sends data to the FLEX 5000 analog output module and when the output module echoes data. The controller sends data to an output module only at the RPI.

At the RPI, not only does the controller send data to the output module, but also the output module sends data to the controller. For example, the output module sends an indication of the channel data quality.

FLEX 5000 analog input modules reside in a FLEX 5000 I/O system that is accessible to a Logix 5000 controller over an EtherNet/IP network. A FLEX 5000 EtherNet/IP adapter is the first component in a FLEX 5000 I/O system and connects the system to the EtherNet/IP network.

FLEX 5000 analog output modules receive output data from a controller. The output module also sends data to the controller.

### *Controller to Remote Analog Output Module Data Transmission*

The controller broadcasts data to its local backplane at one of the following:

- RPI
- An IOT instruction is executed.

---

**IMPORTANT** An IOT instruction sends data to all of the output modules in the system immediately, and resets the RPI timer.

---

Based on the RPI rate and the length of the controller program scan, the output module can receive and echo data multiple times during one program scan.

When the RPI is less than the program scan length, the output channels can change values multiple times during a program scan. The owner-controller does not depend on the program scan to complete to send data.

These events occur when the controller sends data to a FLEX 5000 output module.

1. Data is sent in one of the following ways:
  - If the controller is directly connected to the EtherNet/IP network, it broadcasts data to the network.  
In this case, skip to [step 3](#).

- If the controller is connected to the EtherNet/IP network via a communication module, the controller transmits the data to the backplane.

In this case, proceed to [step 2](#).

2. The EtherNet/IP communication module transmits the data to the EtherNet/IP network.
3. The FLEX 5000 EtherNet/IP adapter in the FLEX 5000 I/O system receives the data from the network and transmits it to the backplane.
4. The remote analog output module receives the data from the backplane and behaves as dictated by its configuration.

### *Remote Analog Output Module to Controller Data Transmission*

When a FLEX 5000 analog output module receives new data and the requested data value is present on the RTB, the output module sends, or 'echoes', a data value back to the controller and to the rest of the control system. The data value corresponds to the signal present at its terminals. This feature is called [Data Echo](#).

In addition to the Data Echo, the output module sends other data to the controller at the RPI. For example, the module alerts the controller if a short circuit condition exists on the module.

The following events occur when a remote FLEX 5000 analog output module sends data to the controller at the RPI.

1. The module sends the data to the backplane.
2. The FLEX 5000 EtherNet/IP adapter in the FLEX 5000 I/O system sends the data over the EtherNet/IP network.
3. One of the following:
  - If the controller is directly connected to the EtherNet/IP network, it receives the input data from the network without need for a communication module.
  - If the controller is connected to the EtherNet/IP network through another communication module, the module transmits the data to its backplane and the controller receives it.

## Listen Only Mode

Any controller in the system can listen to the data from an I/O module. An owner-controller, as described in [Ownership on page 14](#), exchanges data with analog I/O modules.

Other controllers can use a Listen Only connection with the analog I/O module. In this case, the 'listening' controller can only listen to input data or 'echoed' output data. The listening controller does not own the module configuration or exchange other data with the module.

During the I/O configuration process, you can specify a Listen Only connection. For more information on Connection options, see [Module Definition on page 88](#).

---

**IMPORTANT** Remember the following:

- If a controller uses a Listen Only connection, the connection must use the Multicast option. In this case, all other connections to the module, for example, the connection of the owner-controller, must also use the Multicast option.
  - If a controller attempts to use a Listen Only connection to a module but the owner-controller connection uses the Unicast option, the attempt at a Listen Only connection fails.  
The 'Listen Only' controller receives data from the module as long as a connection between an owner-controller and module is maintained.
  - If the connection between an owner-controller and the module is broken, the module stops sending data and connections to all 'listening controllers' are also broken.
-

## Protected Operations

To maintain the secure operation of your FLEX 5000 analog I/O module, operations that can disrupt module operation are restricted based on the module operating mode. [Table 4](#) describes the restrictions.

**Table 4 - Protected Operations on FLEX 5000 Analog I/O Modules**

Current Module Operation	Activity							
	Firmware Update Request	Module Reset Request	Module Calibration Request <sup>(3)</sup>	Connection Request	Configuration Change	Connection or Data Format Change	Electronic Keying Change	RPI Change
Connection not running	Accepted							
Connection running	Rejected <sup>(1)</sup>			Accepted <sup>(4)</sup>	Accepted <sup>(5)</sup>	Not allowed <sup>(6)</sup>	Accepted <sup>(7)</sup>	
Firmware update is in process	Rejected							
Calibration is in process	Accepted <sup>(2)</sup>							

(1) A module calibration request is accepted when the module is connected and the owner-controller is in Program mode.

(2) The module accepts the requests and changes listed. Keep in mind, when the request or change is made, the calibration process is automatically aborted. We recommend that you wait for the module calibration to finish before attempting any of the requests or changes.

(3) When the request is made through the Module Properties dialog box.

(4) Only requests for Listen Only connections are accepted.

(5) Configuration change is accepted in the following scenarios:

- Changes are made in the Module Properties dialog box and you click Apply.
- Changes are made in the Configuration tags and you send a Reconfigure Module MSG to the module.

(6) The difference between Rejected and Not allowed is that rejected activities can be attempted in the Logix Designer application but do not take effect. The activities that are not allowed, that is, attempts to change the Connection or Data Format used, do not occur in the Logix Designer application.

For example, if you attempt to reset a module that is connected to the owner-controller, the Logix Designer application executes the request and alerts you that it was rejected. If you attempt to change the data format on a module that is connected to an owner-controller, the Logix Designer application does not execute the attempted change. The application only alerts you that the change is not allowed. In the case, if the change is attempted online, the Module Definition dialog box field that changes the data format is disabled.

(7) The change occurs after the connection is closed and reopened. You can close and reopen the connection in the following ways:

- Change the project while it is offline and download the updated project before going online again.
- Change the project while it is online and click Apply or OK in the Module Properties dialog box. In this case, before the change is made, a dialog box alerts you of the ramifications before the change is made.

## **Notes:**

## Common Analog I/O Module Features

Topic	Page
Rolling Timestamp of Data	24
Floating Point Data Format	25
Calibration	25
Module Data Quality Reporting	25
Software Configurable	26
Fault and Status Reporting	27
Module Inhibiting	27
Electronic Keying	28
Producer/Consumer Communication	29
Status Indicators	29
Use CIP Sync Time with I/O Modules	30
Alarm Latching	30
Scaling	31
Data Offset	32
Module Accuracy	33
Module Firmware	34

This chapter describes module features that are available on all FLEX 5000 analog I/O modules.

FLEX 5000 analog input modules convert an analog signal to a digital value. For example, the modules can convert the following:

- Volts
- Millivolts
- Milliamps
- Ohms

FLEX 5000 analog output modules convert a digital value to an analog signal. For example, the modules can convert the following:

- Volts
- Milliamps

## Rolling Timestamp of Data

The rolling timestamp is a continuously running 15-bit rolling timestamp that counts in milliseconds from 0...32,767 ms.

The rolling timestamp value is reported in the *I.Chxx.RollingTimestamp* tag for the FLEX 5000 analog I/O modules.

### Rolling Timestamp with the 5094-IF8 and 5094-IY8 Modules

Typically, the FLEX 5000 analog input modules scan their inputs at the RPI. The module also updates the rolling timestamp data at the RPI. The controller program uses the last two rolling timestamp values to calculate the amount of time between the samples.

A system time change can cause a slight change in input sample timing. The rolling timestamp accurately reflects the change.

There can be jitter in the timing between samples before and after the system time change.

### Rolling Timestamp with the 5094-OF8 Module

For the FLEX 5000 analog output modules, the rolling timestamp value is updated only when new values are applied to the Digital to Analog Converter (DAC).

## Floating Point Data Format

The FLEX 5000 analog I/O modules return channel data to the controller in the IEEE 32-bit floating point data format. In your Logix Designer application, the data type is REAL.

The floating point data format lets you change the data representation of the selected channel. Although the full range of the module does not change, you can scale your module to represent I/O data in specific terms for your application.

For more information on using scaling, see [page 31](#).



## Calibration

The FLEX 5000 analog I/O modules use precise analog components that maintain their specifications over time. The modules are calibrated via the following methods:

- Factory calibration when the modules are built.
- User-executed calibration.

For more information on how to calibrate a module, see Chapter 7, [Calibrate the Module on page 101](#).

## Module Data Quality Reporting

The FLEX 5000 analog I/O modules indicate the quality of channel data that is returned to the owner-controller. Data quality represents accuracy. Levels of data quality are reported via module input tags.

The following inputs indicate the level of data quality.

- I.Chxx.Fault - This tag indicates that the reported channel data is inaccurate and cannot be trusted for use in your application. Do not use the reported channel data for control.

If the tag is set to 1, you cannot trust the data reported. You must troubleshoot the module to correct the cause of the inaccuracy.

Example causes of inaccurate data include the following:

- Channel is disabled
- Open Wire condition (input modules)
- No Load condition (output modules)
- Underrange/Overrange condition
- Short Circuit condition
- Field Power Loss condition

We recommend that you troubleshoot the module for the typical causes first.

- I.Chxx.Uncertain - This tag indicates that the reported channel data can be inaccurate but the degree of inaccuracy is unknown. We recommend that you do not use the reported channel data for control.

If the tag is set to 1, you know that the data can be inaccurate. You must troubleshoot the module to discover what degree of inaccuracy exists.

Example causes of uncertain data include the following:

- Data signal slightly outside the channel operating range
- The channel is slightly over temperature
- Invalid sensor offset value
- Calibration fault on the channel

- Calibration is in process on the channel - Active calibration process on one channel can cause an indication of Uncertain data quality on other module channels simultaneously.

We recommend that you monitor the tags in your program to make sure that the application is operating as expected with accurate channel input data.

---

**IMPORTANT** Once the condition that causes the Fault or Uncertain tag to change to 1 is removed, the tag automatically resets to 0. The Logix Designer application controls the tags. You cannot change the status of the tags.

Keep in mind that in some system configurations, the tag is not reset immediately after the condition is removed. The tag typically resets after a small delay.

---

## Calibration Causes Uncertain Data Quality Indication on Input Module Groups

When a channel on a FLEX 5000 analog input module is being calibrated, the Notch Filter setting for that channel changes to 5 Hz. This results in the *I.Chxx.Uncertain* tag being set to 1 for that channel until calibration is completed.

Grouped inputs share an Analog-to-Digital converter. As a result when any input channel is in the calibration process, the *I.Chxx.Uncertain* tag is set to 1 for the other input channels in that group. This setting is because the data sampling rate slows for all input channels in the group.

The Notch Filter settings for the other input channels in the group remain the same.

## Software Configurable

You use the Logix Designer application to configure the module, monitor system operation, and troubleshoot issues. You can also use the Logix Designer application to retrieve the following information from any module in the system:

- Serial number
- Firmware revision information
- Product code
- Vendor
- Error and fault information
- Diagnostic information

By minimizing the need for tasks, such as setting hardware switches and jumpers, the software makes module configuration easier and more reliable.

## Fault and Status Reporting

The FLEX 5000 analog I/O modules report fault and status data along with channel data. Fault and status data is reported in the following ways:

- Logix Designer application
- Module status indicators

For more information on fault reporting, see the individual module feature chapters and Appendix A, [Troubleshoot Your Module on page 115](#).

## Module Inhibiting

Module inhibiting lets you indefinitely suspend a connection, including Listen Only connections, between an owner-controller and an analog I/O module without removing the module from the configuration. This process lets you temporarily disable a module, such as to perform maintenance.

You can use module inhibiting in the following ways:

- You write a configuration for an I/O module but inhibit the module to help prevent it from communicating with the owner-controller. The owner does not establish a connection and the configuration is not sent to the module until the connection is uninhibited.
- In your application, a controller already owns a module, has downloaded the configuration to the module, and is exchanging data over the connection between the devices.

In this case, you can inhibit the module and the connection to the module does not exist.

---

**IMPORTANT** Whenever you inhibit an output module that is ProgMode enabled, it enters Program mode, and all outputs change to the state configured for Program mode.

For example, if an output module is configured so that the state of the outputs transition to zero during Program mode, whenever that module is inhibited, outputs transition to zero.

---

You can use module inhibiting in these instances:

- You want to update a analog I/O module, for example, update the module firmware revision. Use the following procedure.
  - a. Inhibit the module.
  - b. Perform the update.
  - c. Uninhibit the module.

- You use a program that includes a module that you do not physically possess yet. You do not want the controller to look for a module that does not yet exist. In this case, you can inhibit the module in your program until it physically resides in the proper slot.

To see where to inhibit a FLEX 5000 analog I/O module, see [page 89](#).

## Electronic Keying

Electronic Keying reduces the possibility that you use the wrong device in a control system. It compares the device that is defined in your project to the installed device. If keying fails, a fault occurs. These attributes are compared.

Attribute	Description
Vendor	The device manufacturer.
Device Type	The general type of the product, for example, analog I/O module.
Product Code	The specific type of the product. The Product Code maps to a catalog number.
Major Revision	A number that represents the functional capabilities of a device.
Minor Revision	A number that represents behavior changes in the device.

The following Electronic Keying options are available.

Keying Option	Description
Compatible Module	<p>Lets the installed device accept the key of the device that is defined in the project when the installed device can emulate the defined device. With Compatible Module, you can typically replace a device with another device that has the following characteristics:</p> <ul style="list-style-type: none"> <li>• Same catalog number</li> <li>• Same or higher Major Revision</li> <li>• Minor Revision as follows: <ul style="list-style-type: none"> <li>– If the Major Revision is the same, the Minor Revision must be the same or higher.</li> <li>– If the Major Revision is higher, the Minor Revision can be any number.</li> </ul> </li> <li>• Non-XT and XT version as follows: <ul style="list-style-type: none"> <li>– You can use an XT version of the module in place of a non-XT module.</li> <li>– You <b>cannot</b> use a non-XT version of the module in place of an XT module.</li> </ul> </li> </ul>
Disable Keying	<p>Indicates that the keying attributes are not considered when attempting to communicate with a device. With Disable Keying, communication can occur with a device other than the type specified in the project.</p> <p><b>ATTENTION:</b> Be extremely cautious when using Disable Keying; if used incorrectly, this option can lead to personal injury or death, property damage, or economic loss.</p> <p>We <b>strongly recommend</b> that you <b>do not use</b> Disable Keying.</p> <p>If you use Disable Keying, you must take full responsibility for understanding whether the device being used can fulfill the functional requirements of the application.</p>
Exact Match	Indicates that all keying attributes must match to establish communication. If any attribute does not match precisely, communication with the device does not occur.

Carefully consider the implications of each keying option when selecting one.

---

**IMPORTANT** Changing Electronic Keying parameters online interrupts connections to the device and any devices that are connected through the device. Connections from other controllers can also be broken.

If an I/O connection to a device is interrupted, the result can be a loss of data.

---

## More Information

For more detailed information on Electronic Keying, see Electronic Keying in Logix5000 Control Systems Application Technique, publication [LOGIX-AT001](#).

## Producer/Consumer Communication

FLEX 5000 analog I/O modules use the Producer/Consumer communication model to produce data without a controller polling them first. The modules produce the data and controllers consume it. That is, the owner-controller and controllers with a Listen Only connection to the module can consume it.

When an input module produces data, the controllers can consume the data simultaneously. Simultaneous data consumption eliminates the need for one controller to send the data to other controllers.

---

**IMPORTANT** Keep in mind, **only one controller** can own the I/O module. The FLEX 5000 analog I/O modules do not support multiple owners of the same module. Other controllers must use a Listen Only connection to the module.

---

## Status Indicators

Each FLEX 5000 analog I/O module has a status indicator on the front of the module that lets you check the health and operational status of a module. The status indicator displays vary for each module.

For more information on status indicators, see Appendix A, [Troubleshoot Your Module on page 115](#).

## Use CIP Sync Time with I/O Modules

The following FLEX 5000 analog I/O modules use CIP Sync for timestamps:

- 5094-IF8, 5094-IF8XT
- 5094-IY8, 5094-IY8XT

CIP Sync is a CIP implementation of the IEEE 1588 PTP (Precision Time Protocol). CIP Sync provides accurate real-time (Real-World Time) or Universal Coordinated Time (UTC) synchronization of controllers and devices that are connected over CIP networks. This technology supports highly distributed applications that require timestamping, sequence of events recording, distributed motion control, and increased control coordination.

The 5094-IF8 and 5094-IY8 modules are CIP Sync slave-only devices. There must be another module on the network that functions as a master clock. For more information on how to use CIP Sync technology, see the Integrated Architecture® and CIP Sync Configuration Application Technique, publication [IA-AT003](#).

I/O modules can be used to capture timestamps. The advantage is that CIP Sync is system-wide, so timestamp values are consistent across all modules in the system.

## Alarm Latching

When enabled, Alarm Latching lets you latch a module alarm in the set position once the alarm is triggered. The alarm remains set even if the condition causing it to occur disappears, until the alarm is unlatched.

Alarm latching is available on a per channel basis. You can latch the following alarms:

- Input modules - Process and Rate alarms
- Output modules - Clamp and Rate alarms

For more information on latching alarms on FLEX 5000 analog I/O modules, see the module-specific chapters and Chapter 6, [Configure the Module on page 81](#).

## Enable Latching

You can enable alarm latching in the following ways:

- Module Properties dialog box - To see where to latch alarms, see the following:
  - Input modules - *Alarms* category
  - Output modules - *Limits* category

For more information on how to use the Module Properties dialog box, see Chapter 6, [Configure the Module on page 81](#).

- Module tags - The alarm type determines which tag to change.

For more information on module tags and how to use them, see Appendix B, [Module Tag Definitions on page 127](#).

## Unlatch Alarms

---

**IMPORTANT** Before you unlatch an alarm, make sure the condition that triggered the alarm no longer exists

---

Once an alarm is latched, you must manually unlatch it. You can use the module tags to unlatch an alarm. The alarm type determines which module tag to change.

For example, to unlatch a Low Low alarm on a FLEX 5000 analog input module, you set the Chxx.LLAlarmUnlatch output tag to 1.

For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Scaling

When you scale a channel, you select two points that represent signal units, that is, a Low Signal and a High Signal. You also select two points that represent engineering units, that is, Low Engineering and High Engineering.

The Low Signal point equates to the Low Engineering point and the High Signal point matches the High Engineering point.

---

**IMPORTANT** In choosing two points for the low and high value of your application, you do not limit the range of the module. The module range remains constant regardless of how you scale it.

---

Scaling lets you configure the module to return data to the controller in signal units or in engineering units (listed as Percent of Full Scale in the Logix Designer application).

For example, if you use the 5094-IF8 module in Current mode with an input range of 4...20 mA, consider the following:

- To receive values in signal units, configure the module as follows:
  - Low Signal = 4 mA
  - High Signal = 20 mA
  - Low Engineering = 4 EU
  - High Engineering = 20 EU

- To receive values in Percent of Full Scale, configure the module as follows:
  - Low Signal = 4mA
  - High Signal = 20 mA
  - Low Engineering = 0%
  - High Engineering = 100%

The returned value is indicated in the I.Chxx.Data tag.

The following table shows values that can appear when using Percent of Full Scale.

**Table 5 - Current Values Represented in Engineering Units**

Current	Engineering Units Value	Value in I.Chxx.Data Tag
0.0 mA	-25.00%	-25.00
3.0 mA	-6.00%	-6.00
4.0 mA	0.0%	0.00
12.0 mA	50.0%	50.0
20.0 mA	100.0%	100.0
23.0 mA	118.75%	118.75

You configure Scaling on the Chxx category in the Module Properties dialog box for each module. For more information on using the Module Properties dialog box, see Chapter 6, [Configure the Module on page 81](#).

## Data Offset

The FLEX 5000 analog I/O modules support offset features that let you compensate for any inaccuracy inherent to the input or output device connected to the channel. The offset value adjusts the input or output data value.

The following channel offset features are available:

- Sensor Offset - Available on FLEX 5000 analog input modules.  
For more information on using the Sensor Offset feature, see [page 45](#) and [page 66](#).
- Channel Offset - Available on FLEX 5000 analog output modules.  
For more information on using the Channel Offset feature, see [page 73](#).



## Module Accuracy

Module accuracy represents the module accuracy when its ambient temperature is the same as the temperature at which the module was calibrated.

The following specifications are related to Module Accuracy:

- [Absolute Accuracy at 25 °C \(77 °F\)](#)
- [Module Accuracy Drift with Temperature](#)

### Absolute Accuracy at 25 °C (77 °F)

This specification matches the temperature at which the module was calibrated in the factory during manufacturing. FLEX 5000 analog input modules absolute accuracy when operating in 25 °C (77 °F) conditions = 0.05%. FLEX 5000 analog output modules absolute accuracy when operating in 25 °C (77 °F) conditions = 0.10%.

The level of module accuracy remains the same, whether it is operating in Current (mA), Voltage (V), RTD, or Thermocouple mode. Only the 5094-IY8 module supports the RTD or Thermocouple modes.

### Module Accuracy Drift with Temperature

Module Accuracy Drift with Temperature represents the error that occurs if the module's ambient temperature changes for every degree change. That is, from -40...70 °C (-40...158 °F).

The module accuracy drift with temperature varies by module and the mode being used. The following table lists module accuracy drift values:

Cat. No.	Mode	Module Accuracy Drift with Temperature
5094-IF8	Voltage (V)	28 ppm/°C
	Current (mA)	47 ppm/°C
5094-IY8	Voltage (V)	28 ppm/°C
	Current (mA)	47 ppm/°C
	RTD	60 ppm/°C
	Thermocouple/millivolt	15 ppm/°C
5094-OF8	Voltage (V)	47 ppm/°C
	Current (mA)	60 ppm/°C

## Module Firmware

The FLEX 5000 analog I/O modules are manufactured with module firmware installed. If updated module firmware revisions are available in the future, you can update the firmware.

Updated firmware revisions are made available for various reasons, for example, to correct an anomaly that existed in previous module firmware revisions.

You access updated firmware files at the Rockwell Automation® Product Compatibility and Download Center (PCDC). A link to the PCDC is available at <http://www.ab.com>.

At the PCDC, you can use the module catalog number to check for firmware updates. If the catalog number is not available, no updates exist then.

---

## Current/Voltage Analog Input Module Features (5094-IF8)

Topic	Page
Module Features	36
Fault and Status Reporting	47

The 5094-IF8 input module has eight single-ended, non-isolated channels. Each channel supports connection to the following input types:

- Current
- Voltage

---

**IMPORTANT** Remember the following:

- This module also has features that apply to all FLEX 5000 analog I/O modules that are described in Chapter 2, [Common Analog I/O Module Features on page 23](#).
- You can configure the features that are described in this chapter with the Logix Designer application.

For more information on how to configure the module, see Chapter 6, [Configure the Module on page 81](#).

---

## Module Features

The 5094-IF8 module has the following features:

- [Multiple Input Ranges](#)
- [Notch Filter](#)
- [Digital Filter](#)
- [Underrange/Overrange Detection](#)
- [Process Alarms](#)
- [Rate Alarm](#)
- [Sensor Offset](#)
- [Open Wire Detection](#)
- [Over Temperature Detection](#)
- [Field Power Loss Detection](#)

### Multiple Input Ranges

The 5094-IF8 module supports multiple input ranges. The input type that you choose during module configuration determines the available input ranges. An input type is chosen on a channel-by-channel basis.

**Table 6 - Input Ranges**

Input Type	Available Input Range
Current (mA)	<ul style="list-style-type: none"><li>• 0...20 mA</li><li>• 4...20 mA</li></ul>
Voltage (V)	<ul style="list-style-type: none"><li>• -10...10V</li><li>• 0...5V</li><li>• 0...10V</li></ul>

To see where to choose an input range for the 5094-IF8 module, see [page 92](#).

## Notch Filter

The Notch Filter is a built-in feature of the Analog-to-Digital converter (ADC) that removes line noise in your application. The removal of line noise is also known as noise immunity.

The Notch Filter attenuates the input signal at the specified frequency.

Choose a Notch Filter based on what noise frequencies are present in the module operating environment and any sampling requirements that are needed for control. For example if the Notch Filter setting is 60 Hz, 60 Hz AC line noise and its overtones are filtered out.

The following Notch Filter settings are available on a 5094-IF8 module:

- 5 Hz
- 10 Hz
- 15 Hz
- 20 Hz
- 50 Hz
- 60 Hz
- 100 Hz
- 200 Hz
- 500 Hz
- 1000 Hz
- 2500 Hz
- 5000 Hz
- 10000 Hz
- 15625 Hz
- 25000 Hz
- 31250 Hz
- 62500 Hz

If you want to filter lower frequency noise, you get a slower input sample rate.

To see where to choose a notch filter for the 5094-IF8 module, see [page 92](#).

### Relationship between Notch Filter Settings and RPI Setting

There is a relationship between a Notch Filter setting and the RPI rate.

- If you want greater noise suppression at the selected Notch Filter frequency and improved resolution, you use a slower input sample rate.

For example, if you choose the 60 Hz notch filter setting and need better noise suppression and resolution, the recommended module minimum RPI is 60 ms.

- If you want a faster input sample rate at the selected Notch Filter frequency, the noise suppression and resolution is lesser.

Using the previous example, if you choose the 60 Hz notch filter setting and need faster input sampling, the recommended module minimum RPI is 20 ms.

In [Table 7](#), each Notch Filter setting has two recommended minimum module RPI values that allow the required time to collect samples from each channel. One setting provides faster sample speed and the other provides slightly better resolution at slower sample speeds.

**Table 7 - Notch Filter and Recommended Minimum Module RPI Values - Effect on Noise Rejection**

Notch Filter	Recommended Minimum Module RPI Value			
	Application That is Configured With Only One Channel Enabled		Application With All Channels Enabled and Using the Same Notch Filter Setting on All Channels	
	Faster Sampling Speed	Better Noise Rejection	Faster Sampling Speed	Better Noise Rejection
5 Hz	215 ms	635 ms	750 ms <sup>(1)</sup>	N/A
10 Hz	110 ms	320 ms	440 ms	N/A
15 Hz	65 ms	195 ms	260 ms	N/A
20 Hz	60 ms	165 ms	240 ms	660 ms
50 Hz	25 ms	70 ms	100 ms	280 ms
60 Hz (default)	20 ms	60 ms	80 ms	240 ms
100 Hz	15 ms	35 ms	60 ms	140 ms
200 Hz	10 ms	20 ms	40 ms	80 ms
500 Hz	5 ms	10 ms	20 ms	40 ms
1000 Hz	2 ms	5 ms	8 ms	20 ms
2500 Hz	1.5 ms	2.5 ms	6 ms	10 ms
5000 Hz	1 ms	2 ms	4 ms	8 ms
10000 Hz	0.8 ms	1 ms	3.2 ms	4 ms
15625 Hz	0.8 ms	0.9 ms	3.2 ms	3.5 ms
25000 Hz	0.8 ms	0.8 ms	3.2 ms	3.2 ms
31250 Hz	0.8 ms	0.8 ms	3.2 ms	3.2 ms
62500 Hz	N/A	0.7 ms	N/A	2.8 ms

(1) If you use the 5 Hz Notch Filter setting with four or more channels, the input data cannot be refreshed at every RPI, even if the maximum RPI allowed is used. Instead, fresh data is delivered approximately every other RPI.

### Noise Rejection When Using Different Notch Filter Selections

When input channels on the same module use different Notch Filter selections, you must consider the sample time for each channel. This helps you to find the recommended RPI that provides enough time for sampling all channels.

The eight input channels on the 5094-IF8 module are grouped into two groups. Channels 00...03 are grouped, and channels 04...07 are grouped. When you determine the recommended minimum module RPI value, remember:

- The recommended minimum module RPI value when channels use different Notch Filter selections is determined by group.

The recommended minimum RPI rates for all enabled channels are added together. If any channel in the other group is enabled, the recommended minimum RPI rate for each enabled channel is increased by 0.2 ms.

- If the groups have different recommended minimum RPI values, use the higher RPI value when you configure the module.

[Table 8](#) lists the values in an application that needs a **faster sampling rate**.

**Table 8 - Example Application That Requires Faster Sampling Speed**

Channel Group	Channel	Notch Filter	Recommended Minimum Module RPI for Each Channel <sup>(1)</sup>	Recommended Minimum Module RPI	Recommended Minimum Module RPI to Use in Module Configuration
Grouped together	Ch00	50 Hz	25.2 ms	28.3 ms	80.8 ms
	Ch01	1000 Hz	2.2 ms		
	Ch02 - Disabled	N/A	N/A		
	Ch03	62500 Hz	0.9 ms		
Grouped together	Ch04	60 Hz	20.2 ms	80.8 ms	
	Ch05	60 Hz	20.2 ms		
	Ch06	60 Hz	20.2 ms		
	Ch07	60 Hz	20.2 ms		

(1) The values in this column represent the corresponding recommended minimum RPI value listed in [Table 7](#) with an additional 0.2 ms added to it because at least one channel is enabled in the other group.

[Table 9](#) lists the values in an application that needs **better noise rejection**.


**Table 9 - Example Application That Requires Better Noise Rejection**

Channel Group	Channel	Notch Filter	Recommended Minimum Module RPI for Each Channel <sup>(1)</sup>	Recommended Minimum Module RPI	Recommended Minimum Module RPI to Use in Module Configuration
Grouped together	Ch00	50 Hz	70.2 ms	76.3 ms	240.8 ms
	Ch01	1000 Hz	5.2 ms		
	Ch02 - Disabled	N/A	N/A		
	Ch03	62500 Hz	0.9 ms		
Grouped together	Ch04	60 Hz	60.2 ms	240.8 ms	
	Ch05	60 Hz	60.2 ms		
	Ch06	60 Hz	60.2 ms		
	Ch07	60 Hz	60.2 ms		

(1) The values in this column represent the corresponding recommended minimum RPI value listed in [Table 7](#) with an additional 0.2 ms added to it because at least one channel is enabled in the other group.

## Digital Filter

The Digital Filter is a first-order lag filter. It smooths input data noise transients on **each input channel**. This value specifies the time constant for a digital, first-order lag filter on the input. The input is 63% of the step change after the first time constant elapses.



The filter value is specified in units of milliseconds. A value of 0 (zero) disables the filter. The digital filter equation is as shown.

$$Y_n = Y_{n-1} + \frac{\Delta t * (X_n - Y_{n-1})}{\Delta t + TA}$$

$Y_n$  = Present Output, Filtered Peak Voltage (PV)

$Y_{n-1}$  = Previous Output, Filtered PV

$\Delta t$  = Module Channel Update Time (seconds)

$TA$  = Digital Filter time Constant (seconds)

$X_n$  = Present Input, Unfiltered PV

### IMPORTANT Remember the following:

- Digital Filter input data changes only when new input data is collected.
- If an Overrange or Underrange condition is detected before the Digital Filter input data is collected, the condition is indicated immediately. An immediate indication also applies to the Fault data for the input.

To see where to choose a digital filter for the 5094-IF8 module, see [page 92](#).



## Underrange/Overrange Detection

Underrange/Overrange Detection detects when the 5094-IF8 module is operating beyond limits set by the input range.

The module can read input signal levels outside the low and high signal values for each input range. The signal limits to which the module can read are thresholds. Only when the signal is beyond a threshold is an underrange or overrange condition that is detected and indicated.

For example, if you configure a 5094-IF8 module channel to use the  $\pm 10\text{V}$  input range, an overrange condition does not exist until the input signal exceeds 12V.

[Table 10](#) lists the input ranges of the 5094-IF8 module and the thresholds in each range before the module detects an underrange/overrange condition

**Table 10 - Input Signal Threshold Ranges**

Input Type	Range	Underrange Threshold	Overrange Threshold	Deadband Example <sup>(2)</sup>
Current (mA)	0...20 mA	< -0.07 mA	> 23.00 mA	0.07 mA
	4...20 mA	< 3 mA <sup>(1)</sup>		
Voltage (V)	$\pm 10.00\text{V}$	< -12.00V	> 12.00V	0.04V
	0...5V	< -0.02V	> 6.00V	0.02V
	0...10V	< -0.04V	> 12.00V	0.04V

(1) Underrange is set at < 3 mA, but the *I.Chxx.Data* tag reports values as low as 0.0 mA. The condition is clamped when the signal reaches 3 mA.

(2) The module has alarm deadband values for each range. The deadband lets a condition remain set despite it disappearing. For example, if a module uses a Current input type in the 4...20 mA range and the signal value goes below 3 mA, the underrange condition is triggered. Because of the 0.07 mA deadband, the condition is not cleared until the signal value reaches 3.07 mA. For more information on Alarm Deadbands, see [page 43](#).

---

**IMPORTANT** The Disable All Alarms feature, does not disable the underrange/overrange detection feature.

The Disable All Alarms feature disables **alarms** on the module. Underrange/Overrange detection is not an alarm. It is an indicator that channel data has gone beyond the absolute maximum or minimum, respectively, for the channel range.

To disable the Underrange/Overrange detection feature, you must disable the channel.

---

Underrange/overrange conditions are indicated when the following tags change to 1:

- *I.Chxx.Underrange*
- *I.Chxx.Overrange*

For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Process Alarms

Process alarms alert you when the module has exceeded configured high or low limits for **each channel**. The following are the user-configurable, alarm trigger points:

- High high
- High
- Low
- Low low

To use the Process Alarms, you must complete the following tasks:

- Enable the alarms
- Configure the trigger points

### *Enable Process Alarms*

When the module tags are created, the Process Alarm tags are disabled by default.

To see where to enable Process Alarms for the 5094-IF8 module, see [page 92](#).

### *Configure Alarm Trigger Points*

You must configure the Process Alarm with a trigger point. That is, set values in Engineering Units that, once the signal reaches the value, the alarm is triggered.

Process Alarm trigger points are related to the Scaling parameters that you configure for the channel. The Engineering Units that are established in Scaling determine the Process Alarm trigger points. That is, the available trigger point values can be in signal units or engineering units.

For example, consider a channel that uses the Current (mA) input type, the 4 mA...20 mA input range, and scales the High and Low Engineering values of 100 and 0, respectively. The available Process Alarm values range from 0...100.

In this case, if the High Limit alarm is set to 50 EU, when the input signal reaches 12 mA, the High Limit alarm is set. The alarm is set because Scaling was configured for Percentage of Full Scale and a signal value of 12 mA is 50% of the full scale of engineering units.

To see where to set the Process Alarm trigger points for the 5094-IF8 module, see [page 92](#).

### *Latch Alarms*

Check Latch Process Alarms on the *Alarms* category to latch the process alarms. To see where to see where to latch Process Alarms on the 5094-IF8 module, see [page 92](#).

### *Unlatch Alarms*

---

**IMPORTANT** Before you unlatch an alarm, make sure the condition that triggered the alarm no longer exists.

---

Once an alarm is latched, you must manually unlatch it. To unlatch an alarm, change the output tag for that alarm.

For example, change the *O.Chxx.LAlarmUnlatch* tag for the low alarm that you want to unlatch from 0 to 1.

---

**IMPORTANT** After an alarm is unlatched, change the tag back from 1 to 0. You must change the tag from 0 to 1 to unlatch the alarm each time it is triggered.

If you do not change the tag back to 0 and the alarm is latched again in the future, the alarm remains latched despite the Unlatch tag value being 1.

---


For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

### *Alarm Deadband*

You can configure an alarm deadband to work with these alarms. The deadband lets the process alarm status bit remain set, despite the alarm condition disappearing, as long as the input data remains within the deadband of the process alarm.

The following graphic shows input data that sets each of the four alarms at some point during module operation. In this example, latching is disabled; therefore, each alarm turns Off when the condition that caused it to set ceases to exist.

Figure 3 - Alarm Deadband Alarm Settings



43153

To see where to set the Alarm Deadband on the 5094-IF8 module, see [page 92](#).

## Rate Alarm

The Rate Alarm defines the maximum rate of change between input samples in Engineering Units per second. If the Rate Alarm Limit is exceeded, the *I.Chxx.RateAlarm* tag set to 1.

You can enable Rate Alarm latching. To see where to enable the Rate Alarm latching on the 5094-IF8 module, see [page 92](#).

Once the Rate Alarm is latched, you must change the *O.Chxx.RateAlarmUnlatch* tag to 1.

You can unlatch the alarm at any point in the system operation. If you change the unlatch tag to 1 and the triggering condition remains, the alarm is immediately latched again.

We suggest that you unlatch the Rate Alarm only after the rate of change between input samples has returned below the Rate Alarm Limit value.

## Sensor Offset

The Sensor Offset compensates for any known error on the sensor or channel to which the sensor is connected. The value is set in signal units and is added to the data value.

For example, consider an application that uses the Current (mA) input type with the 4...20 mA range and scaling at 0...100%. If a sensor has an error and the channel consistently reports current signal values by 0.2 mA lower than the actual value, you must set Sensor Offset to 1.25%.

You must use the *O.Chxx.SensorOffset* tag to set the Sensor Offset. In the example above, the *O.Chxx.SensorOffset* tag = 1.25.

For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Open Wire Detection

Open Wire Detection detects when a wire is disconnected from the channel. You must enable Open Wire Detection in the module configuration.

To see where to enable Open Wire Detection on the 5094-IF8 module, see [page 92](#).

[Table 11](#) describes the results of an Open Wire condition occurring when the module is operating in each mode.

**Table 11 - Open Wire Conditions**

Mode	Cause of Detection	Resulting Module Behavior
Current (mA)	The input signal for a channel is below 100 $\mu$ A. <b>IMPORTANT:</b> This feature is available in Current mode only when the channel uses the 4...20 mA input range.	<ul style="list-style-type: none"> <li>Input data for the channel changes to a specific scaled value corresponding to the Underrange value for the channel's Input Range.</li> <li>The <i>I.Chxx.OpenWire</i> tag changes to 1.</li> <li>A fault occurs and the <i>I.Chxx.Fault</i> tag is set to 1.</li> </ul>
Voltage	The input signal value reaches full scale of the input range used.	<ul style="list-style-type: none"> <li>Input data for the channel changes to a specific scaled value corresponding to the Overrange value for the channel's Input Range.</li> <li>The <i>I.Chxx.OpenWire</i> tag changes to 1.</li> <li>A fault occurs and the <i>I.Chxx.Fault</i> tag is set to 1.</li> </ul>

---

**IMPORTANT** The Disable All Alarms feature, does not disable the Open Wire Detection feature. The Disable All Alarms feature disables all alarms on the module.

The Open Wire Detection feature is not an alarm. It is an indicator that a wire has been disconnected from the channel but does not trigger an alarm.

To disable the Open Wire Detection feature, you must clear the Open Wire Detection checkbox in the module configuration.

---

## Over Temperature Detection

The Over Temperature Detection feature indicates that the temperature of the conditions within which the module is operating are higher than the module operating limits.

When an Over Temperature condition exists, the I.Chxx.OverTemperature tag is set to 1.

## Field Power Loss Detection

The Field Power Loss Detection feature monitors for the loss of power at an input module channel. When field power to the module is lost, a channel-level fault is sent to the controller to identify the exact channel faulted.

Field Power Loss Detection has a corresponding tag that can be examined in the user program if a fault occurs. For information on modules, see Appendix B, [Module Tag Definitions on page 127](#).

To see where to enable or disable field power detection, see [page 91](#).

## Fault and Status Reporting

The 5094-IF8 module sends fault and status data with channel data to the owner-controller and listening controllers. The data is returned via module tags that you can monitor in your Logix Designer application.

With some exceptions, the 5094-IF8 module provides the fault and data status in a channel-centric format. The tag names in the following table that include **Chxx** represent channel-centric data. The **xx** represents channel number.

**Table 12 - 5094-IF8 Module - Fault and Status Data Tags**

Data Type	Tag Name	Triggering Event That Sets the Tag
Fault	ConnectionFaulted <sup>(1)</sup>	The owner-controller loses its connection to the module.
	Chxx.Fault	The channel data quality is bad.
	Chxx.OpenWire	The following conditions: <ul style="list-style-type: none"> <li>The channel uses a <b>Voltage</b> input type in any input range and the input signal value reaches full scale.</li> <li>The channel uses a <b>Current</b> input type in only the 4...20 mA input range and the input signal goes below 100 µA.</li> </ul> The input signal at the channel is below 100 µA.
	Chxx.Underrange	The channel data is beneath the absolute minimum for this channel.
	Chxx.Overrange	The channel data is above the absolute maximum for this channel.
	Chxx.OverTemperature	The module is at a higher temperature than its rated operating limits.
Status	RunMode <sup>(1)</sup>	The module is in Run Mode.
	DiagnosticActive	Indicates if any diagnostics are active or if the prognostics threshold is reached.
	DiagnosticSequenceCount	A counter that increments when a diagnostic condition occurs or goes away. The counter is a rolling counter that skips 0 on rollovers.
	Chxx.Uncertain	The channel data can be imperfect but it is not known to what degree of inaccuracy.
	Chxx.FieldPowerOff	Field power is not present on the channel.
	Chxx.NotANumber	The most recently received data value was not a number.
	Chxx.LLAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is less than the <i>C.Chxx.LLAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.LLAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.LAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is less than the <i>C.Chxx.LAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.LAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.HAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is greater than the <i>C.Chxx.HAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.HAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.HHAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is greater than the <i>C.Chxx.HHAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.HHAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.RateAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The absolute change between consecutive channel samples exceeds the <i>C.Chxx.RateAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.RateAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.Data	The channel data in scaled Engineering Units.
	Chxx.RollingTimestamp	A continuously running, 15-bit timer that counts in milliseconds and is not related to CIP Sync. Whenever a module scans its channels, it records the value of RollingTimestamp then. The controller program uses the last two rolling timestamp values to calculate the amount of time between the samples.

(1) This tag provides module-wide data and affects all channels simultaneously.

## **Notes:**



---

## Current/Voltage/Temperature-sensing Analog Input Module Features (5094-IY8)

Topic	Page
Module Features	50
Fault and Status Reporting	69

The 5094-IY8 input module has eight single-ended and differential, non-isolated channels. Each channel supports connection to the following input types:

- Current
- Voltage
- RTD
- Thermocouple

Differential inputs have a greater resistance to the effects of electromagnetic noise and provide improved flexibility regarding cable length when wiring your module.

---

**IMPORTANT** Remember the following:

- This module also has features that apply to all FLEX 5000 analog I/O modules that are described in Chapter 2, [Common Analog I/O Module Features on page 23](#).
  - You can configure the features that are described in this chapter with the Logix Designer application.  
For more information on how to configure the module, see Chapter 6, [Configure the Module on page 81](#).
-

## Module Features

The 5094-IY8 module has the following features:

- [Multiple Input Ranges](#)
- [Notch Filter](#)
- [Digital Filter](#)
- [Underrange/Overrange Detection](#)
- [Process Alarms](#)
- [Rate Alarm](#)
- [Sensor Types](#)
- [Sensor Offset](#)
- [10 Ohm Copper Offset](#)
- [Input SSV Switch Enable](#)
- [Open Wire Detection](#)
- [Temperature Units](#)
- [Over Temperature Detection](#)
- [Field Power Loss Detection](#)
- [Cold Junction Compensation](#)

## Multiple Input Ranges

The 5094-IY8 module offers multiple input ranges. The input type that you choose during module configuration determines the available input ranges.

For the RTD input type, the sensor type that you choose determines the available input ranges. The Logix Designer automatically sets the Input Range to the valid setting after you select a sensor type.

[Table 13](#) describes the available module input ranges.

**Table 13 - 5094-IY8 Module - Channel Input Ranges**

Input Type	Sensor Type	Available Input Ranges
Current (mA)	N/A	One of the following: <ul style="list-style-type: none"> <li>0...20 mA</li> <li>4...20 mA</li> </ul>
Voltage (V)	N/A	One of the following: <ul style="list-style-type: none"> <li>-10...10V</li> <li>0...5V</li> <li>0...10V</li> </ul>
RTD	Ohm	One of the following: <ul style="list-style-type: none"> <li>1...500 <math>\Omega</math></li> <li>2...1000 <math>\Omega</math></li> <li>4...2000 <math>\Omega</math></li> <li>8...4000 <math>\Omega</math></li> </ul>
	100 $\Omega$ PT 385	1...500 $\Omega$
	200 $\Omega$ PT 385	2...1000 $\Omega$
	500 $\Omega$ PT 385	4...2000 $\Omega$
	1000 $\Omega$ PT 385	8...4000 $\Omega$
	100 $\Omega$ PT 3916	1...500 $\Omega$
	200 $\Omega$ PT 3916	2...1000 $\Omega$
	500 $\Omega$ PT 3916	4...2000 $\Omega$
	1000 $\Omega$ PT 3916	8...4000 $\Omega$
	10 $\Omega$ CU 427	1...500 $\Omega$
	120 $\Omega$ NI 672	1...500 $\Omega$
	100 $\Omega$ NI 618	1...500 $\Omega$
	120 $\Omega$ NI 618	1...500 $\Omega$
	200 $\Omega$ NI 618	2...1000 $\Omega$
	500 $\Omega$ NI 618	4...2000 $\Omega$
Thermocouple	mV or any Thermocouple type	-100...100 mV

To see where to choose an input range for the 5094-IY8 module, see [page 95](#).

## Notch Filter

The Notch Filter is a built-in feature of the Analog-to-Digital converter (ADC) that removes line noise in your application. The removal of line noise is also known as noise immunity.

The Notch Filter attenuates the input signal at the specified frequency.

Choose a Notch Filter based on what noise frequencies are present in the module operating environment and any sampling requirements that are needed for control. For example if the Notch Filter setting is 60 Hz, 60 Hz AC line noise and its overtones are filtered out.

The following Notch Filter settings are available on a 5094-IY8 module:

- 5 Hz
- 10 Hz
- 15 Hz
- 20 Hz
- 50 Hz
- 60 Hz
- 100 Hz
- 200 Hz
- 500 Hz
- 1000 Hz
- 2500 Hz
- 5000 Hz
- 10000 Hz
- 15625 Hz
- 25000 Hz
- 31250 Hz
- 62500 Hz

If you want to filter lower frequency noise, you get a slower input sample rate.

To see where to choose a notch filter for the 5094-IY8 module, see [page 95](#).

*Relationship between Notch Filter Settings and RPI Setting*

There is a relationship between a Notch Filter setting and the RPI rate.

- If you want greater noise suppression at the selected Notch Filter frequency and improved resolution, you use a slower input sample rate.

For example, if you choose the 60 Hz notch filter setting and need better noise suppression and resolution, the recommended module minimum RPI is 60 ms.

- If you want a faster input sample rate at the selected Notch Filter frequency, the noise suppression and resolution is lesser.

Using the previous example, if you choose the 60 Hz notch filter setting and need faster input sampling, the recommended module minimum RPI is 20 ms.

In [Table 14](#), each Notch Filter setting has two recommended minimum module RPI values that allow the required time to collect samples from each channel. One setting provides faster sample speed and the other provides slightly better resolution at slower sample speeds.

**Table 14 - Notch Filter and Recommended Minimum Module RPI Values - Effect on Noise Rejection**

Notch Filter	Recommended Minimum Module RPI Value			
	Application That is Configured With Only One Channel Enabled		Application With All Channels Enabled and Using the Same Notch Filter Setting on All Channels	
	Faster Sampling Speed	Better Noise Rejection	Faster Sampling Speed	Better Noise Rejection
5 Hz	215 ms	635 ms	750 ms <sup>(1)</sup>	N/A
10 Hz	110 ms	320 ms	440 ms	N/A
15 Hz	65 ms	195 ms	260 ms	N/A
20 Hz	60 ms	165 ms	240 ms	660 ms
50 Hz	25 ms	70 ms	100 ms	280 ms
60 Hz (default)	20 ms	60 ms	80 ms	240 ms
100 Hz	15 ms	35 ms	60 ms	140 ms
200 Hz	10 ms	20 ms	40 ms	80 ms
500 Hz	5 ms	10 ms	20 ms	40 ms
1000 Hz	2 ms	5 ms	8 ms	20 ms
2500 Hz	1.5 ms	2.5 ms	6 ms	10 ms
5000 Hz	1 ms	2 ms	4 ms	8 ms
10000 Hz	0.8 ms	1 ms	3.2 ms	4 ms
15625 Hz	0.8 ms	0.9 ms	3.2 ms	3.5 ms
25000 Hz	0.8 ms	0.8 ms	3.2 ms	3.2 ms
31250 Hz	0.8 ms	0.8 ms	3.2 ms	3.2 ms
62500 Hz	N/A	0.7 ms	N/A	2.8 ms

(1) If you use the 5 Hz Notch Filter setting with four channels, the input data cannot be refreshed at every RPI, even if the maximum RPI allowed is used. Instead, fresh data is delivered approximately every other RPI.

### Noise Rejection When Using Different Notch Filter Selections

When input channels on the same module use different Notch Filter selections, you must consider the sample time for each channel. This helps you to find the recommended RPI that provides enough time for sampling all channels.

The eight input channels on the 5094-IY8 module are grouped into two groups. Channels 00...03 are grouped, and channels 04...07 are grouped. When you determine the recommended minimum module RPI value, remember:

- The recommended minimum module RPI value when channels use different Notch Filter selections is determined by group.

The recommended minimum RPI rates for all enabled channels are added together. If any channel in the other group is enabled, the recommended minimum RPI rate for each enabled channel is increased by 0.2 ms.

- If the groups have different recommended minimum RPI values, use the higher RPI value when you configure the module.

[Table 15](#) lists the values in an application that needs a **faster sampling rate**.

**Table 15 - Example Application That Requires Faster Sampling Speed**

Channel Group	Channel	Notch Filter	Recommended Minimum Module RPI for Each Channel <sup>(1)</sup>	Recommended Minimum Module RPI	Recommended Minimum Module RPI to Use in Module Configuration
Grouped together	Ch00	50 Hz	25.2 ms	28.3 ms	80.8 ms
	Ch01	1000 Hz	2.2 ms		
	Ch02 - Disabled	N/A	N/A		
	Ch03	62500 Hz	0.9 ms		
Grouped together	Ch04	60 Hz	20.2 ms	80.8 ms	
	Ch05	60 Hz	20.2 ms		
	Ch06	60 Hz	20.2 ms		
	Ch07	60 Hz	20.2 ms		

(1) The values in this column represent the corresponding recommended minimum RPI value listed in [Table 14](#) with an additional 0.2 ms added to it because at least one channel is enabled in the other group.

[Table 16](#) lists the values in an application that needs **better noise rejection**.


**Table 16 - Example Application That Requires Better Noise Rejection**

Channel Group	Channel	Notch Filter	Recommended Minimum Module RPI for Each Channel <sup>(1)</sup>	Recommended Minimum Module RPI	Recommended Minimum Module RPI to Use in Module Configuration
Grouped together	Ch00	50 Hz	70.2 ms	76.3 ms	240.8 ms
	Ch01	1000 Hz	5.2 ms		
	Ch02 - Disabled	N/A	N/A		
	Ch03	62500 Hz	0.9 ms		
Grouped together	Ch04	60 Hz	60.2 ms	240.8 ms	
	Ch05	60 Hz	60.2 ms		
	Ch06	60 Hz	60.2 ms		
	Ch07	60 Hz	60.2 ms		

(1) The values in this column represent the corresponding recommended minimum RPI value listed in [Table 14](#) with an additional 0.2 ms added to it because at least one channel is enabled in the other group.

## Digital Filter

The Digital Filter is a first-order lag filter. It smooths input data noise transients on **each input channel**. This value specifies the time constant for a digital, first-order lag filter on the input. The input is 63% of the step change after the first time constant elapses.



The filter value is specified in units of milliseconds. A value of 0 (zero) disables the filter. The digital filter equation is as shown.

$$Y_n = Y_{n-1} + \frac{\Delta t * (X_n - Y_{n-1})}{\Delta t + TA}$$

$Y_n$  = Present Output, Filtered Peak Voltage (PV)

$Y_{n-1}$  = Previous Output, Filtered PV

$\Delta t$  = Module Channel Update Time (seconds)

TA = Digital Filter time Constant (seconds)

$X_n$  = Present Input, Unfiltered PV

### IMPORTANT Remember the following:

- Digital Filter input data changes only when new input data is collected.
- If an Overrange or Underrange condition is detected before the Digital Filter input data is collected, the condition is indicated immediately. An immediate indication also applies to the Fault data for the input.

To see where to choose a digital filter for the 5094-IY8 module, see [page 95](#).

## Underrange/Ovrange Detection

Underrange/Ovrange Detection detects when the 5094-IY8 module is operating beyond limits set by the input range.

The module can read input signal levels outside the low and high signal values for each input range. The signal limits to which the module can read are thresholds. Only when the signal is beyond a threshold is an underrange or overrange condition that is detected and indicated.

For example, if you configure a 5094-IY8 module channel to use the  $\pm 10\text{V}$  input range, an overrange condition does not exist until the input signal exceeds 12V.

[Table 17](#) lists the input ranges of the 5094-IY8 module and the thresholds in each range before the module detects an underrange/overrange condition.

**Table 17 - Input Type Underrange/Ovrange Thresholds**

Input Type	Range - Current and Voltage Input Type  Sensor Type - RTD and Thermocouple Input Type	Underrange Threshold	Ovrange Threshold	Deadband Example <sup>(2)</sup>
Current (mA)	0...20 mA	< -0.07 mA	> 23.00 mA	0.07 mA
	4...20 mA	< 3 mA <sup>(1)</sup>		
Voltage (V)	$\pm 10.00\text{V}$	< -12.00V	> 12.00V	0.04V
	0...5V	< -0.02V	> 6.00V	0.02V
	0...10V	< -0.04V	> 12.00V	0.04V
RTD	Pt 385	< -200 °C < -328 °F < 73 °K < 132 °R	> 870 °C > 1598 °F > 1143 °K > 2058 °R	N/A
	Pt3916	< -200 °C < -328 °F < 73 °K < 132 °R	> 630 °C > 1166 °F > 903 °K > 1626 °R	
	Cu427	< -200 °C < -328 °F < 73 °K < 132 °R	> 260 °C > 500 °F > 533 °K > 960 °R	
	Ni672	< -80 °C < -112 °F < 193 °K < 348 °R	> 320 °C > 608 °F > 593 °K > 1068 °R	
	Ni618	< -60 °C < -76 °F < 213 °K < 384 °R	> 250 °C > 482 °F > 523 °K > 942 °R	



**Table 17 - Input Type Underrange/Ovrange Thresholds**

Input Type	Range - Current and Voltage Input Type  Sensor Type - RTD and Thermocouple Input Type	Underrange Threshold	Ovrange Threshold	Deadband Example <sup>(2)</sup>
Thermocouple	B	< 21 °C < 68 °F < 293 °K < 528 °R	> 1820 °C > 3308 °F > 2093 °K > 3768 °R	N/A
	C	< 0.00 °C < 32 °F < 273 °K < 492 °R	> 2320 °C > 4208 °F > 2593 °K > 4668 °R	
	E	< -270 °C < -454 °F < 3 °K < 6 °R	> 1000 °C > 1832 °F > 1273 °K > 2292 °R	
	J	< -210 °C < -346 °F < 63 °K < 114 °R	> 1200 °C > 2192 °F > 1473 °K > 2652 °R	
	K	< -270 °C < -454 °F < 3 °K < 6 °R	> 1372 °C > 2502 °F > 1645 °K > 2961 °R	
	N	< -270 °C < -454 °F < 3 °K < 6 °R	> 1300 °C > 2372 °F > 1573 °K > 2832 °R	
	R	< -50 °C < -58 °F < 223 °K < 402 °R	> 1768 °C > 3215 °F > 2041 °K > 3674 °R	

Table 17 - Input Type Underrange/Overrange Thresholds

Input Type	Range - Current and Voltage Input Type  Sensor Type - RTD and Thermocouple Input Type	Underrange Threshold	Overrange Threshold	Deadband Example <sup>(2)</sup>
Thermocouple	S	< -50 °C < -58 °F < 223 °K < 402 °R	> 1768 °C > 3215 °F > 2041 °K > 3674 °R	N/A
	T	< -270 °C < -454 °F < 3 °K < 6 °R	> 400 °C > 752 °F > 673 °K > 1212 °R	
	TXK/XK(L)	< -200 °C < -328 °F < 73 °K < 132 °R	> 800 °C > 1472 °F > 1073 °K > 1932 °R	
	D	< 0.00 °C < 32 °F < 273 °K < 492 °R	> 2320 °C > 4208 °F > 2593 °K > 4668 °R	

(1) Underrange is set at < 3 mA, but the *I:Chxx.Data* tag reports values as low as 0.0 mA. The condition is clamped when the signal reaches 3 mA.

(2) The module has alarm deadband values for each range. The deadband lets a condition remain set despite it disappearing. For example, if a module uses a Current input type in the 4...20 mA range and the signal value goes below 3 mA, the underrange condition is triggered. Because of the 0.07 mA deadband, the condition is not cleared until the signal value reaches 3.07 mA. For more information on Alarm Deadbands, see [page 60](#).

**IMPORTANT**

The Disable All Alarms feature, does not disable the underrange/overrange detection feature.

The Disable All Alarms feature disables **alarms** on the module. Underrange/Overrange detection is not an alarm. It is an indicator that channel data has gone beyond the absolute maximum or minimum, respectively, for the channel range.

To disable the Underrange/Overrange detection feature, you must disable the channel.

Underrange/overrange conditions are indicated when the following tags change to 1:

- *I.Chxx.Underrange*
- *I.Chxx.Overrange*

For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Process Alarms

Process alarms alert you when the module has exceeded configured high or low limits for **each channel**. The following are the user-configurable, alarm trigger points:

- High high
- High
- Low
- Low low

To use the Process Alarms, you must complete the following tasks:

- Enable the alarms
- Configure the trigger points

### *Enable Process Alarms*

When the module tags are created, the Process Alarm tags are disabled by default.

To see where to enable Process Alarms for the 5094-IY8 module, see [page 95](#).

### *Configure Alarm Trigger Points*

You must configure the Process Alarm with a trigger point. That is, set values in Engineering Units that, once the signal reaches the value, the alarm is triggered.

Process Alarm trigger points are related to the Scaling parameters that you configure for the channel. The Engineering Units that are established in Scaling determine the Process Alarm trigger points. That is, the available trigger point values can be in signal units or engineering units.

For example, consider a channel that uses the Current (mA) input type, the 4 mA...20 mA input range, and scales the High and Low Engineering values of 100 and 0, respectively. The available Process Alarm values range from 0...100.

In this case, if the High Limit alarm is set to 50 EU, when the input signal reaches 12 mA, the High Limit alarm is set. The alarm is set because Scaling was configured for Percentage of Full Scale and a signal value of 12 mA is 50% of the full scale of engineering units.

To see where to set the Process Alarm trigger points for the 5094-IY8 module, see [page 95](#).

### *Latch Alarms*

Check Latch Process Alarms on the *Alarms* category to latch the process alarms. To see where to latch Process Alarms on the 5094-IY8 module, see [page 95](#).

### *Unlatch Alarms*

---

**IMPORTANT** Before you unlatch an alarm, make sure the condition that triggered the alarm no longer exists.

---

Once an alarm is latched, you must manually unlatch it. To unlatch an alarm, change the output tag for that alarm.

For example, change the *O.Chxx.LAlarmUnlatch* tag for the low alarm that you want to unlatch from 0 to 1.

---

**IMPORTANT** After an alarm is unlatched, change the tag back from 1 to 0. You must change the tag from 0 to 1 to unlatch the alarm each time it is triggered. If you do not change the tag back to 0 and the alarm is latched again in the future, the alarm remains latched despite the Unlatch tag value being 1.


---

For more information on how to use the module tags, see Appendix B, [Module Tag Definitions on page 127](#).

### *Alarm Deadband*

You can configure an alarm deadband to work with these alarms. The deadband lets the process alarm status bit remain set, despite the alarm condition disappearing, as long as the input data remains within the deadband of the process alarm.

The following graphic shows input data that sets each of the four alarms at some point during module operation. In this example, latching is disabled; therefore, each alarm turns Off when the condition that caused it to set ceases to exist.

**Figure 4 - Alarm Deadband Alarm Settings**

43153

To see where to set the Alarm Deadband on the 5094-IY8 module, see [page 95](#).

## Rate Alarm

The Rate Alarm defines the maximum rate of change between input samples in Engineering Units per second. If the Rate Alarm Limit is exceeded, the *I.Chxx.RateAlarm* tag set to 1.

You can enable Rate Alarm latching. To see where to enable the Rate Alarm latching on the 5094-IY8 module, see [page 95](#).

Once the Rate Alarm is latched, you must change the *O.Chxx.RateAlarmUnlatch* tag to 1.

You can unlatch the alarm at any point in the system operation. If you change the unlatch tag to 1 and the triggering condition remains, the alarm is immediately latched again.

We suggest that you unlatch the Rate Alarm only after the rate of change between input samples has returned below the Rate Alarm Limit value.

## Sensor Types

This module supports multiple sensor types with the available selections dictated by the input type configuration.

**Table 18 - Available Sensor Types on the 5094-IY8 Module**

Input Type	Available Sensor Types
RTD	100 $\Omega$ PT 385 200 $\Omega$ PT 385 500 $\Omega$ PT 385 1000 $\Omega$ PT 385 100 $\Omega$ PT 3916 200 $\Omega$ PT 3916 500 $\Omega$ PT 3916 1000 $\Omega$ PT 3916 10 $\Omega$ CU 427 120 $\Omega$ NI 672 100 $\Omega$ NI 618 120 $\Omega$ NI 618 200 $\Omega$ NI 618 500 $\Omega$ NI 618
Thermocouple	B, C, D, E, J, K, N, R, S, T, TXK/XK (L)

To see where to select a Sensor Type for a channel, see [page 95](#).

### *Sensor Type Temperature Limits*

The 5094-IY8 lets you set temperature limits when the module uses the RTD or Thermocouple input types.

The choices made during module configuration for the following parameters determine Sensor Type temperature limits:

- Input Type
- Sensor Type
- Temperature Units

To see where to set the parameters that affect temperature limits on the 5094-IY8 module, see [page 95](#).

---

**IMPORTANT** When you make the configuration choices that are listed previously, the **Scaling parameters are automatically set** on the *Chxx* category of the Module Properties dialog box. They **cannot be changed** in the software.

The Low Signal value equals the Low Engineering value. The High Signal value equals the High Engineering value.


---

For example, you can configure a channel with the following parameters:

- Input Type = RTD
- Sensor Type = 120 ohms NI 672
- Input Range = 1 ohms to 500 ohms 3-wire
- Temperature Units = Celsius

In this case, the Scaling parameters are set as follows:

- Low Signal = -80.0 °C  
Low Engineering = -80.0 °C
- High Signal = 320.0 °C  
High Engineering = 320.0 °C



[Table 19](#) lists temperature range limits on the 5094-IY8 module.

**Table 19 - Temperature Limits for RTD and Thermocouple Sensor Types**

Input Type	Sensor Type	Temperature Range Limits
RTD	100 Ohm PT 385 200 Ohm PT 385 500 Ohm PT 385 1000 Ohm PT 385	-200...870 °C -328...1598 °F 73...1143 °K 132...2058 °R
	100 Ohm PT 3916 200 Ohm PT 3916 500 Ohm PT 3916 1000 Ohm PT 3916	-200...630 °C -328...1166 °F 73...903 °K 132...1626 °R
	10 Ohm CU 427	-200...260 °C -328...500 °F 73...533 °K 132...960 °R
	120 Ohm NI 672	-80...320 °C -112...608 °F 193...593 °K 348...1068 °R
	100 Ohm NI 618 120 Ohm NI 618 200 Ohm NI 618 500 Ohm NI 618	-60...250 °C -76...482 °F 213...523 °K 384...942 °R



**Table 19 - Temperature Limits for RTD and Thermocouple Sensor Types**

Input Type	Sensor Type	Temperature Range Limits
Thermocouple (mV)	TC Type B	21...1820 °C 68...3308 °F 293...2093 °K 528...3768 °R
	TC Type C	0...2320 °C 32...4208 °F 273...2593 °K 492...4668 °R
	TC Type D	0...2320 °C 32...4208 °F 273...2593 °K 492...4668 °R
	TC Type E	-270...1000 °C -454...1832 °F 3...1273 °K 6...2292 °R
	TC Type J	-210...1200 °C -346...2192 °F 63...1473 °K 114...2652 °R
	TC Type K	-270...1372 °C -454...2502 °F 3...1645 °K 6...2961 °R
	TC Type N	-270...1300 °C -454...2372 °F 3...1573 °K 6...2832 °R
	TC Type R	-50...1768 °C -58...3215 °F 223...2041 °K 402...3674 °R
	TC Type S	-50...1768 °C -58...3215 °F 223...2041 °K 402...3674 °R
	TC Type T	-270...400 °C -454...752 °F 3...673 °K 6...1212 °R
	TC Type TXK/XK (L)	-200...800 °C -328...1472 °F 73...1073 °K 132...1932 °R

## Sensor Offset

The Sensor Offset compensates for any known error on the sensor or channel to which the sensor is connected. The value is set in signal units and is added to the data value.

For example, consider an application that uses the Current (mA) input type with the 4...20 mA range and scaling at 0...100%. If a sensor has an error and the channel consistently reports current signal values by 0.2 mA lower than the actual value, you must set Sensor Offset to 1.25%.

You must use the *O.Chxx.SensorOffset* tag to set the Sensor Offset. In the example above, the *O.Chxx.SensorOffset* tag = 1.25.

For more information on using module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## 10 Ohm Copper Offset

With 10 Ohm Copper Offset, you can compensate for a small offset error in a 10 ohm copper RTD. The channel must be connected to the 10 Ohm CU 427 Sensor Type to use this feature. The offset value is indicated in units of 0.01 Ohm.

For example, if the resistance of a copper RTD used with a channel is 9.74  $\Omega$  at 25 °C, the 10 Ohm Copper Offset lets you account for the error. You must set the 10 Ohm Copper Offset field on the Configuration tab to -0.26 or by setting the *C.Chxx.TenOhmOffset* to -26.

To see where to set the 10 Ohm Copper Offset on the 5094-IY8 module, see [page 95](#).

## Input SSV Switch Enable

The 5094-IY8 has eight non-isolated differential inputs.

Select only when the channel is connected to a 2-wire current device. This shorts the analog input channel and analog common ground to avoid the need to install an additional jumper wire on the terminal. The channel will behave as a single-ended channel and the module will source current (maximum 25 A) to the device using the specific terminals marked 24V (terminals 32, 34, 36, 38, 40, 42, 44, and 46).

Do not attempt to have the 5094-IY8 source current through Sensor Source Voltage (SSV) in any other configurations.

The 5094-IY8 does not support 3-wire current or voltage devices. We recommend to use the 5094-IF8 if you need to connect to a 3-wire device. The 5094-IY8 only supports 4-wire current or voltage devices that are using external power.

To see where to enable the Input SSV Switch on the 5094-IY8 module, see [page 95](#).

## Open Wire Detection

Open Wire Detection detects when a wire is disconnected from the channel. You must enable Open Wire Detection in the module configuration.

To see where to enable Open Wire Detection on the 5094-IY8 module, see [page 95](#).

[Table 20](#) describes the results of an Open Wire condition occurring when the module is operating in each mode.

**Table 20 - Open Wire Conditions**

Mode	Cause of Detection	Resulting Module Behavior
Current (mA)	The input signal for a channel is below 100 $\mu$ A. <b>IMPORTANT:</b> This feature is available in Current mode only when the channel uses the 4...20 mA input range.	<ul style="list-style-type: none"> <li>Input data for the channel changes to a specific scaled value corresponding to the Underrange value for the channel's Input Range.</li> <li>The <i>I:Chxx.OpenWire</i> tag changes to 1.</li> <li>A fault occurs and the <i>I:Chxx.Fault</i> tag is set to 1.</li> </ul>
Voltage	The input signal value reaches full scale of the input range used.	<ul style="list-style-type: none"> <li>Input data for the channel changes to a specific scaled value corresponding to the Overrange value for the channel's Input Range.</li> <li>The <i>I:Chxx.OpenWire</i> tag changes to 1.</li> <li>A fault occurs and the <i>I:Chxx.Fault</i> tag is set to 1.</li> </ul>
RTD	A wire is disconnected from the channel.	<ul style="list-style-type: none"> <li>Input data for the channel changes to the highest scaled temperature value associated with the selected sensor type.</li> <li>The <i>I:Chxx.OpenWire</i> tag changes to 1.</li> <li>The <i>I:Chxx.Overrange</i> tag is set to 1.</li> <li>A fault occurs and the <i>I:Chxx.Fault</i> tag is set to 1.</li> </ul>
Thermocouple with Sensor Type = Any TC Type	A wire is disconnected from the channel.	<ul style="list-style-type: none"> <li>Input data for the channel changes to the highest scaled temperature value associated with the selected sensor type.</li> <li>The <i>I:Chxx.OpenWire</i> tag changes to 1.</li> <li>The <i>I:Chxx.Overrange</i> tag is set to 1.</li> <li>A fault occurs and the <i>I:Chxx.Fault</i> tag is set to 1.</li> </ul>
Thermocouple with Sensor Type = mV	A wire is disconnected from the channel.	<ul style="list-style-type: none"> <li>Input data for the channel changes to a specific scaled value corresponding to the Overrange value for the channel's Input Range.</li> <li>The <i>I:Chxx.OpenWire</i> tag changes to 1.</li> <li>The <i>I:Chxx.Overrange</i> tag is set to 1.</li> <li>A fault occurs and the <i>I:Chxx.Fault</i> tag is set to 1.</li> </ul>

---

**IMPORTANT** The Disable All Alarms feature, does not disable the Open Wire Detection feature. The Disable All Alarms feature disables all alarms on the module.

The Open Wire Detection feature is not an alarm. It is an indicator that a wire has been disconnected from the channel but does not trigger an alarm.

To disable the Open Wire Detection feature, you must clear the Open Wire Detection checkbox in the module configuration.

---

## Temperature Units

You can use the following temperature units with your 5094-IY8 module:

- Celsius
- Kelvin
- Fahrenheit
- Rankine
- Custom

Each channel is individually configurable for its temperature units.

To see where to select the temperature units for a channel, see [page 95](#).

## Over Temperature Detection

The Over Temperature Detection feature indicates that the temperature of the conditions within which the module is operating are higher than the module operating limits.

When an Over Temperature condition exists, the I.Chxx.OverTemperature tag is set to 1.

## Field Power Loss Detection

The Field Power Loss Detection feature monitors for the loss of power at an input module channel. When field power to the module is lost, a channel-level fault is sent to the controller to identify the exact channel faulted.

Field Power Loss Detection has a corresponding tag that can be examined in the user program if a fault occurs. For information on modules, see Appendix B, [Module Tag Definitions on page 127](#).

To see where to enable or disable field power detection, see [page 94](#).

## Cold Junction Compensation

When using the 5094-IY8 module with a thermocouple input type, the channel must account for the thermoelectric effect of a junction of the thermocouple field wires and the terminal base (TB) assembly.

---

**IMPORTANT** TBs are not included with your module and are not available for purchase. TBs consists of a mounting base (MB) and removable terminal block (RTB). You must purchase MBs and RTBs separately and assemble them together. You must use a cold junction compensation (CJC) RTB when a 5094-IY8 module uses a thermocouple input type. The CJC RTBs account for the thermoelectric effect.

The following CJC RTBs are available for order:

- 5094-RTB3T, 5094-RTB3TXT
- 5094-RTB3TS, 5094-RTB3TSXT

---

The junction at which temperature is measured is the hot junction. The junction where the thermocouple wire interfaces with copper are the cold junction. The transition from thermocouple wire to copper typically happens at the RTB terminal.

The thermoelectric effect alters the input signal and must be compensated for to measure temperatures accurately. To compensate the input signal from your module accurately, you must use cold junction compensation to account for the increased voltage.

### *Cold Junction Disable Option*

You can disable cold junction compensation on your 5094-IY8 module. To see where to disable cold junction compensation, see [page 96](#).

## Fault and Status Reporting

The 5094-IY8 module sends fault and status data with channel data to the owner-controller and listening controllers. The data is returned via module tags that you can monitor in your Logix Designer application.

With some exceptions, the 5094-IY8 module provides the fault and data status in a channel-centric format. The tag names in the following table that include **Chxx** represent channel-centric data. The **xx** represents channel number.

Table 21 - 5094-IY8 Module - Fault and Status Data Tags

Data Type	Tag Name	Triggering Event That Sets Tag
Fault	ConnectionFaulted <sup>(1)</sup>	The owner-controller loses its connection to the module.
	Chxx.Fault	The channel data quality is bad.
	CJChxx.Fault	The cold junction data quality is bad.
	Chxx.OpenWire	The following conditions: <ul style="list-style-type: none"> <li>The channel uses a <b>Voltage</b> input type in any input range and the input signal value reaches full scale.</li> <li>The channel uses a <b>Current</b> input type in only the 4...20 mA input range and the input signal goes below 100 µA. The input signal at the channel is below 100 µA.</li> <li>When the channel uses <b>RTD or Thermocouple</b> input type and a wire is disconnected from the channel.</li> </ul>
	CJChxx.OpenWire	When a wire is disconnected from the cold junction.
	Chxx.Underrange	The channel data is beneath the absolute minimum for this channel.
	CJChxx.Underrange	The cold junction at the channel is beneath the absolute minimum for this channel.
	Chxx.Overrange	The channel data is above the absolute maximum for this channel.
	CJChxx.Overrange	The cold junction at the channel is above the absolute maximum for this channel.
Status	RunMode <sup>(1)</sup>	The module is in Run Mode.
	DiagnosticActive	Indicates if any diagnostics are active or if the prognostics threshold is reached.
	DiagnosticSequenceCount	A counter that increments when a diagnostic condition occurs or goes away. The counter is a rolling counter that skips 0 on rollovers.
	Chxx.Uncertain	The channel data can be imperfect but it is not known to what degree of inaccuracy.
	CJChxx.Uncertain	The cold junction data can be inaccurate but it is not known to what degree of inaccuracy.
	Chxx.OverTemperature	The module is operating at a higher temperature than its rated operating limits.
	CJChxx.Temperature	Current temperature of the cold junction.
	Chxx.FieldPowerOff	Field power is not present on the channel.
	CJChxx.FieldPowerOff	Field power is not present at the cold junction.
	Chxx.NotANumber	The most recently received data value was not a number.
	Chxx.LLAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is less than the <i>C.Chxx.LLAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.LLAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.LAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is less than the <i>C.Chxx.LAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.LAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.HAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is greater than the <i>C.Chxx.HAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.HAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.HHAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The <i>I.Chxx.Data</i> tag value is greater than the <i>C.Chxx.HHAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.HHAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.RateAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>The absolute change between consecutive channel samples exceeds the <i>C.Chxx.RateAlarmLimit</i> tag value or the alarm is latched.</li> <li>The <i>O.Chxx.RateAlarmEn</i> tag is set.</li> <li>Alarms are enabled for the channel.</li> </ul>
	Chxx.Data	The channel data in scaled Engineering Units.
	Chxx.RollingTimestamp	A continuously running, 15-bit timer that counts in milliseconds and is not related to CIP Sync. Whenever a module scans its channels, it records the value of RollingTimestamp then. The controller program uses the last two rolling timestamp values to calculate the amount of time between the samples.

(1) This tag provides module-wide data and affects all channels simultaneously.

## Current/Voltage Analog Output Module Features (5094-OF8)

Topic	Page
Module Features	72
Fault and Status Reporting	80

The 5094-OF8 output module has eight non-isolated channels. Each channel supports connection to the following output types:

- Current
- Voltage

---

**IMPORTANT** Remember the following:

- This module also has features that apply to all FLEX 5000 analog I/O modules that are described in Chapter 2, [Common Analog I/O Module Features on page 23](#).
  - You can configure the features that are described in this chapter with the Logix Designer application.  
For more information on how to configure the module, see Chapter 6, [Configure the Module on page 81](#).
-

## Module Features

The 5094-OF8 module has the following features:

- [Multiple Output Ranges](#)
- [Channel Offset](#)
- [Hold for Initialization](#)
- [Connection Fault Handling](#)
- [Output Clamping](#)
- [Clamp Alarming](#)
- [Output Ramping/Rate Limiting](#)
- [No Load Detection](#)
- [Short Circuit Protection](#)
- [Over Temperature Detection](#)
- [Field Power Loss Detection](#)

### Multiple Output Ranges

The 5094-OF8 module offers multiple output ranges. The output type that you choose during module configuration determines the available ranges.

**Table 22 - Output Ranges**

Input Type	Available Output Range
Current (mA)	<ul style="list-style-type: none"><li>• 0...20 mA</li><li>• 4...20 mA</li></ul>
Voltage (V)	<ul style="list-style-type: none"><li>• -10...10V</li><li>• 0...5V</li><li>• 0...10V</li></ul>

To see where to choose an output range for the 5094-OF8 module, see [page 98](#).



## Channel Offset

The Channel Offset feature compensates for any known error on the sensor or channel to which the sensor is connected. The value is set in signal units and is added to the output data.

For example, consider an application that uses the Current (mA) input type with the 4...20 mA range and scaling at 0...100%. If a channel used in the output range 4...20 mA has an error that results in it consistently reporting 8 mA as 7.8 mA, you must account for the error by setting the Channel Offset to 1.25.

To see where to set the channel offset for the 5094-OF8 module, see [page 98](#).

## Hold for Initialization

Hold for Initialization causes outputs to hold present state until the value commanded by the controller matches the value at the output screw terminal within 0.1% of full scale, providing a bumpless transfer.

If Hold for Initialization is selected, outputs hold if there is an occurrence of any of these three conditions:

- Initial connection is established after power-up.
- A new connection is established after a communication fault occurs.
- There is a transition to Run mode from Program state.
- The module loses SA power. In this case, the data echo value goes to 0.0.

The *I.Chxx.InHold* tag for a channel indicates that the channel is holding.

To see where to enable Hold for Initialization for the 5094-OF8 module, see [page 98](#).

## Connection Fault Handling

You can configure 5094-OF8 output module behavior when a connection fault occurs, that is, the connection between the owner-controller and the output module breaks.

You must define the following:

- [Output Behavior Immediately After a Connection Fault](#)
- [Fault State Duration After Connection Fault](#)
- [Final Fault State Value](#)

### *Output Behavior Immediately After a Connection Fault*

When the connection between an owner-controller and output module breaks, the output can behave in the following ways. The available options Fault Mode parameter is configured:

- Transition to a specific, user-defined value.
- Hold its last state.

If you configure the output to hold its last state, the output remains at that state value until the following occurs:

- The connection to the owner-controller is re-established.
- The output returns to normal operation, as defined in the module configuration.

### *Fault State Duration After Connection Fault*

If you configure the output to transition to a specific value after the connection breaks, you must define how long the output remains at the specified value before it transitions to a Final Fault State.

You can configure the output to remain at the specific value for the following times:

- Forever
- One second
- Two seconds
- Five seconds
- Ten seconds

After the Fault State Duration time expires, the output transitions to user-defined Final Fault State Value.

### *Final Fault State Value*

The Final Fault State Value defines the value to which the output goes after the Fault State Duration time expires.

### *Output State Once Connection is Re-established*

Once the connection between the owner-controller and output module is re-established, the output resumes normal operation.

To see where to set the Connection Fault Handling parameters for the 5094-OF8 module, see [page 98](#).

## **Output Clamping**

Output Clamping limits the output from the analog module to remain within a range configured by the controller, even when the controller commands an output outside that range.

Once clamp values are set, if data received from the controller exceeds those clamps, the following events occur:

- The output value transitions to the clamp limit but not to the requested value.
- The appropriate limit alarm is triggered.

For more information on limit alarms, see [Clamp Alarming on page 76](#).

For example, an application can set the high clamp on a module for 8V and the low clamp for -8V. If a controller sends a value corresponding to 9V to the module, the module applies only 8V to its screw terminals.

You can disable or latch clamping alarms on a per channel basis. The alarms are disabled by default.

---

**IMPORTANT** Clamp values are in engineering units and are **not automatically updated** when the scaling high and low engineering units are changed. Failure to update the clamp values can generate a very small output signal that could be misinterpreted as a hardware problem.

For example, a FLEX 5000 analog output module channel that uses a Current (mA) output type with Clamping enabled has the following configuration parameters:

- Scaling values:
  - High Engineering = 100.0000%
  - Low Engineering = 0.0000%
- Clamp Limits:
  - High Clamp = 100.0000%
  - Low Clamp = 0.0000%

If you change the Scaling High Engineering value to 90.0000%, the High Clamp value remains at 100.0000.

**You must change** the High Clamp value to 90.0000 to make sure that the application continues to operate as expected.

---

To see where to set the high clamp and low clamp parameters for the 5094-OF8 module, see [page 98](#).

## Clamp Alarming

Clamp Alarming works directly with Output Clamping. When a module receives a data value from the controller that exceeds clamping limits, it applies signal values to the clamping limit. In addition, a limit alarm is triggered.

The following tags indicate that a clamping alarm was triggered. That is, the tag is set to 1.

- *I.Chxx.LLimitAlarm*
- *I.Chxx.HLimitAlarm*

For more information on using module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Output Ramping/Rate Limiting

Output Ramping limits the speed at which an analog output signal can change. This prevents fast transitions in the output from damaging the devices that an output module controls. Output Ramping is also known as Rate Limiting.

[Table 23](#) describes the types of ramping that are possible.

**Table 23 - Output Ramping Types**

Ramping type	Description
Ramp in Run mode	When the module is in Run mode, ramping occurs to all new output values at the maximum ramp rate.
Ramp to Program mode	When the present output value changes to the Program value after a Program command is received from the controller.
Ramp to Fault mode	When the present output value changes to the Fault value after a communication fault occurs.

The maximum rate of change in outputs is expressed in engineering units per second (EU/s), is called the maximum ramp rate and set in the Ramp Rate field.

To see where to enable the **Ramp in Run mode** for the 5094-OF8 module, see [page 98](#).

To enable the other Output Ramping parameters, you must change module tags to 1.

- Ramp to Program Mode - *C.Chxx.RampToProg*
- Ramp to Fault Mode and Final Fault State - *C.Chxx.RampToFault*

For more information on using module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Data Echo

Data Echo automatically sends channel data values that match the analog value that was sent to the module's screw terminals then.

A FLEX 5000 analog output module returns a value that was sent to it by the owner-controller. The echoed value is indicated in the *I.Chxx.Data* and is represented in Engineering Units.

Fault and status data are also sent. This data is sent at the RPI.

## No Load Detection

No Load Detection detects when a wire is disconnected from the channel or a missing load for each output channel.

---

**IMPORTANT** This feature is available only in Current (mA) mode.

---

The output range used with a FLEX 5000 analog output module determines the current below which a load is considered missing. For example, if an operating 5094-OF8 uses the 4...20 mA output range, the presence of a no load condition is detected when the channel is connected to a load that draws less than 4 mA.

The *I.Chxx.NoLoad* tag indicates the presence of a no load condition when it is set to 1.

The No Load Detection feature is disabled by default. You must enable the feature in your Logix Designer application project. To enable No Load Detection, you must change the *C.Chxx.NoLoadEn* tag to 1.

For more information on using module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Short Circuit Protection

Short Circuit Protection prevents damage that can result from driving a current from the channel greater than the maximum current level the channel can handle.

---

**IMPORTANT** This feature is available only in Voltage (V) mode.

---

When a short circuit condition is detected, the following occurs:

- The output turns off.
- The *I.Chxx.ShortCircuit* tag is set to 1.

For more information on using module tags, see Appendix B, [Module Tag Definitions on page 127](#).

For more information on the maximum current that you can apply to an output, see the FLEX 5000 Modules Specifications Technical Data, publication [5094-TD001](#).

## Over Temperature Detection

The Over Temperature Detection feature indicates that the temperature of the conditions within which the module is operating are higher than the module operating limits.

When an Over Temperature condition exists, the I.Chxx.OverTemperature tag is set to 1.

## Field Power Loss Detection

The Field Power Loss Detection feature monitors for the loss of power at an output module channel. When field power to the module is lost, a channel-level fault is sent to the controller to identify the exact channel faulted.

Field Power Loss Detection has a corresponding tag that can be examined in the user program if a fault occurs. For information on modules, see Appendix B, [Module Tag Definitions on page 127](#).

To see where to enable or disable field power detection, see [page 97](#).

## Fault and Status Reporting

The FLEX 5000 analog output modules send fault and status data with channel data to the owner and listening controllers. The data is returned via module tags that you can monitor in your Logix Designer application.

With some exceptions, as noted in the following table, the FLEX 5000 analog output modules provides the fault and data status in a channel-centric format.

[Table 24](#) lists the FLEX 5000 analog output modules's fault and status tags available in the Logix Designer application.

**Table 24 - 5094-OF8 Module- Fault and Status Data Tags**

Data Type	Tag Name	Triggering Event That Sets Tag
Fault	ConnectionFaulted <sup>(1)</sup>	The owner-controller loses its connection to the module.
	Chxx.Fault	The channel data quality is bad.
	Chxx.NoLoad	A no load condition exists on the channel.
	Chxx.ShortCircuit	A short circuit condition exists on the channel.
	Chxx.OverTemperature	The module is at a higher temperature than its rated operating limits.
Status	RunMode <sup>(1)</sup>	The module is in Run Mode.
	DiagnosticActive	Indicates if any diagnostics are active or if the prognostics threshold is reached.
	DiagnosticSequenceCount	A counter that increments when a diagnostic condition occurs or goes away. The counter is a rolling counter that skips 0 on rollovers.
	Chxx.Uncertain	The channel data can be imperfect.
	Chxx.FieldPowerOff	Field power is not present on the channel.
	Chxx.InHold	The channel is holding until the received channel data is within 0.1% of the current channel data value.
	Chxx.NotANumber	The most recently received data value was not a number.
	Chxx.LLimitAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>Alarms are enabled on this channel.</li> <li>The channel data requested, indicated in the <i>O.Chxx.Data</i> tag, is currently less than the configured LowLimit or the alarm is latched.</li> </ul>
	Chxx.HLimitAlarm	The following conditions exist: <ul style="list-style-type: none"> <li>Alarms are enabled on this channel.</li> <li>The channel data requested, indicated in the <i>O.Chxx.Data</i> tag, is currently greater than the configured HighLimit or the alarm is latched.</li> </ul>
	Chxx.RampAlarm	The channel is currently limited to changing the output at the Maximum Ramp rate or once was and is now latched.
	Chxx.Data	The channel data in scaled Engineering Units. This data is the Output Data Echo data returned from the D/A converter.
	Chxx.RollingTimestamp	15-bit timestamp that 'rolls' from 0...32,767 ms. Compatible with existing PID instruction to calculate sample deltas automatically.

(1) This tag provides module-wide data and affects all channels simultaneously.



## Configure the Module

Topic	Page
Before You Begin	82
Create a New Module	82
Edit the Module Configuration Common Categories	87
Edit 5094-IF8 Module Configuration Categories	91
Edit 5094-IY8 Module Configuration Categories	94
Edit 5094-OF8 Module Configuration Categories	97
View the Module Tags	100

This chapter describes how to configure your FLEX 5000 analog I/O modules in a Logix Designer application project. You can use the default module configuration or edit the module configuration.

### IMPORTANT

Consider the following:

- You must use the Logix Designer application, version 31 or later, to configure the FLEX 5000 I/O modules. Version 31 or later is slightly different from previous programming software versions. For example, in some cases, instead of tabs across the top of the Module Properties dialog box, the application uses categories on the left side of the dialog box.
- This chapter does not explain the user-configurable module features that you can edit on different screens in your Logix Designer application project.

For detailed information about module features, see the following:

- Chapter 2, [Common Analog I/O Module Features](#)
- Chapter 3, [Current/Voltage Analog Input Module Features \(5094-IF8\)](#)
- Chapter 4, [Current/Voltage/Temperature-sensing Analog Input Module Features \(5094-IY8\)](#)
- Chapter 5, [Current/Voltage Analog Output Module Features \(5094-OF8\)](#)

### TIP

When a controller establishes a connection to a 5094-IY8 module, it uses a class 3 connection. We recommend that you reserve one class 3 connection on the FLEX 5000 EtherNet/IP adapter to establish a connection to the module. Otherwise, you can encounter a “Connection Request Error: Module connection limit exceeded” error.

## Before You Begin

You must complete the following tasks before you can configure the module:

1. Create a Logix Designer application project.
2. Add a FLEX 5000 EtherNet/IP adapter to the project.

For more information on how to add a FLEX 5000 EtherNet/IP adapter to a Logix Designer application project, see the EtherNet/IP Communication Modules in 5000 Series Systems User Manual, publication [ENET-UM004](#).

## Create a New Module

After you create a Logix Designer application project and add a FLEX 5000 EtherNet/IP adapter to the project, you can use the following methods to add modules to the project.

- [Discover Modules](#)
- [New Module](#)

## Discover Modules


To use the Discover Modules method with FLEX 5000 I/O modules, complete these steps.

1. Go online with your Logix Designer application.


The project must include a FLEX 5000 EtherNet/IP adapter.

2. Right-click the FLEX 5000 EtherNet/IP adapter and choose Discover Modules.


The Logix Designer application automatically detects available modules that are connected to the backplane.




3. At the Select Module Type window, click Create to add the discovered module to your project.



4. At the New Module window, configure the module properties and click OK.



5. At the warning dialog box, make sure that Inhibit module connection(s) is selected and click Yes.



6. Close the Select Module Type dialog box.

To add additional I/O modules with this method, complete one of the following:

- If you cleared the Close on Create check box when you created the first I/O module, repeat steps 3...6.
- If you did not clear the Close on Create checkbox when you created the first I/O module, repeat steps 2...6.


## New Module

To use the New Module method with FLEX 5000 I/O modules, complete these steps.


**TIP** This example shows how to add an I/O module when the Logix Designer application project is offline.

You can add new modules when the project is online, if desired. In this case, the steps are similar to the steps described in [Discover Modules on page 83](#). One exception is that, in step 1, you choose New Module instead of Discover Modules.

1. Right-click FLEX 5000 EtherNet/IP adapter and choose New Module.




## 2. Select the module and click Create.



The New Module dialog box appears. It includes a list of categories on the left side. The number and type of categories varies by module type.

## 3. You can click OK to use the default configuration as shown or edit the module configuration. The rest of this chapter describes how to edit module configuration categories.



To add additional remote I/O modules with this method, complete one of the following:

- If you cleared the Close on Create checkbox when you created the first I/O module, repeat steps 2...3.
- If you did not clear the Close on Create checkbox when you created the first I/O module, repeat steps 1...3.

## Edit the Module Configuration Common Categories

You click the category names in the New Module dialog box to view and change the configuration parameters that are associated with that module.

---

**IMPORTANT** This chapter shows how to edit configuration when you add the module to the Logix Designer application project.

If you access the module configuration after it has been added to the project, the dialog box is named Module Properties. The Module Properties dialog box shows the same categories as the New Module dialog box.

---

Some new module configuration categories apply to all FLEX 5000 analog I/O modules. Some categories are specific to the module type.

For example purposes, the figures in this section are from a 5094-IF8 module.

The following categories apply to all FLEX 5000 analog I/O modules and are described in this section:

- [General Category](#)
- [Connection Category](#)
- [Module Info Category](#)

### General Category

The General category appears first when you create a module. The parameters in this category are the same for all FLEX 5000 analog I/O modules.

You use this category to complete the following tasks:

- Name the module.
- Assign a slot number. (required)
- Describe the module.
- Access the Module Definition.

Module Definition

Module Definition parameters are available on the General tab of the Module Properties dialog box in the Logix Designer application project.

[Table 25](#) describes the parameters on the Module Definition dialog box.

**IMPORTANT**    The graphic is an example of a Module Definition dialog box. The same set of fields and options are not available on all FLEX 5000 I/O modules.




Table 25 - Module Definition Parameters

Parameter	Definition	Available Choices <sup>(1)</sup>
Series	Module hardware series	Module-specific
Revision	Module firmware revision, including major and minor revision levels	Module-specific
Electronic Keying	Software method by which you reduce the possibility of using the wrong device in a control system. For more information, see the following: <ul style="list-style-type: none"><li>• <a href="#">View the Module Tags on page 100</a></li><li>• Electronic Keying in Logix5000 Control Systems Application Technique, publication <a href="#">LOGIX-AT001</a></li></ul>	Exact Match Compatible Module Disable Keying
Connection	Determines the following for the module type you configure: <ul style="list-style-type: none"><li>• Available configuration parameters</li><li>• Data type transferred between the module and the controller</li><li>• Which tags are generated when configuration is complete</li></ul>	Data with Calibration Data Listen Only <sup>(2)</sup>
Input Data - Input modules only	All available configuration, input, and output data for the input module that is being defined.	Analog Data
Output Data - Output module only	All available configuration, input, and output data for the output module that is being defined.	Analog Data None - This choice is available only if you use the Listen Only Connection choice.

(1) The range of available choices varies by module type.

(2) Controller and module establish communication without the controller sending any configuration or output data to the module. A full input data connection is established but depends on the connection between the owner-controller and the module.



## Connection Category


The Connection category lets you complete the following tasks:

- Set the RPI rate. For more information about the RPI, see [Requested Packet Interval on page 16](#).
- Set the connection type to use on the EtherNet/IP network.

For more information on Unicast and Multicast connections, see the EtherNet/IP Communication Modules in 5000 Series Systems User Manual, publication [ENET-UM004](#).

- Inhibit the module. For more information on how to inhibit the module, see [Module Inhibiting on page 27](#).
- Configure whether a connection failure while the controller is in Run module causes a major or minor fault.


**TIP** The Module Fault area of the Connection category is useful during module troubleshooting. For more information on the Module Fault area, see [page 123](#)



## Module Info Category

The Module Info category displays module and status information about the module when the project is online. You can use this category to complete the following:

- Determine the identity of the module.
- Access module diagnostics
- Refresh the data on the screen
- Reset the module



## Edit 5094-IF8 Module Configuration Categories

In addition to the General, Connection, and Module Info categories, the following categories are available when you configure a 5094-IF8 module:


- [Channels Category](#)
- [Calibration Category](#)

**IMPORTANT** If you use the Listen Only connection type, the Channels Category and Calibration Category do not appear.

### Channels Category

The Channels category shows an overview of the configuration values for all module channels. The values for each parameter indicate how that particular channel is configured on that channel's category.


The following shows the Channels category for the 5094-IF8 module.



**IMPORTANT** You can edit the fields on the Channels category dialog box. We recommend that you change channel configuration on the specific channel categories as described in the rest of this section. Use this view to monitor configuration for all channels on the module.

*Chxx Category*


The Chxx category, where xx represents the channel number, shows the configuration options available for the channel. The Scaling and Filter options correspond to the input type and range for the channel.



If desired, you can disable the channel on this dialog box.

*Alarms Category*

Each channel on the 5094-IF8 module has an Alarms category with which it is associated. The Signal Units correspond to the input type and range for the channel.




If desired, you can disable alarms on this dialog box.

## Calibration Category

The Calibration category provides calibration information for all channels on the module. This category is blank when you add a module to the project.

Use this category during the calibration process. For more information on how to calibrate a module, see Chapter 7, [Calibrate the Module on page 101](#).



## Edit 5094-IY8 Module Configuration Categories

In addition to the General, Connection, and Module Info categories, the following categories are available when you configure a 5094-IY8 module:

- [Channels Category](#)
- [CJ Channels Category](#)
- [Calibration Category](#)


**IMPORTANT** If you use the Listen Only connection type, the Channels Category and Calibration Category do not appear.

### Channels Category

The Channels category shows an overview of the configuration values for all module channels. The values for each parameter indicate how that particular channel is configured on that channel's category.


The following shows the Channels category for the 5094-IY8 module.

**IMPORTANT** You can edit the fields on the Channels category dialog box. We recommend that you change channel configuration on the specific channel categories as described in the rest of this section. Use this view to monitor configuration for all channels on the module.



### Chxx Category


The Chxx category, where xx represents the channel number, shows the configuration options available for the channel. The Scaling and Filter options correspond to the input type and range for the channel.



If desired, you can disable the channel on this dialog box.

### Alarms Category


Each channel on the 5094-IY8 module has an Alarms category with which it is associated. The Signal Units correspond to the input type and range for the channel.



If desired, you can disable alarms on this dialog box.

## CJ Channels Category


The CJ Channels category is used when you connect a module channel to a Thermocouple input type.



## Calibration Category

The Calibration category provides calibration information for all channels on the module. This category is blank when you add a module to the project.

Use this category during the calibration process. For more information on how to calibrate a module, see Chapter 7, [Calibrate the Module on page 101](#).





## Edit 5094-OF8 Module Configuration Categories

In addition to the General, Connection, and Module Info categories, the following categories are available when you configure a 5094-OF8 module:

- [Channels Category](#)
- [Calibration Category](#)

---

**IMPORTANT** If you use the Listen Only connection type, the Channels Category and Calibration Category do not appear.

---

### Channels Category

The Channels category shows an overview of the configuration values for all module channels. The values for each parameter indicate how that particular channel is configured on that channel's category.

The following shows the Channels category for the 5094-OF8 module.


---

**IMPORTANT** You can edit the fields on the Channels category dialog box.

We recommend that you change channel configuration on the specific channel categories as described in the rest of this section.


Use this view to monitor configuration for all channels on the module.

---



### Chxx Category


The Chxx category, where xx represents the channel number, shows the configuration options available for the channel. The Scaling options correspond to the input type and range for the channel.



If desired, you can disable the channel on this dialog box.

### Limits Category


Each channel on the 5094-OF8 module has a Limits category with which it is associated. The Signal Units options correspond to the input type and range for the channel.



## Calibration Category

The Calibration category provides calibration information for all channels on the module. This category is blank when you add a module to the Logix Designer application project.

You use this category during the calibration process. For more information on how to calibrate a module, see Chapter 7, [Calibrate the Module on page 101](#).




## View the Module Tags

When you create a module, the Logix Designer application creates a set of tags that you can view in the Tag Editor. Each configured feature on your module has a distinct tag that is available for use in the controller program logic.

Complete the following steps to access the module tags.

1. In the Controller Organizer, right-click Controller Tags and choose Monitor Tags.



The Controller Tags dialog box appears with data.

2. To view module tags as shown, click the ► symbols.

A screenshot of the 'Controller Tags - Controller(controller)' dialog box. The 'Show: All Tags' filter is selected. A list of tags is displayed with columns for Name, Value, Force Mask, Style, and Data Type. A black oval highlights a group of tags under the 'Adapter1:C.Ch01' category, including 'Range', 'SensorType', 'NotchFilter', 'AlarmDisable', 'ProcessAlarmLatchEn', 'RateAlarmLatchEn', 'OpenWireEn', 'Disable', and 'TenOhmOffset'. Each of these tags has a right-pointing arrow (►) in the 'Value' column, indicating they can be expanded to show more details.

Name	Value	Force Mask	Style	Data Type
Adapter1:C	[...]	[...]	[...]	AB:5000_AB:C:0
▶ Adapter1:C.Ch00	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch01	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch01.Range	1		Decimal	SINT
▶ Adapter1:C.Ch01.SensorType	0		Decimal	SINT
▶ Adapter1:C.Ch01.NotchFilter	2		Decimal	SINT
▶ Adapter1:C.Ch01.AlarmDisable	1		Decimal	BOOL
▶ Adapter1:C.Ch01.ProcessAlarmLatchEn	0		Decimal	BOOL
▶ Adapter1:C.Ch01.RateAlarmLatchEn	0		Decimal	BOOL
▶ Adapter1:C.Ch01.OpenWireEn	0		Decimal	BOOL
▶ Adapter1:C.Ch01.Disable	0		Decimal	BOOL
▶ Adapter1:C.Ch01.TenOhmOffset	0		Decimal	INT
▶ Adapter1:C.Ch01.DigitalFilter	0		Decimal	INT
▶ Adapter1:C.Ch01.LowSignal	0.0		Float	REAL
▶ Adapter1:C.Ch01.HighSignal	5.0		Float	REAL
▶ Adapter1:C.Ch01.LowEngineering	0.0		Float	REAL
▶ Adapter1:C.Ch01.HighEngineering	5.0		Float	REAL
▶ Adapter1:C.Ch01.LLAlarmLimit	0.0		Float	REAL
▶ Adapter1:C.Ch01.LAlarmLimit	0.0		Float	REAL
▶ Adapter1:C.Ch01.HAlarmLimit	100.0		Float	REAL
▶ Adapter1:C.Ch01.HHAlarmLimit	100.0		Float	REAL
▶ Adapter1:C.Ch01.RateAlarmLimit	0.0		Float	REAL
▶ Adapter1:C.Ch01.AlarmDeadband	0.0		Float	REAL
▶ Adapter1:C.Ch02	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch03	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch04	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch05	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch06	[...]	[...]	[...]	AB:5000_AI_Channel:C:0
▶ Adapter1:C.Ch07	[...]	[...]	[...]	AB:5000_AI_Channel:C:0

For more information on module tags, see Appendix B, [Module Tag Definitions on page 127](#).

## Calibrate the Module

Topic	Page
Before You Begin	101
Difference Between Calibrating an Input Module and an Output Module	103
Calibrate the Input Modules	104
Calibrate the Output Modules	110

The FLEX 5000 analog I/O modules are calibrated during the manufacturing process. Each module's accuracy remains high throughout its lifespan. You are not required to calibrate the module.

You can calibrate on a per channel basis or in groups.

---

<b>IMPORTANT</b>	This chapter describes a few example module calibration scenarios. It does not cover how to calibrate every FLEX 5000 analog I/O module in all of the operating modes that the module supports.
------------------	---

---

### Before You Begin

Consider the following before you begin:

- [Controller State During Calibration](#)
- [Calibration Impacts Data Quality on Entire Input Module Group](#)

## Controller State During Calibration

You must add the module to your Logix Designer application project, as described in Chapter 6, [Configure the Module on page 81](#), before you can calibrate it.

The project must be online with the owner-controller to calibrate FLEX 5000 analog I/O modules. You can calibrate in the following conditions:

- The controller in Program mode--either Remote Program or Program mode.

We **recommend** that your module be in Program mode and not be actively controlling a process when you calibrate it.

- If there are no connections to the module.

## Calibration Impacts Data Quality on Entire Input Module Group

When a channel on a FLEX 5000 analog input module is being calibrated, the Notch Filter setting for that channel changes to 5 Hz. This results in the *I.Chxx.Uncertain* tag being set to 1 for that channel until calibration is completed.

Grouped inputs share an Analog-to-Digital converter. As a result when any input channel is in the calibration process, the *I.Chxx.Uncertain* tag is set to 1 for the other input channels in that group. This setting is due to the fact that the data sampling rate slows for all input channels in the group.

## Difference Between Calibrating an Input Module and an Output Module

The purpose of calibrating the FLEX 5000 analog I/O modules is the same for input and output modules, to improve the module's accuracy and repeatability. The procedures involved differs by module type:

- When you calibrate input modules, you use current, voltage, or ohms reference signals to send a signal to the module to calibrate it.
- When you calibrate output modules, you use a digital multimeter (DMM) to measure the current or voltage signal the module is sending out.

To maintain your module's factory calibration accuracy, we recommend instrumentation with the specifications listed below. A high resolution DMM can also be used to adjust a voltage/current calibrating source to its value.

Cat. No.	Channel Input Type	Recommended Instrument Specifications
5094-IF8	Current (mA)	1.00 ... 20.00 mA source $\pm 100$ nA current
	Voltage (V)	0 ... 10V source $\pm 2$ $\mu$ V voltage
5094-IY8	Current (mA)	1.00 ... 20.00 mA source $\pm 100$ nA current
	Voltage (V)	0 ... 10V source $\pm 2$ $\mu$ V voltage
	RTD	1.0 ... 487.0 $\Omega$ resistors $\pm 0.01\%$
	Thermocouple (mV)	0 ... 100 mV source $\pm 0.5$ $\mu$ V
5094-OF8	Current (mA)	DMM with resolution better than 0.15 $\mu$ A
	Voltage (V)	DMM with resolution better than 1.0 $\mu$ V

**IMPORTANT** Do not calibrate your module with an instrument that is less accurate than those recommended. The following events can result:

- Calibration appears to occur normally but the module gives inaccurate data during operation.
- A calibration fault occurs, forcing you to abort calibration.
- The *I.Chxx.CalFault* tag is set for the channel you attempted to calibrate.
- You can clear the tag by completing a valid calibration or cycling power to the module. In this case, you must recalibrate the module with an instrument as accurate as recommended.

## Calibrate the Input Modules

You apply low and high signal references to the FLEX 5000 analog input module to calibrate it. The references must match the input range the channel is using.

[Table 26](#) lists the input ranges and corresponding references used to calibrate the modules.


**Table 26 - FLEX 5000 Analog Input Module Calibration References**

Input Type	Input Range	Low Calibration Reference	High Calibration Reference
Voltage (V)	-10...10V	0.0V	10.0V
	0...10V		
	0...5V	0.0V	5.0V
Current (mA)	0...20 mA	4.0 mA	20.0 mA
	4...20 mA		
RTD (5094-IF8 only)	1...500 $\Omega$	1 $\Omega$	487 $\Omega$
	2...1000 $\Omega$		
	4...2000 $\Omega$		
	8...4000 $\Omega$		
Thermocouple (5094-IF8 only)	-100...100 mV	0.0 mV	100.0 mV

## Calibrate the 5094-IF8 Module


This example describes how to calibrate a channel on the 5094-IF8 module for use with a Voltage (V) input type. Complete the following steps:

1. Connect the voltage calibrator to the channel being calibrated.
2. Go online with the project and make sure the controller is in Program mode.
3. Confirm that the channel to be calibrated is configured for the correct Input Range.
4. On the Calibration category in the Module Properties dialog box, click Start Calibration.







- When the dialog box appears to confirm that you want to calibrate the channel, click OK.



- Select the channel to calibrate and click Next.



- When the Attach Low Reference Voltage Signals dialog box appears, set the calibrator to the low reference and apply it to the channel.
- Click Next.



The One At a Time Low Reference Results dialog box appears and indicates the status of the calibrated channel.

9. If the status is OK, click Next.

Calibration Wizard- One At a Time Low Reference Results

Press "Next" to go on to High Reference test.

Channel	Calibrate?	Calibration Range	Low Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	0.00	OK
1	<input type="checkbox"/>			
2	<input type="checkbox"/>			
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

10. When the Attach High Reference Voltage Signals dialog box appears, set the calibrator to the high reference and apply it to the module.
11. Click Next.

Calibration Wizard - Attach High Reference Voltage Signals

Attach High Reference signal to channel 0

Press "Next" to start calibration.

Channel	Calibrate?	Calibration Range	High Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	10.00	
1	<input type="checkbox"/>			
2	<input type="checkbox"/>			
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

<Back **Next>** Stop Help

The One At a Time High Reference Results dialog box appears and indicates the status of the channel after applying the low reference.

12. If the status is OK, click Next.

Calibration Wizard- One At a Time High Reference Results

Press "Next" to continue.

Channel	Calibrate?	Calibration Range	High Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	10.00	OK
1	<input type="checkbox"/>			
2	<input type="checkbox"/>			
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

13. When the Calibration Completed dialog box appears, click Finish.


## Calibrate the 5094-IY8 Module

This example describes how to calibrate a channel on the 5094-IY8 module for use with the RTD input type. The 5094-IY8 module uses the following resistors to calibrate in ohms:


- 1  $\Omega$  resistor for low reference calibration
- 487  $\Omega$  resistor for high reference calibration

Complete the following steps:


1. Connect the low reference resistor to the channel being calibrated.
2. Go online with the project and make sure the controller is in Program mode.
3. Confirm that the channel to be calibrated is configured for the correct Input Range.
4. On the Calibration category in the Module Properties dialog box, click Start Calibration.



5. When the dialog box appears to confirm that you want to calibrate the channel, click OK.



6. Select the channel to calibrate and click Next.



7. When the Attach Low Reference Ohm Sources dialog box appears, connect a 1  $\Omega$  resistor to the channel being calibrated.

## 8. Click Next.

Calibration Wizard - Attach Low Reference ohms Sources

Attach Low Reference ohms Source(s) to selected channel(s).

Channels: 2

Press "Next" to start calibration.

Channel	Calibrate?	Calibration Range	Low Reference (ohms)
0	<input type="checkbox"/>		
1	<input type="checkbox"/>		
2	<input checked="" type="checkbox"/>	1ohms to 500 ohms 3-Wire	1.00
3	<input type="checkbox"/>		
4	<input type="checkbox"/>		
5	<input type="checkbox"/>		
6	<input type="checkbox"/>		
7	<input type="checkbox"/>		

<Back **Next>** Stop Help

The One At a Time Low Reference Results dialog box appears and indicates the status of the calibrated channel.

## 9. If the status is OK, click Next.

Calibration Wizard - One At a Time Low Reference Results

Press "Next" to go on to High Reference test.

Channel	Calibrate?	Calibration Range	Low Reference (Ohms)	Status
0	<input type="checkbox"/>			
1	<input type="checkbox"/>			
2	<input checked="" type="checkbox"/>	1ohms to 500 ohms 3-Wire	1.00	OK
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

10. When the Attach High Reference Ohm Sources dialog box appears, connect a  $487\ \Omega$  resistor to the channel being calibrated.

## 11. Click Next.

Calibration Wizard - Attach High Reference Ohm Sources

Attach High Reference signal to channel 1

Press "Next" to start calibration.

Channel	Calibrate?	Calibration Range	High Reference (Ohms)	Status
0	<input type="checkbox"/>			
1	<input type="checkbox"/>			
2	<input checked="" type="checkbox"/>	1ohms to 500 ohms 3-Wire	487.00	
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

<Back **Next>** Stop Help

The One At a Time High Reference Results dialog box appears and indicates the status of the calibrated channel.

12. If the status is OK, click Next.

Calibration Wizard- One At a Time High Reference Results

Press "Next" to continue.

Channel	Calibrate?	Calibration Range	High Reference (Ohms)	Status
0	<input type="checkbox"/>			
1	<input type="checkbox"/>			
2	<input checked="" type="checkbox"/>	1ohms to 500 ohms 3-Wire	487.00	OK
3	<input type="checkbox"/>			
4	<input type="checkbox"/>			
5	<input type="checkbox"/>			
6	<input type="checkbox"/>			
7	<input type="checkbox"/>			

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

13. When the Calibration Completed dialog box appears, click Finish.

## Calibrate the Output Modules

When calibrating a FLEX 5000 analog output channel, the Logix Designer application commands the module to output specific signal levels. The signal type is determined by the output type being used by the channel.

[Table 27](#) lists the output ranges and corresponding references used to calibrate the module.

**Table 27 - FLEX 5000 Analog Output Module Calibration References**


Output Type	Output Range	Low Calibration Reference Level	High Calibration Reference Level
Voltage (V)	-10...10V	-10.0V	10.0V
	0...10V	1.0V	10.0V
	0...5V	1.0V	5.0V
Current (mA)	0...20 mA	1.0 mA	20.0 mA
	4...20 mA	5.0 mA	20.0 mA

You must measure the actual level and record the results to account for any module inaccuracies.


### Calibrate a 5094-OF8 Module

This example describes how to calibrate a channel on the 5094-OF8 module for use with a Voltage (V) output type. Complete the following steps:


1. Connect the DMM to the channel being calibrated.
2. Go online with the project and make sure the controller is in Program mode.
3. Confirm that the channel to be calibrated is configured for the correct Output Range.
4. On the Calibration category in the Module Properties dialog box, click Start Calibration.




5. When the dialog box appears to confirm that you want to calibrate the channel, click OK.



6. Select the channel to calibrate and click Next.




7. When the Output Reference Signals dialog box appears, click Next.



The Measure and Record Values dialog box appears.

8. Use a multimeter to measure the reference value of the channel.
9. In the Recorded Reference (Volts) column record the measured value and click Next.



The One At a Time Low Reference Results dialog box appears and indicates the status of the calibrated channel.

10. If the status is OK, click Next.

Calibration Wizard- One At a Time Low Reference Results

Press "Next" to go on to High Reference test.

Channel	Calibrate?	Calibration Range	Low Reference (Volts)	Recorded Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	-10.00	-10.00350	OK
1	<input type="checkbox"/>				
2	<input type="checkbox"/>				
3	<input type="checkbox"/>				
4	<input type="checkbox"/>				
5	<input type="checkbox"/>				
6	<input type="checkbox"/>				
7	<input type="checkbox"/>				

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

11. When the Output Reference Signals dialog box appears and indicates the channel to be calibrated for the high reference, click Next.

Calibration Wizard - Output Reference Signals

Press "Next" to start the selected channel producing the reference signal.

Channel: 0

Channel	Calibrate?	Calibration Range	High Reference (Volts)	Recorded Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	10.00		
1	<input type="checkbox"/>				
2	<input type="checkbox"/>				
3	<input type="checkbox"/>				
4	<input type="checkbox"/>				
5	<input type="checkbox"/>				
6	<input type="checkbox"/>				
7	<input type="checkbox"/>				

<Back **Next>** Stop Help

The Measure and Record Values dialog box appears.

12. Use a multimeter to measure the reference value of the channel.
13. In the Recorded Reference (Volts) column record the measured value and click Next.

Calibration Wizard - Measure and Record Values

Measure the output values for the selected channels using a multimeter with an accuracy of at least 4 decimal places.

Channels: 0

Enter the measured value for each channel in the "Recorded Reference" column.

Press "Next" to continue.

Channel	Calibrate?	Calibration Range	High Reference (Volts)	Recorded Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	10.00	10.0043	
1	<input type="checkbox"/>				
2	<input type="checkbox"/>				
3	<input type="checkbox"/>				
4	<input type="checkbox"/>				
5	<input type="checkbox"/>				
6	<input type="checkbox"/>				
7	<input type="checkbox"/>				

Retry **Next>** Stop Help

The One At a Time High Reference Results dialog box appears and indicates the status of the calibrated channel.



14. If the status is OK, click Next.

Calibration Wizard- One At a Time High Reference Results

Press "Next" to continue.

Channel	Calibrate?	Calibration Range	High Reference (Volts)	Recorded Reference (Volts)	Status
0	<input checked="" type="checkbox"/>	-10 V to 10 V	10.00		OK
1	<input type="checkbox"/>				
2	<input type="checkbox"/>				
3	<input type="checkbox"/>				
4	<input type="checkbox"/>				
5	<input type="checkbox"/>				
6	<input type="checkbox"/>				
7	<input type="checkbox"/>				

Retry **Next>** Stop Help

If the status is not OK, repeat the calibration process.

15. When the Calibration Completed dialog box appears, click Finish.

## **Notes:**

## Troubleshoot Your Module

Topic	Page
Module Status Indicator	116
FLEX 5000 Analog Input Modules Status Indicators	117
FLEX 5000 Analog Output Modules Status Indicators	119
Use the Logix Designer Application for Troubleshooting	121

FLEX 5000 analog I/O modules use the following status indicators:

- SA Power Indicator - This indicator operates the same for all FLEX 5000 analog I/O modules.
- Module Status Indicator - This indicator operates the same for all FLEX 5000 analog I/O modules.
- I/O Status Indicator - This indicator operates differently based on the module type.

### SA Power Indicator

[Table 28](#) describes the SA Power indicator on FLEX 5000 analog I/O modules.

**Table 28 - SA Power Indicator - FLEX 5000 Analog I/O Modules**

Indicator State	Description	Recommended Action
Off	The module is not powered.	Complete the following actions: 1. Confirm that the system is powered. 2. Confirm that the module is installed properly.
Steady green	There is SA power to the module.	None
Steady red	There is no SA power to the module.	Complete the following actions: 1. Confirm that the SA Power wiring on the terminal base is installed properly. 2. Check the following: – Confirm that there is sufficient voltage supplied to the module. – If an external power supply is used, confirm that the power supply is turned on. – If power is daisy chained from the previous terminal base, confirm that the wiring on the previous terminal base is installed properly.

## Module Status Indicator

[Table 29](#) describes the Module Status indicator on FLEX 5000 analog I/O modules.



**Table 29 - Module Status Indicator - FLEX 5000 Analog I/O Modules**

Indicator State	Description	Recommended Action
Off	The module is not powered.	Complete the following actions: 1. Confirm that the system is powered. 2. Confirm that the module is installed properly.
Steady green	The module has a connection to the owner-controller and is operating normally.	None
Flashing green	One of the following conditions exist: <ul style="list-style-type: none"> <li>The module has powered up successfully.</li> <li>The module does not have a connection to the controller. A connection can result from missing, incomplete, or incorrect module configuration.</li> <li>Connection to an output module is in the idle state.</li> </ul>	Complete the following actions: <ul style="list-style-type: none"> <li>Troubleshoot your Logix Designer application to determine what is preventing a connection from the module to the controller and correct the issue.</li> <li>Confirm that the system conditions require the controller to be in Remote Run mode or Run mode, transition the controller to one of those modes.</li> </ul>
Steady red	The module experienced a nonrecoverable fault.	Complete the following actions: 1. Cycle power to the module. 2. If the status indicator remains in the steady red state, replace the module.
Flashing red	One of the following conditions exist: <ul style="list-style-type: none"> <li>A module firmware update is in progress.</li> <li>A module firmware update attempt failed.</li> <li>The device has experienced a recoverable fault.</li> <li>A connection to the module has timed out.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>Let the firmware update progress complete.</li> <li>Reattempt a firmware update after one fails.</li> <li>Use the Logix Designer application to determine the cause of the module fault. The Connection and Module Info categories of the modules configuration indicate the fault type. To clear a recoverable fault, complete one of the following: <ul style="list-style-type: none"> <li>Cycle module power.</li> <li>Click Reset Module in the Logix Designer project via the Module Info category of the Module Properties dialog box.</li> </ul> If the fault does not clear after cycling power and clicking Reset Module, contact Rockwell Automation® Technical Support.</li> <li>Use the Logix Designer application to determine if a connection has timed out. The Connection category in the Module Properties for the module indicates the module state, including if a connection has timed out. If a connection has timed out, determine the cause and correct it. For example, a cable failure can cause a connection timeout.</li> </ul>

## FLEX 5000 Analog Input Modules Status Indicators

Figure 5 shows the status indicators on FLEX 5000 analog input modules.

Figure 5 - FLEX 5000 Analog Input Module Status Indicators



[Table 30](#) describes the I/O status indicators on FLEX 5000 analog input modules.


**Table 30 - I/O Status Indicators - FLEX 5000 Analog Input Modules**

Indicator State	Description	Recommended Action
Off	One of the following conditions exists: <ul style="list-style-type: none"> <li>The module is not powered.</li> <li>The module is powered but no connection from the controller to module has been established.</li> <li>The module is powered, but the input channel is disabled.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>None - If your application does not use the input channel.</li> <li>If you expect the module to be powered but it is not, complete the following: <ul style="list-style-type: none"> <li>Confirm that the system is powered.</li> <li>Confirm that the module is installed properly.</li> </ul> </li> <li>If the module is powered but the channel is not operating as expected, use the Logix Designer application to confirm that the channel is not disabled and has a connection to the controller. The Connection category in the Module Properties for the module indicates if the module is running or faulted. If the module is faulted, the Connection category indicates error information affecting the state of the module.</li> </ul>
Steady yellow	The input channel is operating normally.	None
Steady red	An issue has occurred that is internal to the module. The following are example issues that can cause the status indicator to be steady red: <ul style="list-style-type: none"> <li>The module has experienced a non-recoverable fault.</li> <li>A calibration fault occurred on the channel.</li> <li>The module is operating over its specified temperature. That is, an Over Temperature condition exists.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>If the indicator is in the steady red state following the initial power-up sequence and remains in that state, replace the module.</li> <li>If a calibration fault occurred, cycle power to the module. When the power-up sequence completes, the channel returns to the factory calibration setting. If the indicator remains in the steady red state after you cycle power, replace the module.</li> <li>To return the module to the specified operating temperature range, complete the following: <ul style="list-style-type: none"> <li>Check the temperature at the module installation location and lower it if necessary.</li> <li>Make sure the proper level of current is applied to the module. If not, change the current applied to an acceptable level.</li> </ul> Module specifications, for example, acceptable operating temperature or applied current levels, are available in the FLEX 5000 Modules Specifications Technical Data, publication <a href="#">5094-TD001</a>.</li> </ul>
Flashing red	One of the following conditions exists: <ul style="list-style-type: none"> <li>The input signal is overrange or underrange. The signal range is set in your Logix Designer application project.</li> <li>An Open Wire condition, that is, a wire is disconnected from the input channel.</li> <li>An over temperature warning is present on the channel.</li> <li>There is no SA power to the module.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>Check the input signal to determine if it is overrange or underrange. If so, make changes to return the input signal to within the range limits.</li> <li>Check the wiring at the input channel. If necessary, reconnect the wire.</li> <li>Locate and correct the cause of over temperature warning.</li> <li>Check the wiring at the SA terminals to make sure 24V DC power is present. If 24V DC power is not present, troubleshoot the SA power connection.</li> </ul>
Alternating yellow/red	Calibration is in progress.	Finish the calibration process in the Logix Designer application.

## FLEX 5000 Analog Output Modules Status Indicators

Figure 6 shows the status indicators on FLEX 5000 analog output modules.

**Figure 6 - FLEX 5000 Analog Output Module Status Indicators**



[Table 31](#) describes the I/O status indicators on FLEX 5000 analog output modules.

**Table 31 - I/O Status Indicators - FLEX 5000 Analog Output Modules**

Indicator State	Description	Recommended Action
Off	One of the following conditions exists: <ul style="list-style-type: none"> <li>The module is not powered.</li> <li>The module is powered but no connection from the controller to module was ever established.</li> <li>The module is powered, but the output channel is disabled.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>None - If your application does not use the output channel.</li> <li>If you expect the module to be powered but it is not, complete the following: <ul style="list-style-type: none"> <li>Confirm that the system is powered.</li> <li>Confirm that the module is installed properly.</li> </ul> </li> <li>If the module is powered but the channel is not operating as expected, use the Logix Designer application to confirm that the channel is not disabled and has a connection to the controller. The Connection category in the Module Properties for the module indicates if the module is running or faulted. If the module is faulted, the Connection category indicates error information affecting the state of the module.</li> </ul>
Steady yellow	The output channel is operating normally.	No action necessary.
Steady red	An issue has occurred that is internal to the module. The following are example issues that can cause the status indicator to be steady red: <ul style="list-style-type: none"> <li>The module has experienced a non-recoverable fault.</li> <li>A calibration fault occurred on the channel.</li> <li>The module is operating over its specified temperature. That is, an Over Temperature condition exists.</li> </ul>	Complete one of the following: <ul style="list-style-type: none"> <li>If the indicator is in the steady red state following the initial power-up sequence and remains in that state, replace the module.</li> <li>If a calibration fault occurred, cycle power to the module. When the power-up sequence completes, the channel returns to the factory calibration setting. If the indicator remains in the steady red state after you cycle power, replace the module.</li> <li>To return the module to the specified operating temperature range, complete the following: <ul style="list-style-type: none"> <li>Check the temperature at the module installation location and lower it if necessary.</li> <li>Make sure the proper level of current is applied to the module. If not, change the current applied to an acceptable level.</li> </ul> Module specifications, for example, acceptable operating temperature or applied current levels, are available in the FLEX 5000 Modules Specifications Technical Data, publication <a href="#">5094-TD001</a>.</li> </ul>
Flashing red	One of the following conditions exists: <ul style="list-style-type: none"> <li>A wire is disconnected from the output. That is, a No Load condition exists.</li> <li>The module is driving a current from the channel greater than the maximum current level the channel can handle. That is, a Short Circuit condition exists.</li> <li>An SSV Over Current condition exists.</li> <li>An over temperature warning is present on the channel.</li> <li>There is no SA power to the module.</li> </ul>	One of the following: <ul style="list-style-type: none"> <li>Check the wiring at the output channel. If necessary, reconnect the wire.</li> <li>Troubleshoot the application to make sure an acceptable level of current is driven from the channel.</li> <li>Locate and correct the cause of SSV Over Current.</li> <li>Locate and correct the cause of over temperature warning.</li> <li>Check the wiring at the SA terminals to make sure 24V DC power is present. If 24V DC power is not present, troubleshoot the SA power connection.</li> </ul>
Alternating yellow/red	Calibration is in progress.	Finish the calibration process in the Logix Designer application.



## Use the Logix Designer Application for Troubleshooting

In addition to the status indicator display on the module, the Logix Designer application indicates the presence of fault conditions.


Fault conditions are reported in the following ways:

- [Warning Signal in the I/O Configuration Tree](#)
- [Status and Fault Information in Module Properties Categories](#)
- [Logix Designer Application Tag Editor](#)

### Warning Signal in the I/O Configuration Tree

As shown in [Figure 7](#), a warning icon appears in the I/O Configuration tree when a fault occurs.

**Figure 7 - Warning Signal in Controller Organizer**



## Status and Fault Information in Module Properties Categories

The Module Properties section in the Logix Designer applications includes a series of categories. The number and types of categories varies by module type.


Each category includes options to configure the module or monitor the module's current status. The following are ways to monitor a module's state for faults:

- [Module Status on General Category](#)
- [Module Fault Descriptions on Connection Category](#)
- [Module Fault Descriptions on Module Info Category](#)

### *Module Status on General Category*

As shown in [Figure 8](#), the status of a module is indicated on the General category of the Modules Properties.


**Figure 8 - Fault Message in Status Line**



### Module Fault Descriptions on Connection Category

As shown in [Figure 9](#), a module fault description that includes an error code associated with the specific fault type is listed on the Connection category.


**Figure 9 - Fault Description with Error Code**



### Module Fault Descriptions on Module Info Category

As shown in [Figure 10](#), major and minor fault information is listed on the Module Info category.


**Figure 10 - Major and Minor Fault Information**



Module Diagnostics Dialog Box

Module Diagnostics are accessible from the Module Properties dialog box, as shown in [Figure 11](#).

Figure 11 - Module Diagnostics



## Logix Designer Application Tag Editor

[Figure 12](#) shows how fault conditions are indicated in the controller tags for the module.

**Figure 12 - Fault Indication in Controller Tags**

Name	Value	Force Mask	Style	Data Type
Adapter1.C	[...]	[...]		AB:5000_AB:C:0
Adapter1.I	[...]	[...]		AB:5000_AB:I:0
Adapter1.I.RunMode	0		Decimal	BOOL
Adapter1.I.ConnectionFaulted	1		Decimal	BOOL
Adapter1.I.DIAGNOSTICActive	0		Decimal	BOOL
Adapter1.I.DiagnosticSequenceCount	0		Decimal	SINT
Adapter1.I.Ch00	[...]	[...]		CHANNEL_AI_DIAG:I:0
Adapter1.I.Ch01	[...]	[...]		CHANNEL_AI_DIAG:I:0
Adapter1.I.Ch01.Fault	1		Decimal	BOOL
Adapter1.I.Ch01.Uncertain	0		Decimal	BOOL
Adapter1.I.Ch01.OpenWire	0		Decimal	BOOL
Adapter1.I.Ch01.OverTemperature	0		Decimal	BOOL
Adapter1.I.Ch01.FieldPowerOff	0		Decimal	BOOL
Adapter1.I.Ch01.NotANumber	0		Decimal	BOOL
Adapter1.I.Ch01.UnderRange	0		Decimal	BOOL
Adapter1.I.Ch01.Overrange	0		Decimal	BOOL
Adapter1.I.Ch01.LLAlarm	0		Decimal	BOOL
Adapter1.I.Ch01.LLAlarm	0		Decimal	BOOL
Adapter1.I.Ch01.HAlarm	0		Decimal	BOOL

## **Notes:**

## Module Tag Definitions

Topic	Page
Tag Name Conventions	128
Access the Tags	128
5094-IF8 Module Tags	129
5094-IY8 Module Tags	136
5094-OF8 Module Tags	147

Module tags are created when you add a module to the Logix Designer application project.

The set of module tags associated with a module depends on the module type and Module Definition choices made during module configuration. For example, if you use a Listen Only Connection in the Module Definition, the Logix Designer application creates only Input tags for that module.

The following types of tags are available with FLEX 5000 analog I/O modules:

- Configuration
- Input
- Output

The tables contained in this section list all of the tags available with a module. Not all tags in the list are used when that module type is added to a project. Tag use varies by module configuration.

# Tag Name Conventions

The module tag names use defined naming conventions. The conventions are as follows:

Example tag name = Adapter:1:I.Ch00.Data

- Adapter = name of the FLEX 5000 EtherNet/IP adapter in the FLEX 5000 I/O system
- 1 = slot number
- I = tag type

The possible FLEX 5000 analog I/O tag types are C (configuration), I (input), and O (output).


- Ch00 = module channel number
- Data = tag function

In this case, Data represents the input data returned to the owner-controller.

# Access the Tags

You view tags from the Tag Editor.

1. Open your Logix Designer application project.
2. Right-click Controller Tags and choose Monitor Tags.



3. Open the tags as necessary to view specific tags.

A screenshot of the 'Controller Tags - Controller(controller)' window. It displays a list of tags with columns for Name, Value, Force Mask, Style, and Data Type. The tags are organized under the 'Adapter:1:C' folder.

Name	Value	Force Mask	Style	Data Type
Adapter:1:C	{...}	{...}	{...}	AB:5000_AB:C:0
Adapter:1:C.Ch00	{...}	{...}	{...}	AB:5000_AI_Channel:C:0
Adapter:1:C.Ch01	{...}	{...}	{...}	AB:5000_AI_Channel:C:0
Adapter:1:C.Ch01.Range	1		Decimal	SINT
Adapter:1:C.Ch01.SensorType	0		Decimal	SINT
Adapter:1:C.Ch01.NotchFilter	2		Decimal	SINT
Adapter:1:C.Ch01.AlarmDisable	1		Decimal	BOOL
Adapter:1:C.Ch01.ProcessAlarmLatchEn	0		Decimal	BOOL
Adapter:1:C.Ch01.RateAlarmLatchEn	0		Decimal	BOOL
Adapter:1:C.Ch01.OpenWireEn	0		Decimal	BOOL
Adapter:1:C.Ch01.Disable	0		Decimal	BOOL
Adapter:1:C.Ch01.TenOhmOffset	0		Decimal	INT



## 5094-IF8 Module Tags

This section describes the tags associated with the 5094-IF8 module.

### Configuration Tags

[Table 32](#) describes the 5094-IF8 module configuration tags.

**Table 32 - 5094-IF8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.Range	SINT	Channel's operating range	<ul style="list-style-type: none"> <li>0 = -10...10V</li> <li>1 = 0...5V</li> <li>2 = 0...10V</li> <li>4 = 0...20 mA</li> <li>5 = 4...20 mA</li> </ul>
Chxx.NotchFilter	SINT	Notch Filter removes line noise for the channel.	<ul style="list-style-type: none"> <li>0 = 5 Hz</li> <li>1 = 10 Hz</li> <li>2 = 15 Hz</li> <li>3 = 20 Hz</li> <li>4 = 50 Hz</li> <li>5 = 60 Hz</li> <li>6 = 100 Hz</li> <li>7 = 200 Hz</li> <li>8 = 500 Hz</li> <li>9 = 1,000 Hz</li> <li>10 = 2,500 Hz</li> <li>11 = 5,000 Hz</li> <li>12 = 10,000 Hz</li> <li>13 = 15,625 Hz</li> <li>14 = 25,000 Hz</li> <li>15 = 31,250 Hz</li> <li>16 = 62,500 Hz</li> </ul>
Chxx.AlarmDisable	BOOL	<p>Disables all alarms on the channel.</p> <p><b>IMPORTANT:</b> Consider the following:</p> <ul style="list-style-type: none"> <li>When if you change this tag to 0, that is, so alarms are not disabled, you must also enable the individual alarms for them to work.</li> </ul> <p>For example, if you want to use the Low Low alarm for a channel, you must set the Chxx.AlarmDisable to 0 and set the Chxx.LLAlarmEn output tag to 1 so the alarm is enabled.</p> <p>This applies to all alarms on the module.</p> <ul style="list-style-type: none"> <li>Conversely, if you set this tag to 1, alarms are disabled regardless of the setting on the alarm enable tag for any alarm.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Alarms are enabled</li> <li>1 = Alarms are disabled (default)</li> </ul>
Chxx.ProcessAlarmLatchEn	BOOL	<p>Configures Process alarms to latch until they are explicitly unlatched.</p> <p>The Process alarms include:</p> <ul style="list-style-type: none"> <li>HighHigh alarm</li> <li>High alarm</li> <li>Low alarm</li> <li>LowLow alarm</li> </ul>	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.RateAlarmLatchEn	BOOL	Configures the Rate alarm to latch until it is explicitly unlatched.	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.OpenWireEn	BOOL	Enable the input Open Wire diagnostic	<ul style="list-style-type: none"> <li>0 = Disabled (default)</li> <li>1 = Enabled</li> </ul>
Chxx.Disable	BOOL	<p>Disables the channel.</p> <p>When a channel is disabled, the following occurs:</p> <ul style="list-style-type: none"> <li>The I/O status indicator for the channel turns off.</li> <li>The Chxx.Fault input tag is set to 1.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Channel is enabled (default)</li> <li>1 = Channel is disabled</li> </ul>

Table 32 - 5094-IF8 Module - Configuration Tags

Name	Data Type	Definition	Valid Values
Chxx.TenOhmOffset	INT	Offset used to linearize a 10 $\Omega$ copper sensor type's input	-1.00 to 1.00 $\Omega$
Chxx.DigitalFilter	INT	A non-zero value enables the filter, providing a time constant in milliseconds used in a first order lag filter to smooth the input signal.	0 = Filter is turned off. Any value greater than zero = Filter value in milliseconds
Chxx.LowSignal	REAL	One of four points used in scaling. The low signal is in terms of the inputs signal units and corresponds to the low engineering term when scaled.	Current applications - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>0 = default for 0...20 mA range</li> <li>4 = default for 4...20 mA</li> </ul> Voltage applications - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>-10 = default for -10...10V range</li> <li>0 = default for 0...5V and 0...10V ranges</li> </ul>
Chxx.HighSignal	REAL	One of four points used in scaling. The high signal is in terms of the inputs signal units and corresponds to the high engineering term when scaled.	Current applications - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>20 = default for either current input range</li> </ul> Voltage applications - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>10 = default for 0...10V and -10...10V ranges</li> <li>5 = default for 0...5V range</li> </ul>
Chxx.LowEngineering	REAL	One of four points used in scaling. The low engineering helps determine the engineering units the signal values scale into. The low engineering term corresponds to the low signal value.	Any value less than the high engineering value. <ul style="list-style-type: none"> <li>Current applications: 0.0 = default</li> <li>Voltage applications: Low signal = default. For example, with the -10...10V range, the default = -10.</li> </ul>
Chxx.HighEngineering	REAL	One of four points used in scaling. The high engineering helps determine the engineering units the signal values scale into. The high engineering term corresponds to the high signal value.	Any value greater than the low engineering value. <ul style="list-style-type: none"> <li>Current applications: 100.0 = default</li> <li>Voltage applications: High signal = default. For example, with the -10...10V range, the default = 10.</li> </ul>
Chxx.LLAlarmLimit	REAL	The Low Low alarm trigger point. Causes the Chxx.LLAlarm to trigger when the input signal moves beneath the configured trigger point. In terms of engineering units.	0.0 = default
Chxx.LAlarmLimit	REAL	The Low alarm trigger point. Causes the Chxx.LAlarm to trigger when the input signal moves beneath the configured trigger point. In terms of engineering units.	0.0 = default
Chxx.HAlarmLimit	REAL	The High alarm trigger point. Causes the Chxx.HAlarm to trigger when the input signal moves above the configured trigger point. In terms of engineering units.	100.0 = default

**Table 32 - 5094-IF8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.HHAlarmLimit	REAL	The High High alarm trigger point. Causes the ChxxHHAlarm to trigger when the input signal moves above the configured trigger point. In terms of engineering units.	100.0 = default
Chxx.RateAlarmLimit	REAL	The Rate alarm trigger point. Causes the ChxxRateAlarm to trigger when the input signal changes at a rate faster than the configured rate alarm. Configured in Engineering Units per second.	0 = Rate Alarm is not used Any value greater than zero = Trigger point
Chxx.AlarmDeadband	REAL	Allows a process alarm to remain set, despite the alarm condition disappearing, as long as the input data remains within the deadband of the process alarm.  The deadband value is subtracted from the High and High High Alarm Limits to calculate the deadband thresholds for these alarms. The deadband value is added to the Low and Low Low Alarm Limits to calculate the deadband thresholds for these alarms.	Any non-negative value 0 = default

## Input Tags

[Table 33](#) describes the 5094-IF8 module input tags.

**Table 33 - 5094-IF8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
RunMode	BOOL	Channel's operating state	<ul style="list-style-type: none"> <li>0 = Idle</li> <li>1 = Run</li> </ul>
ConnectionFaulted	BOOL	Indicates if a connection is running. The module sets this tag to 0 when connected. If the module is not connected, it changes the tag to 1.	<ul style="list-style-type: none"> <li>0 = Connection running</li> <li>1 = Connection not running</li> </ul>
DiagnosticActive	BOOL	Indicates if any diagnostics are active or if the prognostics threshold is reached.	<ul style="list-style-type: none"> <li>0 = No diagnostics active</li> <li>1 = One or more diagnostics are active or the prognostics threshold is reached</li> </ul>
DiagnosticSequenceCount	SINT	Increments for each time a distinct diagnostic condition is detected, and when a distinct diagnostic condition transitions from detected to not detected. Set to zero by product reset or power cycle. Wraps from 255 (-1) to 1 skipping zero.	-128...127 The value of 0 is skipped except during module power-up.
Chxx.Fault	BOOL	Indicates that channel data is inaccurate and <b>cannot be trusted</b> for use in the application. If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good</li> <li>1 = Bad, causing fault</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Channel is disabled</li> <li>– Open Wire (input modules) or No Load (output modules) condition</li> <li>– Underrange/Ovrrange condition</li> <li>– Short Circuit condition</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>

Table 33 - 5094-IF8 Module - Input Tags

Name	Data Type	Definition	Valid Values
Chxx.Uncertain	BOOL	Indicates that the channel data can be inaccurate but the <b>degree of inaccuracy is not known</b> . If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good data</li> <li>1 = Uncertain data</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Data signal slightly outside the channel operating range</li> <li>– The channel is slightly over temperature.</li> <li>– Invalid sensor offset value</li> <li>– Calibration fault on the channel</li> <li>– Calibration is in process on the channel</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>
Chxx.OpenWire	BOOL	The signal wire is disconnected from the channel or the RTB is removed from the module.	<ul style="list-style-type: none"> <li>0 = Open Wire condition does not exist or Open Wire Detection is disabled</li> <li>1 = Open Wire condition exists. That is, a signal wire is disconnected from the channel or the RTB is removed from the module.</li> </ul>
Chxx.OverTemperature	BOOL	Module is higher temperature than its operating limits. <ul style="list-style-type: none"> <li>If this tag is set to 1 but a fault does not exist on the channel, this tag is only an indication of operating conditions but the channel is functioning.</li> <li>If this tag is set to 1 and a fault exists on the channel, the channel is not functioning.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Module temperature is not over the operating limits</li> <li>1 = Module temperature is over the operating limits</li> </ul>
Chxx.FieldPowerOff	BOOL	Field power is not present at the channel.	<ul style="list-style-type: none"> <li>0 = Field Power is present</li> <li>1 = Field Power is not present</li> </ul>
Chxx.NotANumber	BOOL	Indicates if the last received channel data was not a number.	<ul style="list-style-type: none"> <li>0 = Last channel data received was a number</li> <li>1 = Last channel data received was not a number</li> </ul>
Chxx.Underrange	BOOL	Indicates the channel data is beneath the underrange threshold for this channel. For example, when the channel operates in the 4...20 mA input range, the underrange threshold on the channel is $\leq 3.0$ mA. If the input signal is 0 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not beneath the underrange threshold</li> <li>1 = Channel data is beneath the underrange threshold</li> </ul>
Chxx.Overrange	BOOL	Indicates the channel data is above the overrange threshold for this channel. For example, when the channel operates in the 4...20 mA output range, the overrange threshold on the channel is $\geq 23.0$ mA. If the input signal is 24 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not above the overrange threshold</li> <li>1 = Channel data is above the overrange threshold</li> </ul>
Chxx.LLAlarm	BOOL	Triggered when the input data value is less than the Low Low alarm value. If latching is enabled, this alarm remains triggered until unlatched. If latching is not enabled, the alarm clears after the input data value is greater than the Low Low limit and the Alarm Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.LAlarm	BOOL	Triggered when the input data value is less than the Low alarm value. If latching is enabled, this alarm remains triggered until unlatched. If latching is not enabled, the alarm clears after the input data value is greater than the Low limit and the Alarm Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.HAlarm	BOOL	Triggered when the input data value is greater than the High alarm value. If latching is enabled, this alarm remains triggered until unlatched. If latching is not enabled, the alarm clears after the input data value is less than the High limit and the Alarm Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>

**Table 33 - 5094-IF8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
Chxx.HHAlarm	BOOL	Triggered when the input data value is greater than the High High alarm value. If latching is enabled, this alarm remains triggered until unlatched. If latching is not enabled, the alarm clears after the input data value is less than the High High limit and the Alarm Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.RateAlarm	BOOL	Triggered when the change between consecutive channel samples divided by the period of time between when the samples were taken exceeds the Rate Alarm. If latched, this tag remains set until it is unlatched.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.CalFault	BOOL	Indicates the last attempted Calibration for this channel failed or there is no calibration data present. This tag is cleared, that is, set to 0, when power is cycled to the module.	<ul style="list-style-type: none"> <li>0 = Calibration did not fail</li> <li>1 = Calibration failed</li> </ul>
Chxx.Calibrating	BOOL	Indicates the channel is currently being calibrated.	<ul style="list-style-type: none"> <li>0 = Channel is not being calibrated</li> <li>1 = Channel is being calibrated</li> </ul>
Chxx.CalGoodLowRef	BOOL	Indicates that a valid Low Reference signal has been sampled on this channel. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a> .	<ul style="list-style-type: none"> <li>0 = Valid Low Reference signal has not been sampled on this channel</li> <li>1 = Valid Low Reference signal has been sampled on this channel</li> </ul>
Chxx.CalBadLowRef	BOOL	Indicates that an invalid Low Reference signal has been sampled on this channel. You must correct this condition to successfully calibrate the module. If calibration is aborted with an invalid Low Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a> .	<ul style="list-style-type: none"> <li>0 = Invalid Low Reference signal has not been sampled on this channel</li> <li>1 = Invalid Low Reference signal has been sampled on this channel</li> </ul>
Chxx.CalGoodHighRef	BOOL	Indicates that a valid High Reference signal has been sampled on this channel. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a> .	<ul style="list-style-type: none"> <li>0 = Valid High Reference signal has not been sampled on this channel</li> <li>1 = Valid High Reference signal has been sampled on this channel</li> </ul>
Chxx.CalBadHighRef	BOOL	Indicates that an invalid High Reference signal has been sampled on this channel. You must correct this condition to successfully calibrate the module. If calibration is aborted with an invalid High Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a> .	<ul style="list-style-type: none"> <li>0 = Invalid High Reference signal has not been sampled on this channel</li> <li>1 = Invalid High Reference signal has been sampled on this channel</li> </ul>

**Table 33 - 5094-IF8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
Chxx.CalSuccessful	BOOL	Indicates calibration on this channel is complete and the Calibrating state has been exited. This tag remains set after valid calibration as long as connection is open. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Calibration was not successful</li> <li>1 = One of the following: <ul style="list-style-type: none"> <li>Calibration was successful and calibrating state has been exited.</li> <li>Calibration data is present and applied.</li> </ul> </li> </ul>
Chxx.Data	REAL	Channel data in scaled Engineering Units.	Any positive or negative value.
Chxx.RollingTimestamp	INT	Continuously-running 15-bit timer that counts in milliseconds. Whenever an input module scans its channels, it also records the value of RollingTimestamp at that time. The user program can then use the last two RollingTimestamp values and calculate the interval between receipt of data or the time when new data has been received.	0 ... 32767

## Output Tags

[Table 34](#) describes the 5094-IF8 module output tags.

**Table 34 - 5094-IF8 Module - Output Tags**

Name	Data Type	Definition	Valid Values
Chxx.LLAlarmEn	BOOL	Enables the Low Low alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.LAlarmEn	BOOL	Enables the Low alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.HAlarmEn	BOOL	Enables the High alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.HHAlarmEn	BOOL	Enables the High High alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>

**Table 34 - 5094-IF8 Module - Output Tags**

Name	Data Type	Definition	Valid Values
Chxx.RateAlarmEn	BOOL	Enables the Rate alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.LLAlarmUnlatch	BOOL	Unlatches a latched Low Low Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Low Low Alarm remains latched</li> <li>1 = Low Low Alarm unlatches</li> </ul>
Chxx.LAlarmUnlatch	BOOL	Unlatches a latched Low Alarm at the first instance of the bit transition from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Low Alarm remains latched</li> <li>1 = Low Alarm unlatches</li> </ul>
Chxx.HAlarmUnlatch	BOOL	Unlatches a latched High Alarm at the first instance of the bit transition from 0 to 1.	<ul style="list-style-type: none"> <li>0 = High Alarm remains latched</li> <li>1 = High Alarm unlatches</li> </ul>
Chxx.HHAlarmUnlatch	BOOL	Unlatches a set High High Alarm at the first instance of the bit transition from 0 to 1.	<ul style="list-style-type: none"> <li>0 = High High Alarm remains latched</li> <li>1 = High High Alarm unlatches</li> </ul>
Chxx.RateAlarmUnlatch	BOOL	Unlatches a set Rate Alarm at the first instance of the bit transition from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Rate Alarm remains latched</li> <li>1 = Rate Alarm unlatches</li> </ul>
Chxx.Calibrate	BOOL	Initiates the Calibration process. This tag must remain set until a valid Low Reference and High Reference values are applied to the input. If the tag value transitions to 0 before calibration is finished, the process stops and calibration fails.	<ul style="list-style-type: none"> <li>0 = Calibration process is not started</li> <li>1 = Calibration process is started</li> </ul>
Chxx.CalLowRef	BOOL	Rising edge triggers the Low Calibration at the Low Reference Point for the current input range value. A valid Low Reference signal must be connected to the channel before setting this tag. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Channel data value has not passed the Low Reference Point value for the current <i>InputRange</i> tag value</li> <li>1 = Channel data value has passed the Low Reference Point value for the current <i>InputRange</i> tag value</li> </ul>
Chxx.CalHighRef	BOOL	Rising edge triggers a High Calibration at the High Reference Point for the current input range value. A valid High Reference signal must be connected to the channel before setting tag. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Channel data value has not passed the High Reference Point for the current <i>InputRange</i> tag value</li> <li>1 = Channel data value has passed the High Reference Point for the current <i>InputRange</i> tag value</li> </ul>
Chxx.SensorOffset	REAL	Compensates for any known offset error on the sensor or channel to which the sensor is connected. In terms of engineering units. The value of this tag is added to the measured value in engineering units and is used in the Chxx.Data input tag.	Any valid float value (We recommend that you use a value in the channel's operating range.) 0.0 = default

## 5094-IY8 Module Tags

This section describes the tags associated with the 5094-IY8 module.

### Configuration Tags

[Table 35](#) describes the 5094-IY8 module configuration tags.

**Table 35 - 5094-IY8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
CJChxx.Disable	BOOL	<p>The CJ measurement is not used when the module calculates the CJ compensation.</p> <p>There are two CJ measurements that can be taken on the module. The combination of configuration values determines how CJ compensation is affected. Consider the following:</p> <ul style="list-style-type: none"> <li>If you enable CJCh00 and CJCh01 measurements, both measurements are used to calculate CJ compensation.</li> <li>If you enable only one CJChxx measurement, only that measurement is used to calculate CJ compensation.</li> <li>If you disable both CJChxx measurements, it is assumed that the cold junction temperature is 0 in the CJ compensation.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Cold junction measurement is used to calculate CJ compensation</li> <li>1 = Cold junction measurement is not used to calculate CJ compensation</li> </ul>
CJChxx.Remote	BOOL	<p>Indicates if the cold junction sensor is mounted on a remote termination block when set, rather than on the local terminal block. Needed for proper cold junction compensation when linearizing thermocouples.</p> <p>If the cold junction sensor is mounted on a remote termination block, CJCh00 is used with channels 00 and 01 and CJCh01 is used with channels 02 and 03.</p> <p>If the input type is Thermocouple/RTD, one additional field Remote CJ Ch is added.</p> <p>When Remote CJ Ch is selected, InputSSVSwitchEN is disabled.</p> <p>Any one CJ channel or multiple channels can be chosen as remote termination.</p>	<ul style="list-style-type: none"> <li>0 = Cold junction sensor is not mounted on a remote termination block</li> <li>1 = Cold junction sensor is mounted on a remote termination block</li> </ul>
CJChxx.SensorOffset	REAL	Offset added directly to the measured CJ temperature. Used to compensate for cold junction temperature sensor error.	Any
Chxx.Range	SINT	Channel's operating range	<ul style="list-style-type: none"> <li>0 = -10...10V</li> <li>1 = 0...5V</li> <li>2 = 0...10V</li> <li>4 = 0...20 mA</li> <li>5 = 4...20 mA</li> <li>6 = -100...100 mV</li> <li>7 = unused</li> <li>8 = 1...487 Ω 2-wire</li> <li>9 = 2...1,000 Ω 2-wire</li> <li>10 = 4...2,000 Ω 2-wire</li> <li>11 = 8...4,000 Ω 2-wire</li> <li>12 = 1...487 Ω 3-wire</li> <li>13 = 2...1,000 Ω 3-wire</li> <li>14 = 4...2,000 Ω 3-wire</li> <li>15 = 8...4,000 Ω 3-wire</li> </ul> <p>If the input type is Thermocouple/RTD, the additional values below are included.</p> <ul style="list-style-type: none"> <li>16 = 1...500 Ω 4-wire</li> <li>17 = 2...1,000 Ω 4-wire</li> <li>18 = 4...2,000 Ω 4-wire</li> <li>19 = 8...4,000 Ω 4-wire</li> </ul>



**Table 35 - 5094-IY8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.SensorType	SINT		<p>RTD Mode:</p> <ul style="list-style-type: none"> <li>0 = no linearization, <math>\Omega</math> (if "Remote termination" is used as the input channel, this value is not shown)</li> <li>1 = 100 <math>\Omega</math> Platinum 385</li> <li>2 = 200 <math>\Omega</math> Platinum 385</li> <li>3 = 500 <math>\Omega</math> Platinum 385</li> <li>4 = 1000 <math>\Omega</math> Platinum 385</li> <li>5 = 100 <math>\Omega</math> Platinum 3916</li> <li>6 = 200 <math>\Omega</math> Platinum 3916</li> <li>7 = 500 <math>\Omega</math> Platinum 3916</li> <li>8 = 1000 <math>\Omega</math> Platinum 3916</li> <li>9 = 10 <math>\Omega</math> Copper 427</li> <li>10 = 120 <math>\Omega</math> Nickel 672</li> <li>11 = 100 <math>\Omega</math> Nickel 618</li> <li>12 = 120 <math>\Omega</math> Nickel 618</li> <li>13 = 200 <math>\Omega</math> Nickel 618</li> <li>14 = 500 <math>\Omega</math> Nickel 618</li> </ul> <p>Thermocouple Mode:</p> <ul style="list-style-type: none"> <li>0 = mV (if "Remote termination" is used as the input channel, this value is not shown)</li> <li>1 = B</li> <li>2 = C</li> <li>3 = E</li> <li>4 = J</li> <li>5 = K</li> <li>6 = N</li> <li>7 = R</li> <li>8 = S</li> <li>9 = T</li> <li>10 = TXK/XK (L)</li> <li>11 = D</li> </ul>
Chxx.NotchFilter	SINT	Notch Filter removes line noise for the channel.	<ul style="list-style-type: none"> <li>0 = 5 Hz</li> <li>1 = 10 Hz</li> <li>2 = 15 Hz</li> <li>3 = 20 Hz</li> <li>4 = 50 Hz</li> <li>5 = 60 Hz</li> <li>6 = 100 Hz</li> <li>7 = 200 Hz</li> <li>8 = 500 Hz</li> <li>9 = 1,000 Hz</li> <li>10 = 2,500 Hz</li> <li>11 = 5,000 Hz</li> <li>12 = 10,000 Hz</li> <li>13 = 15,625 Hz</li> <li>14 = 25,000 Hz</li> <li>15 = 31,250 Hz</li> <li>16 = 62,500 Hz</li> </ul>

Table 35 - 5094-IY8 Module - Configuration Tags

Name	Data Type	Definition	Valid Values
Chxx.AlarmDisable	BOOL	<p>Disables all alarms on the channel.</p> <p><b>IMPORTANT:</b> Consider the following:</p> <ul style="list-style-type: none"> <li>When if you change this tag to 0, that is, so alarms are not disabled, you must also enable the individual alarms for them to work.</li> </ul> <p>For example, if you want to use the Low Low alarm for a channel, you must set the Chxx.AlarmDisable to 0 and set the Chxx.LLAlarmEn output tag to 1 so the alarm is enabled.</p> <p>This applies to all alarms on the module.</p> <ul style="list-style-type: none"> <li>Conversely, if you set this tag to 1, alarms are disabled regardless of the setting on the alarm enable tag for any alarm.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Alarms are enabled</li> <li>1 = Alarms are disabled (default)</li> </ul>
Chxx.ProcessAlarmLatchEn	BOOL	<p>Configures Process alarms to latch until they are explicitly unlatched.</p> <p>The Process alarms include:</p> <ul style="list-style-type: none"> <li>HighHigh alarm</li> <li>High alarm</li> <li>Low alarm</li> <li>LowLow alarm</li> </ul>	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.RateAlarmLatchEn	BOOL	Configures the Rate alarm to latch until it is explicitly unlatched.	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.OpenWireEn	BOOL	Enable the input Open Wire diagnostic	<ul style="list-style-type: none"> <li>0 = Disabled (default)</li> <li>1 = Enabled</li> </ul>
Chxx.Disable	BOOL	Disables the channel.	<ul style="list-style-type: none"> <li>0 = Channel is enabled (default)</li> <li>1 = Channel is disabled</li> </ul>
Chxx.InputSSVSwitchEn	BOOL	Select when using 2-wire current transmitter that is powered from Sensor Source Voltage (SSV). This shorts the analog input channel and analog common ground to avoid the need to install an additional jumper wire on the terminal.	<ul style="list-style-type: none"> <li>0 = Analog input and analog common ground are opened (default) (For use with RTD, thermocouple, or transmitters (V/I output) that are powered by an external power source)</li> <li>1 = Analog input and analog common ground are shorted (For use with 2-wire current transmitter that are powered from SSV)</li> </ul>
Chxx.TenOhmOffset	INT	Offset used to linearize a 10 $\Omega$ copper sensor type's input	-1.00...1.00 $\Omega$
Chxx.DigitalFilter	INT	A non-zero value enables the filter, providing a time constant in milliseconds used in a first order lag filter to smooth the input signal.	All positive values

**Table 35 - 5094-IY8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.LowSignal	REAL	One of four points used in scaling. The low signal is in terms of the inputs signal units and corresponds to the low engineering term when scaled.	<ul style="list-style-type: none"> <li>• <b>Current input type</b> - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>– 0 = default for 0...20 mA range</li> <li>– 4 = default for 4...20 mA</li> </ul> </li> <li>• <b>Voltage input type</b> - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>– -10 = default for -10...10V range</li> <li>– 0 = default for 0...5V and 0...10V ranges</li> </ul> </li> <li>• <b>RTD input type</b> - By default, this tag value is the lowest temperature supported by the Sensor Type connected to the channel. You can change the value, if necessary. The value is always Celsius units. For a list of the temperature values associated with each RTD input sensor type, see <a href="#">Table 17 on page 56</a>.</li> <li>• <b>Thermocouple input type</b> - By default, this tag value is the lowest temperature supported by the Thermocouple type connected to the channel. The value is always in Celsius units. For a list of the temperature values associated with each Thermocouple input sensor type, see <a href="#">Table 17 on page 56</a>.</li> </ul>
Chxx.HighSignal	REAL	One of four points used in scaling. The high signal is in terms of the inputs signal units and corresponds to the high engineering term when scaled.	<ul style="list-style-type: none"> <li>• <b>Current input type</b> - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>– 20 = default for either current input range</li> </ul> </li> <li>• <b>Voltage input type</b> - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>– 10 = default for 0...10V and -10...10V ranges</li> <li>– 5 = default for 0...5V range</li> </ul> </li> <li>• <b>RTD input type</b> - By default, this tag value is the highest temperature supported by the Sensor Type connected to the channel. You can change the value, if necessary. The value is always Celsius units. For a list of the temperature values associated with each RTD input sensor type, see <a href="#">Table 17 on page 56</a>.</li> <li>• <b>Thermocouple input type</b> - By default, the tag value is the highest temperature supported by the Thermocouple type connected to the channel. You can change the value, if necessary. The value is always in Celsius units. For a list of the temperature values associated with each Thermocouple input sensor type, see <a href="#">Table 17 on page 56</a>.</li> </ul>

Table 35 - 5094-IY8 Module - Configuration Tags

Name	Data Type	Definition	Valid Values
Chxx.LowEngineering	REAL	One of four points used in scaling. The low engineering helps determine the engineering units the signal values scale into. The low engineering term corresponds to the low signal value.	<p>Any value less than the high engineering value.</p> <ul style="list-style-type: none"> <li>• <b>Current input type:</b> 0.0 = default</li> <li>• <b>Voltage input type:</b> Low signal = default. For example, with the -10...10V range, the default = -10.</li> <li>• <b>RTD input type</b> - By default, the tag value is the lowest temperature supported by the Sensor Type connected to the channel. You can change the value, if necessary. The engineering units value matches the Temperature Units that you choose. For a list of the temperature values associated with each RTD input sensor type, see <a href="#">Table 17 on page 56</a>.</li> <li>• <b>Thermocouple input type</b> - By default, the tag value is the lowest temperature supported by the Thermocouple type connected to the channel. You can change the value, if necessary. The engineering units value matches the Temperature Units that you choose. For a list of the temperature values associated with each Thermocouple input sensor type, see <a href="#">Table 17 on page 56</a>.</li> </ul>
Chxx.HighEngineering	REAL	One of four points used in scaling. The high engineering helps determine the engineering units the signal values scale into. The high engineering term corresponds to the high signal value.	<p>Any value greater than the low engineering value.</p> <ul style="list-style-type: none"> <li>• <b>Current input type:</b> 100.0 = default</li> <li>• <b>Voltage input type:</b> High signal = default. For example, with the -10...10V range, the default = 10.</li> <li>• <b>RTD input type</b> - By default, the tag value is the highest temperature supported by the Sensor Type connected to the channel. You can change the value, if necessary. The engineering units value matches the Temperature Units that you choose. For a list of the temperature values associated with each RTD input sensor type, see <a href="#">Table 17 on page 56</a>.</li> <li>• <b>Thermocouple input type</b> - By default, the tag value is the highest temperature supported by the Thermocouple type connected to the channel. You can change the value, if necessary. The engineering units value matches the Temperature Units that you choose. For a list of the temperature values associated with each Thermocouple input sensor type, see <a href="#">Table 17 on page 56</a>.</li> </ul>
Chxx.LLAlarmLimit	REAL	The Low Low alarm trigger point. Causes the ChxxLLAlarm to trigger when the input signal moves beneath the configured trigger point. In terms of engineering units.	0.0 = default
Chxx.LAlarmLimit	REAL	The Low alarm trigger point. Causes the ChxxLAlarm to trigger when the input signal moves beneath the configured trigger point. In terms of engineering units.	0.0 = default

**Table 35 - 5094-IY8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.HAlarmLimit	REAL	The High alarm trigger point. Causes the ChxxHAlarm to trigger when the input signal moves above the configured trigger point. In terms of engineering units.	100.0 = default
Chxx.HHAlarmLimit	REAL	The High High alarm trigger point. Causes the ChxxHHAlarm to trigger when the input signal moves above the configured trigger point. In terms of engineering units.	100.0 = default
Chxx.RateAlarmLimit	REAL	The Rate alarm trigger point. Causes the ChxxRateAlarm to trigger when the input signal changes at a rate faster than the configured rate alarm. Configured in Engineering Units per second.	0...100 0 = default
Chxx.AlarmDeadband	REAL	Allows a process alarm to remain set, despite the alarm condition disappearing, as long as the input data remains within the deadband of the process alarm. The deadband value is subtracted from the High and High High Alarm Limits to calculate the deadband thresholds for these alarms. The deadband value is added to the Low and Low Low Alarm Limits to calculate the deadband thresholds for these alarms.	Any non-negative value 0 = default

## Input Tags

[Table 36](#) describes the 5094-IY8 module input tags.

**Table 36 - 5094-IY8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
RunMode	BOOL	Channel's operating state	<ul style="list-style-type: none"> <li>0 = Idle</li> <li>1 = Run</li> </ul>
ConnectionFaulted	BOOL	Indicates if a connection is running. The module sets this tag to 0 when connected. If the module is not connected, it changes the tag to 1.	<ul style="list-style-type: none"> <li>0 = Connection running</li> <li>1 = Connection not running</li> </ul>
DiagnosticActive	BOOL	Indicates if any diagnostics are active or if the prognostics threshold is reached.	<ul style="list-style-type: none"> <li>0 = No diagnostics active</li> <li>1 = One or more diagnostics are active or the prognostics threshold is reached</li> </ul>
DiagnosticSequenceCount	SINT	Increments for each time a distinct diagnostic condition is detected, and when a distinct diagnostic condition transitions from detected to not detected. Set to zero by product reset or power cycle. Wraps from 255 (-1) to 1 skipping zero.	-127...128 The value of 0 is skipped except during module power-up.
CJChxx.Fault	BOOL	Indicates that the cold junction data is inaccurate and <b>cannot be trusted</b> for use in the application. If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good</li> <li>1 = Bad, causing fault</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Channel is disabled</li> <li>– Open Wire condition</li> <li>– Underrange/Ovrrange condition</li> <li>– Short Circuit condition</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>

Table 36 - 5094-IY8 Module - Input Tags

Name	Data Type	Definition	Valid Values
CJChxx.Uncertain	BOOL	Indicates that the cold junction data can be inaccurate but the <b>degree of inaccuracy is not known</b> . If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good data</li> <li>1 = Uncertain data</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Data signal slightly outside the channel operating range</li> <li>– The channel is slightly over temperature.</li> <li>– Invalid sensor offset value</li> <li>– Calibration fault on the channel</li> <li>– Calibration is in process on the channel</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>
CJChxx.OpenWire	BOOL	The cold junction wire is disconnected from the channel or the RTB is removed from the module. If this condition exists, confirm that you are using one of the following RTBs: <ul style="list-style-type: none"> <li>• 5094-RTB3T</li> <li>• 5094-RTB3TS</li> </ul>	<ul style="list-style-type: none"> <li>0 = Open Wire condition does not exist</li> <li>1 = Open Wire condition exists. That is, a signal wire is disconnected from the channel or the RTB is removed from the module.</li> </ul>
CJChxx.FieldPowerOff	BOOL	Field power is present at the cold junction.	<ul style="list-style-type: none"> <li>0 = Field Power is present</li> <li>1 = Field Power is not present</li> </ul>
CJChxx.Underrange	BOOL	The cold junction at the channel is below the minimum of its operating range.	<ul style="list-style-type: none"> <li>0 = Channel data is not beneath the absolute minimum</li> <li>1 = Channel data is beneath the absolute minimum</li> </ul>
CJChxx.Ovrange	BOOL	The cold junction at the channel is above the maximum of its operating range.	<ul style="list-style-type: none"> <li>0 = Channel data is not above the absolute minimum</li> <li>1 = Channel data is above the absolute minimum</li> </ul>
CJChxx.Temperature	REAL	Current temperature of the cold junction in degrees C. This tag <b>must</b> use Celsius.	Any
Chxx.Fault	BOOL	Indicates that channel data is inaccurate and <b>cannot be trusted</b> for use in the application. If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good</li> <li>1 = Bad, causing fault</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Channel is disabled</li> <li>– Open Wire condition</li> <li>– Underrange/Ovrange condition</li> <li>– Short Circuit condition</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>
Chxx.Uncertain	BOOL	Indicates that the channel data can be inaccurate but the <b>degree of inaccuracy is not known</b> . If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good data</li> <li>1 = Uncertain data</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Data signal slightly outside the channel operating range</li> <li>– The channel is slightly over temperature.</li> <li>– Invalid sensor offset value</li> <li>– Calibration fault on the channel</li> <li>– Calibration is in process on the channel</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>
Chxx.OpenWire	BOOL	The signal wire is disconnected from the channel or the RTB is removed from the module.	<ul style="list-style-type: none"> <li>0 = Open Wire condition does not exist</li> <li>1 = Open Wire condition exists. That is, a signal wire is disconnected from the channel or the RTB is removed from the module.</li> </ul>

**Table 36 - 5094-IY8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
Chxx.OverTemperature	BOOL	Module is higher temperature than its operating limits. <ul style="list-style-type: none"> <li>If this tag is set to 1 but a fault does not exist on the channel, this tag is only an indication of operating conditions but the channel is functioning.</li> <li>If this tag is set to 1 and a fault exists on the channel, the channel is not functioning.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Module temperature is not over the operating limits</li> <li>1 = Module temperature is over the operating limits</li> </ul>
Chxx.FieldPowerOff	BOOL	Field power is not present at the channel.	<ul style="list-style-type: none"> <li>0 = Field Power is present</li> <li>1 = Field Power is not present</li> </ul>
Chxx.NotANumber	BOOL	Indicates if the last received channel data was not a number.	<ul style="list-style-type: none"> <li>0 = Last channel data received was a number</li> <li>1 = Last channel data received was not a number</li> </ul>
Chxx.Underrange	BOOL	Indicates the channel data is beneath the underrange threshold for this channel. For example, when the channel operates in the 4...20 mA input range, the underrange threshold on the channel is $\leq 3.0$ mA. If the input signal is 0 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not beneath the underrange threshold</li> <li>1 = Channel data is beneath the underrange threshold</li> </ul>
Chxx.Ovrerrange	BOOL	Indicates the channel data is above the overrange threshold for this channel. For example, when the channel operates in the 4...20 mA input range, the overrange threshold on the channel is $\geq 23.0$ mA. If the input signal is 24 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not above the overrange threshold</li> <li>1 = Channel data is above the overrange threshold</li> </ul>
Chxx.LLAlarm	BOOL	Triggered when the input data value is less than the Low Low alarm value. If latched, this alarm remains triggered until unlatched or if the input data value is within Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.LAlarm	BOOL	Triggered when the input data value is less than the Low alarm value. If latched, this alarm remains triggered until unlatched or if the input data value is within Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.HAlarm	BOOL	Triggered when the input data value is greater than the High alarm value. If latched, this alarm remains triggered until unlatched or if the input data value is within Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.HHAlarm	BOOL	Triggered when the input data value is greater than the High High alarm value. If latched, this alarm remains triggered until unlatched or if the input data value is within Deadband.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.RateAlarm	BOOL	Triggered when the change between consecutive channel samples divided by the period of time between when the samples were taken exceeds the Rate Alarm. If latched, this tag remains set until it is unlatched.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.CalFault	BOOL	Indicates the last attempted Calibration for this channel failed. This tag is cleared, that is, set to 0, when power is cycled to the module.	<ul style="list-style-type: none"> <li>0 = Calibration did not fail</li> <li>1 = Calibration failed</li> </ul>
Chxx.Calibrating	BOOL	Indicates the channel is currently being calibrated.	<ul style="list-style-type: none"> <li>0 = Channel is not being calibrated</li> <li>1 = Channel is being calibrated</li> </ul>
Chxx.CalGoodLowRef	BOOL	Indicates that a valid Low Reference signal has been sampled on this channel. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Valid Low Reference signal has not been sampled on this channel</li> <li>1 = Valid Low Reference signal has been sampled on this channel</li> </ul>

Table 36 - 5094-IY8 Module - Input Tags

Name	Data Type	Definition	Valid Values
Chxx.CalBadLowRef	BOOL	<p>Indicates that an invalid Low Reference signal has been sampled on this channel. You must correct this condition to successfully calibrate the module.</p> <p>If calibration is aborted with an invalid Low Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = Invalid Low Reference signal has not been sampled on this channel</li> <li>1 = Invalid Low Reference signal has been sampled on this channel</li> </ul>
Chxx.CalGoodHighRef	BOOL	<p>Indicates that a valid High Reference signal has been sampled on this channel.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = Valid High Reference signal has not been sampled on this channel</li> <li>1 = Valid High Reference signal has been sampled on this channel</li> </ul>
Chxx.CalBadHighRef	BOOL	<p>Indicates that an invalid High Reference signal has been sampled on this channel.</p> <p>You must correct this condition to successfully calibrate the module.</p> <p>If calibration is aborted with an invalid High Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = Invalid High Reference signal has not been sampled on this channel</li> <li>1 = Invalid High Reference signal has been sampled on this channel</li> </ul>
Chxx.CalSuccessful	BOOL	<p>Indicates calibration on this channel is complete and the Calibrating state has been exited.</p> <p>This tag remains set after valid calibration as long as connection is open.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = Calibration was not successful</li> <li>1 = Calibration was successful and calibrating state has been exited.</li> </ul>
Chxx.Data	REAL	Channel data in scaled Engineering Units.	Any positive or negative value.
Chxx.RollingTimestamp	INT	<p>Continuously-running 15-bit timer that counts in milliseconds.</p> <p>Whenever an input module scans its channels, it also records the value of RollingTimestamp at that time.</p> <p>The user program can then use the last two RollingTimestamp values and calculate the interval between receipt of data or the time when new data has been received.</p>	0 ... 32767



## Output Tags

[Table 37](#) describes the 5094-IY8 module output tags.

**Table 37 - 5094-IY8 Module - Output Tags**

Name	Data Type	Definition	Valid Values
Chxx.LLAlarmEn	BOOL	Enables the Low Low alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.LAlarmEn	BOOL	Enables the Low alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.HAlarmEn	BOOL	Enables the High alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.HHAlarmEn	BOOL	Enables the High High alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.RateAlarmEn	BOOL	Enables the Rate alarm. <b>IMPORTANT:</b> To use this alarm, you must not only set the tag to 1. You must also make sure the Chxx.AlarmDisable configuration tag for the same channel is set to 0. If the Chxx.AlarmDisable configuration tag is set to 1, that is, alarms are disabled, this alarm does not work regardless of the tag value.	<ul style="list-style-type: none"> <li>0 = Alarm is disabled</li> <li>1 = Alarm is enabled</li> </ul>
Chxx.LLAlarmUnlatch	BOOL	Unlatches a latched Low Low Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Low Low Alarm remains latched</li> <li>1 = Low Low Alarm unlatches</li> </ul>
Chxx.LAlarmUnlatch	BOOL	Unlatches a latched Low Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Low Alarm remains latched</li> <li>1 = Low Alarm unlatches</li> </ul>
Chxx.HAlarmUnlatch	BOOL	Unlatches a latched High Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = High Alarm remains latched</li> <li>1 = High Alarm unlatches</li> </ul>
Chxx.HHAlarmUnlatch	BOOL	Unlatches a set High High Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = High High Alarm remains latched</li> <li>1 = High High Alarm unlatches</li> </ul>
Chxx.RateAlarmUnlatch	BOOL	Unlatches a set Rate Alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Rate Alarm remains latched</li> <li>1 = Rate Alarm unlatches</li> </ul>
Chxx.Calibrate	BOOL	Initiates the Calibration process. This tag must remain set until a valid Low Reference and High Reference values are applied to the input. If the tag value transitions to 0 before calibration is finished, the process stops and calibration fails.	<ul style="list-style-type: none"> <li>0 = Calibration process is not started</li> <li>1 = Calibration process is started</li> </ul>

Table 37 - 5094-IY8 Module - Output Tags

Name	Data Type	Definition	Valid Values
Chxx.CalLowRef	BOOL	<p>Rising edge triggers the Low Calibration at the Low Reference Point for the current input range value.</p> <p>A valid Low Reference signal must be connected to the channel before setting this tag.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = Low Reference Signal is not applied to the RTB</li> <li>1 = Low Reference Signal is applied to RTB</li> </ul>
Chxx.CalHighRef	BOOL	<p>Rising edge triggers a High Calibration at the High Reference Point for the current input range value.</p> <p>A valid High Reference signal must be connected to the channel before setting tag.</p> <p><b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags.</p> <p>For more information on how to define a module, see <a href="#">Module Definition on page 88</a></p>	<ul style="list-style-type: none"> <li>0 = High Reference Signal is not applied to the RTB</li> <li>1 = High Reference Signal is applied to RTB</li> </ul>
Chxx.SensorOffset	REAL	<p>Compensates for any known offset error on the sensor or channel to which the sensor is connected. In terms of engineering units.</p> <p>The value of this tag is added to the measured value in engineering units and is used in the Chxx.Data input tag.</p>	<p>Any</p> <p>(We recommend that you use a value in the channel's operating range.)</p> <p>0.0 = default</p>

## 5094-OF8 Module Tags

This section describes the tags associated with the 5094-OF8 module.

### Configuration Tags

[Table 38](#) describes the 5094-OF8 module configuration tags.

**Table 38 - 5094-OF8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.Range	SINT	Channel's operating range	<ul style="list-style-type: none"> <li>0 = -10...10V</li> <li>1 = 0...5V</li> <li>2 = 0...10V</li> <li>4 = 0...20 mA</li> <li>5 = 4...20 mA</li> </ul>
Chxx.AlarmDisable	BOOL	Disables all alarms on the channel.	<ul style="list-style-type: none"> <li>0 = Alarms are enabled</li> <li>1 = Alarms are disabled (default)</li> </ul>
Chxx.LimitAlarmLatchEn	BOOL	Configures Limit alarms to latch until they are explicitly unlatched.	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.RampAlarmLatchEn	BOOL	Latches Ramp alarm when set so that does not clear until explicitly unlatched.	<ul style="list-style-type: none"> <li>0 = Latching disabled (default)</li> <li>1 = Latching enabled</li> </ul>
Chxx.NoLoadEn	BOOL	Enable the input No Load diagnostic	<ul style="list-style-type: none"> <li>0 = Disabled (default)</li> <li>1 = Enabled</li> </ul>
Chxx.Disable	BOOL	Disables the channel.	<ul style="list-style-type: none"> <li>0 = Channel is enabled (default)</li> <li>1 = Channel is disabled</li> </ul>
Chxx.FaultMode	BOOL	Determines output action when a connection fault occurs. At the fault occurrence, the output holds its last state or transitions to the value set in the Fault Value parameter. The channel continues the Fault Mode for the length of time set in the Fault Value State Duration parameter.	<ul style="list-style-type: none"> <li>0 = Transition to user-defined value</li> <li>1 = Hold Last State (default)</li> </ul>
Chxx.ProgMode	BOOL	Determines output action when the controller transitions to Program mode or the connection to the module is inhibited. At the transition to Program mode, the output holds its last state or transitions to the value set in the Program Value parameter.	<ul style="list-style-type: none"> <li>0 = Transition to user-defined value</li> <li>1 = Hold Last State (default)</li> </ul>
Chxx.ProgramToFaultEn	BOOL	Determines channel action if a connection faults while the module is in a safe state for Program mode. The channel can remain in the safe state for Program mode or transition to a safe state for Fault mode. If the channel remains in safe state for Program mode, the Final Fault State parameter is ignored.	<ul style="list-style-type: none"> <li>0 = Remains in the Program state</li> <li>1 = Transitions to the safe state for the Fault mode</li> </ul>
Chxx.RampInRun	BOOL	Enables Output Ramping when the module is in Run mode. Output changes during Run mode are limited to the Maximum Ramp Rate value.	<ul style="list-style-type: none"> <li>0 = Ramping disabled (default)</li> <li>1 = Ramping enabled in Run mode</li> </ul>
Chxx.RampToProg	BOOL	Enables Output Ramping when the controller transitions to Program mode. Output changes during Program mode are limited to the Maximum Ramp Rate value.	<ul style="list-style-type: none"> <li>0 = Ramping disabled (default)</li> <li>1 = Ramping enabled to Program mode state</li> </ul>
Chxx.RampToFault	BOOL	Enables Output Ramping when the connection to the module faults. Output transitions to FaultValue and FaultFinalState are limited to the MaximumRampRate.	<ul style="list-style-type: none"> <li>0 = Ramping disabled (default)</li> <li>1 = Ramping enabled to Fault mode state</li> </ul>

Table 38 - 5094-0F8 Module - Configuration Tags

Name	Data Type	Definition	Valid Values
Chxx.HoldForInit	BOOL	When set, configures the channel to hold, or not change, until initialized with a value within 0.1% of full scale of its current value when one of the following conditions occurs. <ul style="list-style-type: none"> <li>Module initial connection (power up)</li> <li>Controller transition from Program mode back to Run mode</li> <li>Module reestablishes communication after a fault</li> <li>SA power is restored after being lost.</li> </ul>	<ul style="list-style-type: none"> <li>0= Output 0.Chxx.Data signal immediately</li> <li>1= Hold last signal until initialization match</li> </ul>
Chxx.FaultValueStateDuration	SINT	Determines the length of time the FaultMode or FaultValue parameter value is held prior to the Final Fault State.	<ul style="list-style-type: none"> <li>0 = Hold forever (default)</li> <li>Any of the following: <ul style="list-style-type: none"> <li>1, 2, 5, or 10 seconds</li> </ul> </li> </ul>
Chxx.MaxRampRate	REAL	Maximum rate at which the channel can transition to in Engineering Units/Second. This tag is used only if at least one of the following output ramping modes is enabled: <ul style="list-style-type: none"> <li>Ramp In Run</li> <li>Ramp To Fault</li> <li>Ramp To Program</li> </ul>	Any value $\geq 0.0$ 1,000,000.00 = default  If the MaxRampRate = 0.0, the ramp rate is limited to ramping the range full scale in one RPI.
Chxx.LowSignal	REAL	One of four points used in scaling. The low signal is in terms of the inputs signal units and corresponds to the low engineering term when scaled.	Current applications - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>0 = default for 0...20 mA range</li> <li>4 = default for 4...20 mA</li> </ul> Voltage applications - Any value less than the high signal in range. <ul style="list-style-type: none"> <li>-10 = default for -10...10V range</li> <li>0 = default for 0...5V and 0...10V range</li> </ul>
Chxx.HighSignal	REAL	One of four points used in scaling. The high signal is in terms of the inputs signal units and corresponds to the high engineering term when scaled.	Current applications - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>20 = default for either current input range</li> </ul> Voltage applications - Any value greater than the low signal in range. <ul style="list-style-type: none"> <li>10 = default for 0...10V and -10...10V ranges</li> <li>5 = default for 0...5V range</li> </ul>
Chxx.LowEngineering	REAL	One of four points used in scaling. The low engineering helps determine the engineering units the signal values scale into. The low engineering term corresponds to the low signal value.	Any value less than the high engineering value. <ul style="list-style-type: none"> <li>Current applications: 0.0 = default</li> <li>Voltage applications: Low signal = default. For example, with the -10...10V range, the default = -10.</li> </ul>
Chxx.HighEngineering	REAL	One of four points used in scaling. The high engineering helps determine the engineering units the signal values scale into. The high engineering term corresponds to the high signal value.	Any value greater than the low engineering value. <ul style="list-style-type: none"> <li>Current applications: 100.0 = default</li> <li>Voltage applications: High signal = default. For example, with the -10...10V range, the default = 10.</li> </ul>
Chxx.LowLimit	REAL	Lowest value to which the output can go based on the operating range established by the Output Clamping feature. The tag value is engineering units.	Any value lower than the HighLimit 0.0 = default
Chxx.HighLimit	REAL	Highest value to which the output can go based on the operating range established by the Output Clamping feature. The tag value is engineering units.	Any value higher than the LowLimit 0.0 = default
Chxx.Offset	REAL	Compensates for any known error on the sensor or channel to which the sensor is connected. The value is set in engineering units.	Any value (We recommend that you use a small value.) 0.0 = default

**Table 38 - 5094-OF8 Module - Configuration Tags**

Name	Data Type	Definition	Valid Values
Chxx.FaultValue	REAL	Value to which the output changes if the following events exist: <ul style="list-style-type: none"> <li>Fault Mode = 0</li> <li>Either of the following: <ul style="list-style-type: none"> <li>Controller is in Run mode and the connection is lost</li> <li>Controller is in Program mode, the connection is lost, and the ProgramToFaultEn tag is set</li> </ul> </li> </ul>	Any value 0.0 = default
Chxx.ProgValue	REAL	Value to which the channel changes if the following events exist: <ul style="list-style-type: none"> <li>Program Mode = 0</li> <li>Controller transitions to Program mode</li> </ul>	Any value 0.0 = default
Chxx.FaultFinalState	REAL	Value to which the channel changes if the following events exist: <ul style="list-style-type: none"> <li>Connection is lost</li> <li>Time defined by the FaultValueStateDuration parameter has been exceeded</li> </ul> Output transitions to FaultValue and FaultFinalState are limited to the MaximumRampRate.	Any value 0.0 = default

## Input Tags

[Table 39](#) describes the 5094-OF8 module input tags.

**Table 39 - 5094-OF8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
RunMode	BOOL	Channel's operating state	<ul style="list-style-type: none"> <li>0 = Idle</li> <li>1 = Run</li> </ul>
ConnectionFaulted	BOOL	Indicates if a connection is running. The module sets this tag to 0 when connected. If the module is not connected, it changes the tag to 1.	<ul style="list-style-type: none"> <li>0 = Connection running</li> <li>1 = Connection not running</li> </ul>
DiagnosticActive	BOOL	Indicates if any diagnostics are active or if the prognostics threshold is reached.	<ul style="list-style-type: none"> <li>0 = No diagnostics active</li> <li>1 = One or more diagnostics are active or the prognostics threshold is reached</li> </ul>
DiagnosticSequenceCount	SINT	Increments for each time a distinct diagnostic condition is detected, and when a distinct diagnostic condition transitions from detected to not detected. Set to zero by product reset or power cycle. Wraps from 255 (-1) to 1 skipping zero.	-128...127 The value of 0 is skipped except during module power-up.
Chxx.Fault	BOOL	Indicates that channel data is inaccurate and <b>cannot be trusted</b> for use in the application. If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good</li> <li>1 = Bad, causing fault</li> </ul> The typical causes of uncertain data are the following: <ul style="list-style-type: none"> <li>Channel is disabled</li> <li>No Load condition</li> <li>Underrange/Overrange condition</li> <li>Short Circuit condition</li> </ul> We recommend that you first troubleshoot the module to see if the typical causes exist.

Table 39 - 5094-0F8 Module - Input Tags

Name	Data Type	Definition	Valid Values
Chxx.Uncertain	BOOL	Indicates that the channel data can be inaccurate but the <b>degree of inaccuracy is not known</b> . If the tag is set to 1, you must troubleshoot the module to correct the cause of the inaccuracy. <b>IMPORTANT:</b> Once the condition that causes the tag to change to 1 is removed, the tag automatically resets to 0.	<ul style="list-style-type: none"> <li>0 = Good data</li> <li>1 = Uncertain data</li> </ul> <p>The typical causes of uncertain data are the following:</p> <ul style="list-style-type: none"> <li>– Data signal slightly outside the channel operating range</li> <li>– The channel is slightly over temperature.</li> <li>– Invalid sensor offset value</li> <li>– Calibration fault on the channel</li> <li>– Calibration is in process on the channel</li> </ul> <p>We recommend that you first troubleshoot the module to see if the typical causes exist.</p>
Chxx.NoLoad	BOOL	The signal wire is disconnected from the channel or the RTB is removed from the module. This condition is detected only when the channel is used in current mode.	<ul style="list-style-type: none"> <li>0 = No Load condition does not exist</li> <li>1 = No Load condition exists. That is, a signal wire is disconnected from the channel or the RTB is removed from the module.</li> </ul>
Chxx.ShortCircuit	BOOL	A Short Circuit or Overcurrent condition exists. This condition is detected only when the channel is used in voltage mode.	<ul style="list-style-type: none"> <li>0 = No Short Circuit or Overcurrent condition exists</li> <li>1 = Short Circuit or Overcurrent condition exists</li> </ul>
Chxx.OverTemperature	BOOL	Module is higher temperature than its operating limits. <ul style="list-style-type: none"> <li>If this tag is set to 1 but a fault does not exist on the channel, this tag is only an indication of operating conditions but the channel is functioning.</li> <li>If this tag is set to 1 and a fault exists on the channel, the channel is not functioning.</li> </ul>	<ul style="list-style-type: none"> <li>0 = Module temperature is not over the operating limits</li> <li>1 = Module temperature is over the operating limits</li> </ul>
Chxx.FieldPowerOff	BOOL	Field power is not present at the channel.	<ul style="list-style-type: none"> <li>0 = Field Power is present</li> <li>1 = Field Power is not present</li> </ul>
Chxx.InHold	BOOL	Indicates that the channel is currently holding until the received data value is within 0.1% range full scale of the current data value.	<ul style="list-style-type: none"> <li>0 = Channel is not holding</li> <li>1 = Channel is holding</li> </ul>
Chxx.NotANumber	BOOL	Indicates that the last value received for the channel output data value was not a number.	<ul style="list-style-type: none"> <li>0 = Last channel data received was a number</li> <li>1 = Last channel data received was not a number</li> </ul>
Chxx.Underrange	BOOL	Indicates the channel data is beneath the underrange threshold for this channel. For example, when the channel operates in the 4...20 mA output range, the underrange threshold on the channel is $\leq 3.6$ mA. If the output signal is 0 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not beneath the underrange threshold</li> <li>1 = Channel data is beneath the underrange threshold</li> </ul>
Chxx.Ovrange	BOOL	Indicates the channel data is above the overrange threshold for this channel. For example, when the channel operates in the 4...20 mA output range, the overrange threshold on the channel is $\geq 21.0$ mA. If the output signal is 21 mA, this tag is set to 1.	<ul style="list-style-type: none"> <li>0 = Channel data is not above the overrange threshold</li> <li>1 = Channel data is above the overrange threshold</li> </ul>
Chxx.LLimitAlarm	BOOL	Triggered when the requested output value is below the configured Low Limit value. It remains set until the requested output is above the Low Limit. If the Chxx.AlarmDisable tag is set to 1, that is, the output signal is still clamped at the Low Limit value. But the Low Limit alarm is not triggered.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.HLimitAlarm	BOOL	Triggered when the requested output value is above the configured High Limit value. It remains set until the requested output is below the High Limit. If the Chxx.AlarmDisable tag is set to 1, that is, the output signal is still clamped at the High Limit value. But the High Limit alarm is not triggered.	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>

**Table 39 - 5094-0F8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
Chxx.RampAlarm	BOOL	Indicates that the analog output has been commanded to change value in a way such that the Maximum Ramp Rate is exceeded	<ul style="list-style-type: none"> <li>0 = Alarm is not triggered</li> <li>1 = Alarm is triggered</li> </ul>
Chxx.CalFault	BOOL	Indicates the last attempted Calibration for this channel failed. This tag is cleared, that is, set to 0, when power is cycled to the module.	<ul style="list-style-type: none"> <li>0 = Calibration did not fail</li> <li>1 = Calibration failed</li> </ul>
Chxx.Calibrating	BOOL	Indicates the channel is currently being calibrated.	<ul style="list-style-type: none"> <li>0 = Channel is not being calibrated</li> <li>1 = Channel is being calibrated</li> </ul>
Chxx.CalGoodLowRef	BOOL	Indicates that a valid Low Reference measurement was passed through the output tag to the module. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Valid Low Reference measurement was not passed to the module</li> <li>1 = Valid Low Reference measurement was passed to the module</li> </ul>
Chxx.CalBadLowRef	BOOL	Indicates that an invalid Low Reference signal has been sampled on this channel. You must correct this condition to successfully calibrate the module. If calibration is aborted with an invalid Low Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Invalid Low Reference signal has not been sampled on this channel</li> <li>1 = Invalid Low Reference signal has been sampled on this channel</li> </ul>
Chxx.CalGoodHighRef	BOOL	Indicates that a valid High Reference measurement was passed through the output tag to the module. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Valid High Reference measurement was not passed to the module</li> <li>1 = Valid High Reference measurement was passed to the module</li> </ul>
Chxx.CalBadHighRef	BOOL	Indicates that an invalid High Reference signal has been sampled on this channel. You must correct this condition to successfully calibrate the module. If calibration is aborted with an invalid High Reference signal, the Chxx.CalFault tag is set for this channel until a successful calibration is performed. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Invalid High Reference signal has not been sampled on this channel</li> <li>1 = Invalid High Reference signal has been sampled on this channel</li> </ul>

**Table 39 - 5094-OF8 Module - Input Tags**

Name	Data Type	Definition	Valid Values
Chxx.CalSuccessful	BOOL	Indicates calibration on this channel is complete and the Calibrating state has been exited. This tag remains set after valid calibration as long as connection is open. <b>IMPORTANT:</b> This tag is available only when you use the Data with Calibration connection type in the Module Definition. If you use the Data connection type, this tag does not appear in the module tags. For more information on how to define a module, see <a href="#">Module Definition on page 88</a>	<ul style="list-style-type: none"> <li>0 = Calibration was not successful</li> <li>1 = Calibration was successful and calibrating state has been exited.</li> </ul>
Chxx.Data	REAL	Indicates the signal value currently output at the RTB in scaled Engineering Units.	Any positive or negative value.
Chxx.RollingTimestamp	INT	Continuously-running 15-bit timer that counts in milliseconds. Whenever the data echo value changes, the output module updates the value of the RollingTimestamp.	0...32767

## Output Tags

[Table 40](#) describes the 5094-OF8 module output tags.

**Table 40 - 5094-OF8 Module - Output Tags**

Name	Data Type	Definition	Valid Values
Chxx.LLimitAlarmUnlatch	BOOL	Unlatches a latched Low Limit alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Alarm remains latched (default)</li> <li>1 = Alarm is unlatched</li> </ul>
Chxx.HLimitAlarmUnlatch	BOOL	Unlatches a latched High Limit alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Alarm remains latched (default)</li> <li>1 = Alarm is unlatched</li> </ul>
Chxx.RampAlarmUnlatch	BOOL	Unlatches a latched Ramp alarm at the first instance of the bit transitioning from 0 to 1.	<ul style="list-style-type: none"> <li>0 = Alarm remains latched (default)</li> <li>1 = Alarm is unlatched</li> </ul>
Chxx.Calibrate	BOOL	Initiates the Calibration process. This tag must remain set until a valid Low Reference and High Reference values are applied to the channel.	<ul style="list-style-type: none"> <li>0 = Calibration process is not started (default)</li> <li>1 = Calibration process is started</li> </ul>
Chxx.CalOutputLowRef	BOOL	A 0 to 1 transition commands the channel to produce the Low Calibration Reference Point for the chosen current or voltage output range.	<ul style="list-style-type: none"> <li>0 = Do not output Cal Low Reference</li> <li>1 = Output Calibration Low Reference</li> </ul> Do not set this tag and the CalOutputHighRef tag to 1 simultaneously.
Chxx.CalOutputHighRef	BOOL	A 0 to 1 transition commands the channel to produce the High Calibration Reference Point for the chosen current or voltage output range.	<ul style="list-style-type: none"> <li>0 = Do not Output Cal High Reference</li> <li>1 = Output Calibration High Reference Signal</li> </ul> Do not set this tag and the CalOutputLowRef tag to 1 simultaneously.
Chxx.CalLowRefPassed	BOOL	A 0 to 1 transition indicates that the Chxx.Data output tag data contains the recorded Low Reference value for the channel that is used by the module in Calibration.	<ul style="list-style-type: none"> <li>0 = Not sending Recorded Cal Low Ref</li> <li>1 = Sending Recorded Cal Low Reference in Output Data for Calibration Verification</li> </ul>



**Table 40 - 5094-0F8 Module - Output Tags**

<b>Name</b>	<b>Data Type</b>	<b>Definition</b>	<b>Valid Values</b>
Chxx.CalHighRefPassed	BOOL	A 0 to 1 transition indicates that the Chxx.Data output tag data contains the recorded High Reference value for the channel that is used by the module in Calibration.	<ul style="list-style-type: none"> <li>• 0 = Not sending Cal High Reference</li> <li>• 1 = Sending recorded Calibration High Reference Signal in Output Data for Calibration Verification</li> </ul>
Chxx.CalFinish	BOOL	Data value change that triggers the channel to complete the Calibration procedure, applying the Valid Low and High References received. Channel exits the Calibration state if successful.	<ul style="list-style-type: none"> <li>• 0 = Channel not triggered to complete the calibration procedure</li> <li>• 1 = Channel triggered to complete the calibration procedure</li> </ul>
Chxx.Data	REAL	The value that is converted to the signal on the RTB in scaled Engineering Units.	Any valid engineering unit

## **Notes:**

**A****absolute module accuracy** 33**alarm deadband**5094-IF8 module 43  
5094-IY8 module 60**alarms**clamp alarming  
5094-OF8 module 76  
process alarms 42-44, 59-61  
rate alarm 61  
5094-IF8 module 44**C****calibration**absolute module accuracy 33  
input module 104-109  
input module reference value 104  
Logix Designer application 101-113  
output module 110-113  
output module reference value 110**channel offset**

5094-OF8 module 73

**CIP Sync Time** 30**clamp limit**

5094-OF8 module 76

**clamping**

5094-OF8 module 75

**cold junction compensation**

Logix Designer application 96

**compatible Logix 5000 controllers** 9**configuration**Logix Designer application 81-99  
Calibration category 93, 96, 99  
Channels category 91, 94, 97  
CJ Channels category 96  
Connection category 89  
General category 87  
module definition 88  
Module Info category 90  
module tags 127-153**configure**

with Logix Designer application 26

**connection**fault handling  
5094-OF8 module 74-75  
inhibit the module 89**connection types** 15, 88**copper offset**

5094-IY8 module 66

**D****data exchange**

data echo 77

**data noise transient**digital filter usage  
5094-IF8 module 40  
5094-IY8 module 55**data tags**fault and status reporting  
5094-IF8 module 47  
5094-IY8 module 69  
5094-OF8 module 80**data transmission**

multicast method 15

**data types** 16

available with I/O modules 15

**define module**

Logix Designer application 88

**digital filter**5094-IF8 module 40  
5094-IY8 module 55**E****electronic keying** 21, 28, 88**F****fault and status reporting** 121-1255094-IF8 module 47  
5094-IY8 module 69  
5094-OF8 module 80**fault handling**

5094-OF8 module 74-75

**firmware**

obtain from PCDC 34

**H****hold for initialization**

5094-OF8 module 73

**I****I/O status indicator**description 118-120  
display 117-119**input range**5094-IF8 module 36  
5094-IY8 module 51**L****limiting**

5094-OF8 module 75

**line noise**reduce with the Notch Filter  
5094-IF8 module 37-40  
5094-IY8 module 52-55**Logix 5000 controllers**compatible with FLEX 5000 I/O modules 9  
ownership of FLEX 5000 I/O modules 14**Logix Designer application** 26calibration 101-113  
input module 104-109

- output module 110-113
- Calibration category 93, 96, 99
- Channels category 91, 94, 97
- CJ Channels category 96
- configuration overview 14
- configure a FLEX 5000 I/O system 81-99
- Connection category 89
- connection types 15
- General category 87
- module definition 88
- Module Info category 90
- module tag definitions 127
- module tags
  - 5094-IF8 module 129-135
  - 5094-IY8 module 136-146
  - 5094-OF8 module 147-153
- fault and status reporting 47, 70
- name module tag 128
- tag editor 125
- troubleshooting 121-125
- view module tag 100

## M

### module accuracy

- absolute 33
- drift with temperature 33

### module feature

- 10 Ohm copper offset
  - 5094-IY8 module 66
- alarm deadband
  - 5094-IF8 module 43
  - 5094-IY8 module 60
- channel offset
  - 5094-OF8 module 73
- clamp limit
  - 5094-OF8 module 76
- clamping
  - 5094-OF8 module 75
- cold junction compensation
  - 5094-IY8 module 69
- data echo
  - 5094-OF8 modules 77
- digital filter
  - 5094-IF8 module 40
  - 5094-IY8 module 55
- hold for initialization
  - 5094-OF8 module 73
- input ranges
  - 5094-IF8 module 36
  - 5094-IY8 module 51
- limiting
  - 5094-OF8 module 75
- no load detection
  - 5094-OF8 module 78
- notch filter
  - 5094-IF8 module 37-40
  - 5094-IY8 module 52-55
- open wire detection
  - 5094-IF8 module 45
  - 5094-IY8 module 67
- output range
  - 5094-OF8 module 72
- over temperature detection
  - 5094-IF8 module 46

- 5094-IY8 module 68
- 5094-OF8 module 79
- process alarms
  - 5094-IF8 module 42-44
  - 5094-IY8 module 59-61
- ramping
  - 5094-OF8 module 77
- rate alarm
  - 5094-IF8 module 44
  - 5094-IY8 module 61
- rate limiting
  - 5094-OF8 module 77
- sensor offset
  - 5094-IF8 module 45
  - 5094-IY8 module 66
- sensor type
  - 5094-IY8 module 62-65
- short circuit protection
  - 5094-OF8 module 78
- underrange/overrange detection
  - 5094-IF8 module 41
  - 5094-IY8 module 56

### module keying 12

### module location

- remote I/O modules 10

### module status indicator

- description 116
- display 117-119

### module tags

- 5094-IF8 module 129-135
- 5094-IY8 module 136-146
- 5094-OF8 module 147-153
- definitions 127
- fault and status reporting
  - 5094-IF8 module 47
  - 5094-IY8 module 69
  - 5094-OF8 module 80
- naming 128
- tag editor 125
- viewing 100

### module types 11

### multicast

- data broadcast method 17

## N

### no load detection

- 5094-OF8 module 78

### noise immunity

- via Notch Filter
  - 5094-IF8 module 37-40
  - 5094-IY8 module 52-55

### noise rejection

- related to multiple input channel usage
  - 5094-IF8 module 39
  - 5094-IY8 module 54
- related to RPI setting
  - 5094-IF8 module 38
  - 5094-IY8 module 53

### Notch Filter

- 5094-IF8 module 37-40
- 5094-IY8 module 52-55

## O

- open wire detection**
  - 5094-IF8 module 45
  - 5094-IY8 module 67
- output behavior**
  - after connection fault
  - 5094-OF8 module 74-75
- output device**
  - available operating range 72
- output range**
  - 5094-OF8 module 72
- over temperature detection**
  - 5094-IF8 module 46
  - 5094-IY8 module 68
  - 5094-OF8 module 79
- ownership** 14

## P

- PCDC**
  - obtain firmware 34
- process alarms**
  - 5094-IF8 module 42-44
  - 5094-IY8 module 59-61

## R

- ramping**
  - 5094-OF8 module 77
- rate alarm**
  - 5094-IF8 module 44
  - 5094-IY8 module 61
- rate limiting**
  - 5094-OF8 module 77
- remote I/O modules** 10
- RPI**
  - related to noise rejection
    - 5094-IF8 module 38
    - 5094-IY8 module 53
  - valid value 16

## S

- SA Power status indicator**
  - description 115
  - display 117-119
- sensor error**
  - channel offset
    - 5094-OF8 module 73
- sensor offset**
  - 5094-IF8 module 45
  - 5094-IY8 module 66
- sensor type**
  - temperature limit
    - 5094-IY8 module 62
  - to use with 5094-IY8 module 62-65
- short circuit protection**
  - 5094-OF8 module 78

## signal threshold

- 5094-IF8 module 41
- 5094-IY8 module 56

## status indicator, description

- I/O status indicator 118-120
- module status indicator 116
- SA Power status indicator 115

## status indicator, display

- I/O status indicator 117-119
- module status indicator 117-119
- SA Power status indicator 117-119

## T

## temperature

- effect on module accuracy 33

## thermoelectric effect

- cold junction compensation 69

## troubleshooting 115-125

- input module status indicator 117
- Logix Designer application 121-125
- module status indicator 12, 116
- output module status indicator 119
- tag editor 125

## U

## underrange/overrange detection

- 5094-IF8 module 41
- 5094-IY8 module 56

## unicast

- data broadcast method 17

## Notes:



## Rockwell Automation Support

Use the following resources to access support information.

<b>Technical Support Center</b>	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	<a href="https://rockwellautomation.custhelp.com/">https://rockwellautomation.custhelp.com/</a>
<b>Local Technical Support Phone Numbers</b>	Locate the phone number for your country.	<a href="http://www.rockwellautomation.com/global/support/get-support-now.page">http://www.rockwellautomation.com/global/support/get-support-now.page</a>
<b>Direct Dial Codes</b>	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	<a href="http://www.rockwellautomation.com/global/support/direct-dial.page">http://www.rockwellautomation.com/global/support/direct-dial.page</a>
<b>Literature Library</b>	Installation Instructions, Manuals, Brochures, and Technical Data.	<a href="http://www.rockwellautomation.com/global/literature-library/overview.page">http://www.rockwellautomation.com/global/literature-library/overview.page</a>
<b>Product Compatibility and Download Center (PCDC)</b>	Get help determining how products interact, check features and capabilities, and find associated firmware.	<a href="http://www.rockwellautomation.com/global/support/pcdc.page">http://www.rockwellautomation.com/global/support/pcdc.page</a>

## Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at [http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002\\_-en-e.pdf](http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_-en-e.pdf).

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, CompactLogix, ControlLogix, FLEX 5000, Integrated Architecture, Logix5000, Logix 5000, Rockwell Automation, Rockwell Software, Studio 5000, and Studio 5000 Logix Designer are trademarks of Rockwell Automation, Inc.  
Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444  
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640  
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 5094-UM002B-EN-P - October 2018

Supersedes Publication 5094-UM002A-EN-P - May 2018

Copyright © 2018 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.