

CompactLogix 5380, Compact GuardLogix 5380, and CompactLogix 5480 Controller Accessories

The following accessories are used with a CompactLogix 5380, Compact GuardLogix 5380, or CompactLogix 5480 controller:

- [End Cap](#)
- [Memory Cards](#)
- [Removable Terminal Kits](#) - Not used with CompactLogix 5480 controllers because the required RTBs ship with the controllers.
- [Ethernet Communication Cables](#)

End Cap

You must install an end cap, catalog number 5069-ECR, on the right side of the last module in a CompactLogix 5380, Compact GuardLogix 5380, or CompactLogix 5480 control system. The end cap is shipped with the controller.



SHOCK HAZARD: The end cap covers the exposed interconnections on the last module in the system. If you do not install the end cap before powering the system, equipment damage or injury from electric shock can result.

Memory Cards

Memory cards, also known as Secure Digital (SD) cards, offer nonvolatile memory to store a user program and tag data on a controller. Through the Logix Designer application, you can manually trigger the controller to save to or load from nonvolatile memory or configure the controller to load from nonvolatile memory on powerup.

A 1784-SD2 card ships with the controller. If you need additional SD cards, we recommend that you use one that is available from Rockwell Automation. The 1784-SD1 (1 GB) and 1784-SD2 (2 GB) cards are available.

Technical Specifications - 1784-SD1, 1784-SD2

Attribute	1784-SD1	1784-SD2
Memory	1 GB	2 GB
Supported controllers	CompactLogix 5380 controllers	
Weight, approx	1.76 g (0.062 oz)	