

Overload Relays

Bulletin 193-1EE – Single- & Three-phase Devices (Trip Class 10, 20; Manual Reset Only)

	Mounting Options	Current Range [A]	For Use With	Cat. No.
	IEC Contactors	0.1...0.5	100-C09...C23	193-1EEAB
		0.2...1.0		193-1EEBB
		1.0...5.0		193-1EECB
		3.2...16		193-1EEDB
		5.4...27		193-1EEEB
		5.4...27	100-C30...C55	193-1EEED
		11...55		193-1EEFD
		20...100	100-C60...C97	193-1EEGE
		0.1...0.5	100-E09...E16, Bul. 300 Size 00...0	193-1EEAF
		0.2...1.0		193-1EEBF
		1.0...5.0		193-1EECF
		3.2...16		193-1EEDF
		5.4...27		193-1EEEF
		1.0...5.0	100-E26...E38, Bul. 300 Size 1	193-1EECG
		5.4...27		193-1EEEG
		11...55		193-1EEFG
		13.2...66	100-E40...E65, Bul. 300 Size 2	193-1EEQH
		20...100	100-E80...E96, Bul. 300 Size 3	193-1EEGJ
	Integrated panel/DIN Rail Mount and Pass-thru • Built-in current transformer; no external current transformer required	1.0...5.0	All contactors	193-1EECP
		3.2...16		193-1EEDP
		5.4...27		193-1EEEP
		11...55		193-1EEFP
		20...100		193-1EEGP