


	Description		For Use With	Cat. No.
	Lug Connectors (3 per package)		1494C, 1494F, 1494G, and 1494V Disconnect Switches	
	Disconnect Size [A]	Wire Size		
	30	#14...8 AWG Wire		*
	60	#14...4 AWG Wire		§ 1494R-N1
	100	#8...1/0 AWG Wire		§ 1494R-N2
	200	#6...4/0 AWG Wire		§ 1494R-N3
		#6...250 MCM Wire (oversized)		§ 199-LF1
	400	(2) of #1/0...250 MCM Wire		§ 1494R-N14
		#4 AWG...500 MCM Wire (oversized)		§ 1494R-N15
600	(2) of #1/0...350 MCM Wire	§ 1494R-N10		
	(2) of #1/0...350 MCM Wire	1491-N621 or 1491-R621 600 A fuse blocks	♣ 1494R-N11	
	(1) of #4...500 MCM Wire		♣ 1494R-N12	
	Ground Connectors		1494C, 1494F, 1494G, and 1494V Disconnect Switches	599-GR1
	Ground Lug Kits	30...100 A		599-GR2
		200...400 A		599-GR3
		600 A		
		30, 60 A	1494H & 1494HL Safety Switches	599-GR4
	100, 200 A		599-GR5	
		Neutral Kits		1494H Safety Switches
30 A @ 250/600V AC Fusible (Type 1 & 3R)		599-NK1		
30 A @ 250/600V AC Non-Fusible (Type 1 & 3R)		599-NK2		
30 A @ 250/600V AC Fusible & Non-Fusible (Type 12)		599-NK3		
60 A @ 250/600V AC Fusible & Non-Fusible (Type 1 & 3R)		599-NK4		
60 A @ 250/600V AC Fusible (Type 12)		599-NK5		
60 A @ 250/600V AC Non-Fusible (Type 12)		599-NK6		
100 A @ 250/600V AC Fusible (Type 1 & 3R)		599-NK7		
100 A @ 250/600V AC Non-Fusible (Type 1, 3R, and 12)		599-NK8		
100 A @ 250/600V AC Fusible (Type 12)		599-NK9		
200 A @ 250/600V AC Fusible & Non-Fusible (Type 1 & 3R)		599-NK10		
200 A @ 250/600V AC Fusible & Non-Fusible (Type 12)		599-NK11		
	Phase Barrier Kits		1494C, 1494F, 1494G, 1494V	
	Disconnect Size [A]			
	30, 60			1494F-PH2
	100			1494F-PH3
	200			1494F-PH4
	400			1494F-PH5

* All terminals of the 30 A switches are furnished with self-lifting pressure plate connectors as standard.

♣ Each kits contains (2) lugs.

§ Each kit contains (3) lugs.