

Speed Sensing

Introduction

Standards Compliance
and Certifications

Technical
Data

Ordering
Information

**Product
Selection**

Modification and
Accessories

Approximate
Dimensions



Style J Type 1, 4 & 13 With Base Mounting

Style J — Low Speed, N.O. Contacts

Mounting Arrangement	Range of Adjustment for Contact Operation (RPM) *	Shaft Operating Speed, Max. (RPM)	Type 1, 4, & 13 Enclosure	Type 7 & 9 Enclosure♣
			Cat. No.	Cat. No.
Base	15...80\$	1200	808-J1	808-J17
3-Point Flange	15...80\$	1200	808-J2	—
4-Point Flange	15...80\$	1200	808-J3	—
Less Bracket‡	15...80\$	1200	808-J4	—



Style K Type 1, 4 & 13 with Three-Point Flange Mounting

Style K — Low Speed, N.C. Contacts

Mounting Arrangement	Range of Adjustment for Contact Operation (RPM) *	Shaft Operating Speed, Max. (RPM)	Type 1, 4, & 13 Enclosure	Type 7 & 9 Enclosure♣
			Cat. No.	Cat. No.
Base	15...80\$	1200	808-K1	808-K17
3-Point Flange	15...80\$	1200	808-K2	—
4-Point Flange	15...80\$	1200	808-K3	—