Coil Surge Protection


Standard built-in Features:

- LED
 Reverse Polarity Protection for DC Inputs





Specifications



Output Type	DPDT (2 C/O); I _{th} = 10 A		
Recommended Tightening Torque	0.6 N•m max. (5.3 lb•in.)		
Wire Range Screw Terminal: 0.22.5 mm² (#2414 AWG), Spring Terminal: 0.22.5 mm² (#2414			
Approvals	cULus, cURus, CE		

Assembled Devices	Pkg. Quantity	Cat. No. (Screw Terminals)	Cat. No. (Spring Clamp Terminals)		
Input Voltage					
12V DC	10	700-HLT12Z12	700-HLT22Z12		
24V DC	10	700-HLT12Z24*	700-HLT22Z24*		
48V DC	10	700-HLT12Z48	700-HLT22Z48		
24V AC/DC	10	700-HLT12U24*	700-HLT22U24*		
110/125V AC/DC	10	700-HLT12U1*	700-HLT22U1*		
220240V AC/DC	10	700-HLT12U2*	700-HLT22U2*		

* For Gold-plated contacts: Add the letter "X" at the end of the catalog number. Example: Cat. No. 700-HLT12Z24 with gold plated contacts is Cat. No. 700-HLT12Z24X. The following relays are available with the gold-plated contact option: 700-HLT_2Z24, 700-HLT_2U14, 700-HLT_2U14, and 700-HLT_2U12.

	Description	Pkg. Quantity	Socket Input Voltage	Cat. No.
		20	12V DC	700-TBR212
			24V AC/DC	700-TBR224*
111	Replacement Relays Order must be for 20 relays or multiples of 20.		48V DC	700-TBR248
Cat. No. 700-TBR224			110/125V AC/DC 220240V AC/DC	700-TBR2110*
**		1	Color	
and the state of t	8-Way Jumper		Red	700-TBJ08R
and the second	Can be cut to required length. I_{th} = 10 A max per 8-way jumper.		Grey	700-TBJ08G
Cat. No. 700-TBJ08B			Blue	700-TBJ08B
Cat. No. 700-HN177	End Barrier Used for visual inspection of groups, safe separation of neighboring 700-HL modules that end with jumpers.	10	Black	700-HN177
	Snap-in Marker These snap-in markers have a 6 x 12 mm surface and snap into the ejection lever for the relay.	100	Blank Standard 1492- MS6X12	1492-MS6X12 www.ab.com/ catalogs for information
			Custom	*

^{*} For gold-plated contacts: Add the letter "X" at the end of the catalog number. For example: if Cat. No. 700-TBR224 is required with gold plating, the new cat. no. is 700-TBR224X.

Note: Terminal Block Relay bases are not sold separately.



^{*} Go to http://www.ab.com/software/, click on "Terminal Marking System and WinABMS" to download software. Create custom text, save file, and e-mail to your local Rockwell Automation sales office or Allen-Bradley distributor.