


Standard Legend Plates – Aluminum, Type 4/13 (Bul. 800T)



Standard Legend Plate



Jumbo Legend Plate

Marking	Standard Cat. No.	Jumbo Cat. No.	Marking	Standard Cat. No.	Jumbo Cat. No.
AUTO-OFF-HAND	<b>800T-X501</b>	800T-X501J	ON-OFF	<b>800T-X622</b>	800T-X622J
AUTO-MAN-OFF	<b>800T-X625</b>	800T-X625J	OPEN	<b>800T-X531</b>	800T-X531J
CLOSE	<b>800T-X502</b>	800T-X502J	OPEN-CLOSE	<b>800T-X532</b>	800T-X532J
CYCLE START	<b>800T-X562</b>	800T-X562J	OPEN-OFF-CLOSE	<b>800T-X533</b>	800T-X533J
DOWN	<b>800T-X503</b>	800T-X503J	OUT	<b>800T-X534</b>	800T-X534J
EMERG. STOP (Yellow)	<b>800T-X504Y</b>	—	POWER ON	<b>800T-X639</b>	800T-X639J
EMERG. STOP (Red)*	<b>800T-X504</b>	<b>800T-X504J</b>	RAISE	<b>800T-X535</b>	800T-X535J
EMERGENCY STOP (Red)*	<b>800T-X648</b>	<b>800T-X648J</b>	RAISE-LOWER	<b>800T-X536</b>	800T-X536J
FAST	<b>800T-X505</b>	800T-X505J	RAISE-OFF-LOWER	<b>800T-X537</b>	800T-X537J
FEED START	<b>800T-X566</b>	800T-X566J	RESET	<b>800T-X538</b>	800T-X538J
FEED STOP	<b>800T-X567</b>	800T-X567J	REVERSE	<b>800T-X539</b>	800T-X539J
FOR.-REV.	<b>800T-X506</b>	800T-X506J	RUN	<b>800T-X540</b>	800T-X540J
FOR.-OFF-REV.	<b>800T-X507</b>	800T-X507J	RUN-INCH	800T-X634	800T-X634J
FORWARD	<b>800T-X508</b>	800T-X508J	RUN-JOG	<b>800T-X541</b>	<b>800T-X541</b>
FOURTH SPEED	800T-X624	800T-X624J	SAFE-RUN	<b>800T-X542</b>	800T-X542J
FULL SPEED	<b>800T-X509</b>	800T-X509J	SECOND SPEED	800T-X543	800T-X543J
HAND-AUTO	<b>800T-X510</b>	800T-X510J	SPEED*	<b>800T-X608</b>	—
HAND-OFF-AUTO	<b>800T-X511</b>	800T-X511J	SLOW	<b>800T-X544</b>	800T-X544J
HIGH	<b>800T-X512</b>	800T-X512J	SLOW-FAST	<b>800T-X545</b>	800T-X545J
HIGH-LOW	<b>800T-X513</b>	800T-X513J	SLOW-OFF-FAST	<b>800T-X546</b>	800T-X546J
HIGH-OFF-LOW	<b>800T-X514</b>	800T-X514J	START	<b>800T-X547</b>	800T-X547J
IN	<b>800T-X515</b>	800T-X515J	START-JOG	<b>800T-X548</b>	800T-X548J
INCH	<b>800T-X516</b>	800T-X516J	START-STOP	<b>800T-X549</b>	800T-X549J
JOG	<b>800T-X517</b>	800T-X517J	STOP (Red)	<b>800T-X550</b>	<b>800T-X550J</b>
JOG FORWARD	<b>800T-X518</b>	800T-X518J	STOP-START	<b>800T-X551</b>	800T-X551J
JOG REVERSE	<b>800T-X519</b>	800T-X519J	SUMMER-OFF-WINTER	800T-X553	800T-X553J
JOG RUN	<b>800T-X520</b>	800T-X520J	SUMMER-WINTER	800T-X552	800T-X552J
JOG-SAFE-RUN	<b>800T-X522</b>	800T-X522J	TEST	<b>800T-X554</b>	800T-X554J
JOG-STOP-RUN	<b>800T-X521</b>	800T-X521J	THIRD SPEED	800T-X555	800T-X555J
LEFT-RIGHT	<b>800T-X523</b>	800T-X523J	UP	<b>800T-X556</b>	800T-X556J
LOCAL-REMOTE	<b>800T-X638</b>	800T-X638J	UP-DOWN	<b>800T-X557</b>	800T-X557J
LOW	<b>800T-X524</b>	800T-X524J	UP-OFF-DOWN	<b>800T-X558</b>	800T-X558J
LOW SPEED	800T-X525	800T-X525J	O (Red)	800T-X640	800T-X640J
LOWER	<b>800T-X526</b>	800T-X526J	I	800T-X641	800T-X641J
OFF	<b>800T-X527</b>	800T-X527J	O I	800T-X642	800T-X642J
OFF-COOLANT-ON	<b>800T-X528</b>	800T-X528J	I O II	800T-X643	800T-X643J
OFF-ON	<b>800T-X529</b>	800T-X529J	—	—	—
ON	<b>800T-X530</b>	800T-X530J	—	—	—

\* These legend plates do not comply with E-Stop standards that specify a yellow background, such as IEC 60947-5-5 and NFPA 79.

\* Potentiometer type with graduated markings.