

24	60	CD013	CD013C	—	—	—	—
110 120	50 60	CD236	CD236C	CE236	CE236C	AF236	
200...208	60	CD249	CD249C	CE249	CE249C	AF249	
220 240	50 60	CD254	CD254C	CE254	CE254C	AF254	
277	60	CD260	CD260C	CE260	CE260C	AF260	
380	50	CD354	CD354C	CE354	CE354C	AF354	
415	50	CD357	CD357C	CE357	CE357C	AF357	
440 480	50 60	CD273	CD273C	CE273	CE273C	AF273	
550 600	50 60	CD278	CD278C	CE278	CE278C	AF278	

★ For non-motor loads (Bulletin 500L).

‡ For motor rated contactors and starters.


♣ Also for 240V, 60Hz.

Single Pole Contact Kit — Sizes 00...5 (Includes Front and Rear Stationary Contact, Movable Contact and Contact Spring)

	Motor Rated Contactors and Starters (Bulletin 500, 505, 509, and 520)			Non-Motor Rated Contactors (Bulletin 500L)		
	Size	Part No.		Size	No. of Poles	Part No.
	0	\$	40410-331-51	15/20 A	2...3	\$ 40410-331-53
	1	\$	40410-331-52	30 A	2...3	\$ 40410-331-54
	1P	\$	40410-331-55	60 A	2...3	\$ 40420-322-52
	2	\$	40420-322-51	100 A	2...3	40430-300-52
					4	40430-300-53
	3	40430-300-51		200 A	2...3	40440-325-52
	4	40440-300-51			4	40440-325-53
	—			300 A (Series A)	2	Z-34119
					3	Z-34120
5 (Series L&1)			42450-805-01	300 A (Series L)	2...3	42450-805-02
6 (Series B,C,&1)			40783-802-02	540A (Series B&C)	3	40783-802-02

Manual Reset (Eutectic Alloy) Overload Relays

Heater Elements — Order heater elements as a separate item. See *Eutectic Alloy Overload Relay Heater Elements for heater element selection tables.*

	Size	Cat. No.
	3-Phase or 1-Phase (3 elements)	
	00 (Series B & D)	592-JOV16
	0, 1	592-EUTB
	2	592-EUTC
	3	592-EUTD
	4	592-EUTE