

Disconnect Switch Accessories

For use on Bulletins 502, 502L, 506, 506X, 512, 512H, 512M, 512V, 522, 532, 542, 572, 1242, 1272, 1282, 1232X, and 1232V

	Description	NEMA Size	Cat. No.
	Fuse Clips		
	0...30 A, 250V AC, Class H	0...2	1401-N41
	0...30 A, 250V AC, Class J	1...3	1401-N42
	0...30 A, 600V AC, Class H		
	0...30 A, 600V AC, Class J		
	31...60 A, 250V AC, Class H		
	31...60 A, 250V AC, Class J	1...3	1401-N43
	31...60 A, 600V AC, Class H		
	31...60 A, 600V AC, Class J		
	61...100 A, 250V AC, Class H	2...4	1401-N44
	61...100 A, 250V AC, Class J		
	61...100 A, 600V AC, Class H		
	61...100 A, 600V AC, Class J		
	101...200 A, 250V AC, Class H	3...5	1401-N45
	101...200 A, 250V AC, Class J		
	101...200 A, 600V AC, Class H		
	101...200 A, 600V AC, Class J		
	201...400 A, 250V AC, Class H	4...5	1401-N46
	201...400 A, 250V AC, Class J		
	201...400 A, 600V AC, Class H		
	201...400 A, 600V AC, Class J		
	0...30 A, 250V AC, Class R	0...2*	1401-N50
	0...30 A, 600V AC, Class R		1401-N51
	31...60 A, 250V AC, Class R		
	31...60 A, 600V AC, Class R	1...3	1401-N52
	61...100 A, 250V AC, Class R	2...4	1401-N53
	61...100 A, 600V AC, Class R		
	101...200 A, 250V AC, Class R	3...5	1401-N54
	101...200 A, 600V AC, Class R		
	201...400 A, 250V AC, Class R	5...6	1401-N55
	201...400 A, 600V AC, Class R		
	0...30 A, 250V AC HRC Form II Fusing*	0...2* 1...3	⌘
	0...30 A, 600V AC HRC Form II Fusing*		
	31...60 A, 250V AC HRC Form II Fusing*		
	31...60 A, 600V AC HRC Form II Fusing*		
	Auxiliary Contacts for Disconnect Switches		
	1 N.O.	0...5	1495-N8
	1 N.C.	0...5	1495-N9

* HRC Form II fusing for Canada only.

* For 0...30 A only.

⌘ Fuse clip not required. Fuse bolts directly to switch and trailer fuse block.

Circuit Breaker Accessories

For use on Bulletins 503, 503L, 507, 507X, 513, 513H, 513M, 513V, 523, 533, 543, 573, 1243, 1273, 1283, 1233X, and 1233V

	Description	NEMA Size	Cat. No.
	Circuit Breaker Kits		
	3 A, 0...1/3 Hp @ 200 and 230V 3 A, 0...1 Hp @ 460 and 575V	0...1	1401-N60
	7 A, 0.5...1 Hp @ 200 and 230V 7 A, 1.5...3 Hp @ 460 and 575V	0...1	1401-N61
	15 A, 1.5...3 Hp @ 200 and 230V 15 A, 5...7.5 Hp @ 460 and 575V	0...1	1401-N62
	30 A, 5 Hp @ 200V 30 A, 5...7.5 Hp @ 230V 30 A, 10...15 Hp @ 460 and 575V	1...2	1401-N63
	50 A, 5...10 Hp @ 200V 50 A, 10 Hp @ 230V 50 A, 20...25 Hp @ 460V 50 A, 20...30 Hp @ 575V	1...3	1401-N64
	100 A, 15...25 Hp @ 200 and 230V 100 A, 30...50 Hp @ 460V 100 A, 40...50 Hp @ 575V	2...4	1401-N65
	150 A, 30 Hp @ 200V 150 A, 30...40 Hp @ 230V 150 A, 60...75 Hp @ 460V 150 A, 75...100 Hp @ 575 V	3...4	1401-N66
	250 A, 125 Hp @ 575V	5	1401-N68
	250 A, 50...60 Hp @ 200V 250 A, 60...75 Hp @ 230V		1401-N69
	Auxiliary Contacts for Disconnect Switches		
	One normally open (1 N.O.) Adapter kit may be required.* Bolted — One normally open (1 N.O.)⚡ Unilock — One normally open (1 N.O.)⚡	0...5‡ 4...5§	1495-N8
	One normally closed (1 N.C.) Adapter kit may be required.* Bolted — One normally closed (1 N.C.)⚡ Unilock — One normally closed (1 N.C.)⚡	0...5	1495-N9
	Unilock — One normally open (1 N.O.)⚡	0...2	1495-N14
	Unilock — One normally closed (1 N.C.)⚡	0...2	1495-N15
	HMCP Circuit Breaker Adapter Kits (for mounting 1 or 2 auxiliary contacts) 400 A Frame⚡	5	1495-N16
	150 A Frame	3...4	1495-N21
	250 A Frame - Enclosure Type 1, 3R/4/12, 3R and 4/4X (stainless steel)	4...5♣	1495-N22
	250 A Frame - Enclosure Type 7 & 9 (bolted & Unilock) and 4/4X (non-metallic)	0...5➤	
	250 A Frame - Enclosure Type 1, 3R/4/12, 3R, and 4/4X (stainless steel)	4	1495-N23
	Unilock — 150 A Frame⚡	3...4	1495-N21
	Unilock — 250 A Frame⚡	4...5	1495-N22

* Contact Ratings — NEMA B600 and NEMA P600.

⚡ Not available on larger sizes 6...9.

‡ For Bolted and 1 N.O.

§ For Unilock 1 N.C.

♣ For Enclosure Type 1.

➤ For Enclosure Types 7 & 9.

NEMA Disconnect Switches

Accessories

1

		Description	For Use With	Cat. No.			
		Auxiliary Contacts	1 N.O. Contact	1494C, 1494F, 1494V, and 1494G (30...400 A) Disconnect Switches	1495-N8		
			1 N.O. Contact (low-level switching)		1495-N8X		
			1 N.C. Contact		1495-N9		
			1 N.C. Contact (low-level switching)		1495-N9X		
 <i>Cat. No. 595-A Cat. No. 595-B</i>		Auxiliary Contacts (600 A Disconnect Switch only)	1 N.O. Contact	1494C, 1494G, and 1494V Disconnect Switches 600 A only	595-A		
			1 N.C. Contact		595-B		
 <i>Cat. No. 595-N1</i>		Auxiliary Contact Adapter Kit For Disconnect Switches	600 A		595-N1		
 <i>Cat. No. 1495-N24</i>		Auxiliary Contact Adapter Kit For Disconnect Switches with Left-Hand Mechanism	30...100 A Disconnect Switch	1494V Disconnect Switch with Left-Hand Mechanism, 30...100 A	 1495-N24		
			200...400 A Disconnect Switch	1494V Disconnect Switch with Left-Hand Mechanism, 200...400 A	 1495-N25		
 <i>Cat. No. 1495-N21 Cat. No. 1495-N23</i>		Auxiliary Contact Adapter Kit For Circuit Breakers	125 A and 150 A Frame Allen-Bradley, Cutler-Hammer	1494D, 1494V Circuit Breakers	 1495-N21		
			250 A, 400 A Frame Allen-Bradley, Cutler-Hammer	1494V Circuit Breaker	 1495-N23		
			250 A Frame Allen-Bradley, Cutler-Hammer	1494D Circuit Breaker	 1495-N22		
			400 A Frame Allen-Bradley, Cutler-Hammer	1494D Circuit Breaker	 1495-N16		
			600 A, 800 A, 1200 A Frame Cutler-Hammer	1494D Circuit Breaker	 1495-N13		
 <i>Cat. No. 1495-N34</i>		Electrical Interlocks	1 N.O. and 1 N.C. — early make/break	1494C, 1494G & 1494V Disconnect Switches with Left-/Right-Hand Mechanism, 30...100 A & Right-Hand Mechanism, 600 A	 1495-N34		
			2 N.O. and 2 N.C. — early make/break		 1495-N35		
			1 N.O. and 1 N.C. — early make/break	1494C, 1494G, & 1494V Disconnect Switch with Right-Hand Mechanism, 200 A, 400 A	1495-N43		
			2 N.O. and 2 N.C. — early make/break		1495-N44		
			1 N.O. and 1 N.C. — early make/break	1494C and 1494V Disconnect Switch with Left-Hand Mechanism, 30...100 A	1495-N37		
			2 N.O. and 2 N.C. — early make/break		1495-N38		
			 <i>Cat. No. 1495-N35</i>		1 N.O. and 1 N.C. — early make/break	1494V Disconnect Switch with Left-Hand Mechanism, 200 A	1495-N39
					2 N.O. and 2 N.C. — early make/break		1495-N40
1 N.O. and 1 N.C. — early make/break	1494V Disconnect Switch with Left-Hand Mechanism, 400 A				1495-N41		
2 N.O. and 2 N.C. — early make/break					1495-N42		
10 A DPDT — early break (for 30 A, Type 1 & 3R only)	1494H Safety Switch				1495-N77		
15 A DPDT — early break (for 30 A, Type 12)					1495-N78		
15 A DPDT — early break (for all 60 A, 100 A, & 200 A, Type 1, 3R, and 12)							
Electrical Interlock Adapter Kit		600 A Disconnect Switch	1494C, 1494G, 1494V Disconnect Switch	1495-N36			

* Requires an adapter kit on new installations.

⊛ One adapter kit enables up to two auxiliary contacts to be installed.

⊕ Additional adapter kit (**Cat. No. 1495-N36**) required for installation on 600 A switch.